
eELib

elenia

Apr 19, 2024

CONTENTS

1 Getting Started for Using the eELib	3
2 Getting Started for Contributing to the eELib	5
3 Indices and tables	141
Python Module Index	143
Index	145

The **eELib** (elenia Energy Library) is the software tool for simulations concerning **future power systems for prosumers**. The library with its functionalities and models can be used for various simulative investigations regarding research or current challenges in the field of a distributed electrical power system.

The goal of the eELib is creating a model library that is suitable for solving energy-related questions around prosumers (consumers that are now also producing energy). This includes, among other things, the ...

- ... creation and consideration of different **energy supply scenarios** (on building, district and grid level, among others with different penetration levels of distributed facilities like PV).
- ... comparison of different **operating strategies for energy management systems**, including e.g. variable tariffs, multi-use concepts, operator models or schedule-based flexibility.
- ... investigation of the **impacts and interactions** of prosumer households (e.g., sector coupling and electrification) **with the power grid** to identify violations of grid limits.
- ... calculating the **economic values of different use cases and strategies** for components and systems.
- ... investigation of innovative marketing strategies of market players in the spot and balancing **power markets**.

**CHAPTER
ONE**

GETTING STARTED FOR USING THE EELIB

The eELib will soon be made available to install via [PyPI - the Python Package Index](#). Until then, you need to use the installation via its [Gitlab Page](#). The procedure for this is explained in the following subsection.

GETTING STARTED FOR CONTRIBUTING TO THE EELIB

When working with the eELib, you should consider this documentation pages and the [Gitlab Repository](#). The documentation gives a short overview of what the eELib is, how it is set up and how it can be used. The short introduction is provided by this start page and the [About eELib](#) section. Afterwards you should have a look at the [Wiki](#) part of the documentation. It provides info about how to

- Set up your environment to work with the eELib via an [Installation Guide](#),
- Work with [Git](#) (version management control) and its different operations
- [Set up a scenario](#) and [run a simulation](#)
- Add new implementations like [models](#)

Additionally, the section [API reference](#) provides an overview of the setup of the eELib and its models and gives explanations to the classes and their methods, which are provided by the docstrings in the source code.

One major thing to know for working with and using the eELib is that we are [using a co-simulation tool \(mosaik\)](#) to run simulations, as the eELib itself just provides the implementation of models and no configuration to run a simulation. The sense of this is further explained in the [About eELib](#) section on [Coupling With mosaik](#). Additionally, there is a short [mosaik introduction](#) and the linking of tutorials using mosaik given in the Wiki.

2.1 For contributing to the eELib, it is useful to follow these steps:

1. [Create a local copy of the Git repository](#) on your computer. Afterwards, make sure the eELib folder exists on your local hardware and the test scenarios can be executed without any error.
2. Get familiar on how you can [use Git for version control](#).
3. Read the [About eELib](#) section to get a sense of the structure of the eELib and how simulations are carried out.
4. Familiarize with the test scenarios (for one single building and a small 8-bus low-voltage grid):
 - For running a simulation, we need four files: A **scenario script** and the scenario data, which is divided into a **model data** file, the **model connections** and a **grid** file. Additionally, corresponding input data like files for the input of pv generation or a household baseload need to be provided. The setup of these files and their combination is more deeply explained in the Wiki page on [Running a simulation](#).
5. You should additionally have a look at a simulator and model for an exemplary model type. The idea of using simulators and models separately is explained in the [Coupling With mosaik and Architecture of a Simulation*](#) part of the [About eELib section](#). You can find further information on [Simulators](#) and [Models](#) and how they are set up in the Wiki pages. This should give you the relevant information to implement your own or advance existing models.

6. If you are interested in setting up (implementing) a new operating strategy for energy management systems (EMS), you should have a look at the explanations on [*Implementing a new EMS strategy*](#). Following the steps mentioned there you should be able to set up your operating strategy and integrate it into your simulation.

2.1.1 About eELib

The models in eELib - like other models too - represent the real processes of existing components in a quasi-stationary / quasi-dynamic approach under the assumption of simplifications. The implementations of the eELib hold some characteristics, that will shortly be explained here.

Folder Structure

This is to give an overview of where different parts of the eELib are stored:

- **docs** : Files for the documentation with AutodocSphinx into the GitLab Pages style. Documentation is stored in `.rst` files within the source subfolder.
- **eelib** : This stores the main part of the elenia Energy Library, as it contains the models and all other functionalities.
 - **core** : Here all of the models are stored. This is divided into the devices (like PV system or electric vehicle), control models (like energy management system), grid models (for power flow calculation), forecasting, and market models (like intraday market).
 - **data** : This contains all models that are “just” retrieving input data (like a simple csv-reader). It also includes the functionalities for simulation data to be collected and assessed.
 - **utils**
[Contains helper functions and classes, exemplarily for running a simulation or] evaluating and plotting/presenting outputs of simulations.
 - **testing** : Contains all of the testing for the models and functionalities of the library.
- **examples** : This folder gives data and scripts for some test scenarios and should provide an overview of how the eELib can be used. Some exemplary data is stored in the data subfolder which also contains the simulations results.

The highest folder also contains various files that are used for setup of the environment, gitlab communication, a README for information etc.

You can also familiarize with the folder structure of the [*eElab package*](#) by exploring the [*API Reference*](#).

Plug-and-Play Style

The programming of the models should be implemented in such a way that it can also be used in real-world applications without any adjustments. This ensures that, for example, in the case of changed simulation scenarios or also in laboratory investigations, the same source code can simply be applied in a “**plug-and-play**” way.

Coupling With mosaik and Architecture of a Simulation

In order to make the above mentioned investigation cases possible, one needs to couple the different models of the library in scenarios to be created, e.g. a **PV** system with the energy management system (**EMS**). For this purpose, an *Orchestrator* is to be used, which performs the exchange of data sets between models, calls the calculation of the individual models and controls the general model flow as well as the coupling with a database. **mosaik** is intended for these tasks. Certain input values are assumed, data sets are calculated internally and output data sets are issued. See the *eELib documentation part on mosaik* for more information. The eELib should definitely be usable with other orchestrators of a simulation, but the explanations in this documentation are done for mosaik and its simulation orchestration. Additionally, the eELib provides simulators to its models that serve the purpose of APIs for a simulation with mosaik.

The following graphic illustrates the architecture of a simulation and the usage of mosaik in it. For explanations to the terms used for the parties also have a look at the *glossary*. While the eELib provides implementations for the models and their simulators, mosaik is used for a simulation. Additionally a scenario script and data for the scenario (like parameterization of the model entities and linking of entities) have to be provided. Examples for these last two are provided within the eELib in an *examples* part.




Fig. 1: The architecture of a simulation using mosaik with the eELib.

For a setup of a simulation, have a look at the following illustration. It depicts the physical and data connections between the different parts of the eELib.




Fig. 2: The setup of a (grid) simulation with the eELib.

Event-Based Simulation

The computations within the eELib - using mosaik - are executed in an **event-based** manner. This implies the process of a simulation to depend on the triggering of events. Independent of a *step size* - the length of a simulation step in seconds - the process within one simulation step is executed by event triggering, as depicted in the following figure. To add to the [explanation of mosaik](#), the execution of events depends on the triggering of such events. E.g. the simulation of a BSS is triggered by an EMS sending a power set value to the BSS. For this, mosaik knows about ...

- ... when each model has to be called for calculation.
- ... which outputs for the models are send to which inputs for other models.





Fig. 3: The simulation process of event-based simulation.

1. mosaik calls the calculation of the entities via the simulator

2. models calculate output with the already given input
3. simulator returns the time, when the models have to be calculated next
4. mosaik sends the output to a connected entity (e.g. the power generation of a PV system to the HEMS)
5. mosaik then calls the calculation of the next entity for which all inputs have been collected (this is done by means of the word “triggering”, so the finalized calculation of one entity triggers the calculation of another entity...)

This is done within a single timestep as long as data is send between the entities such that the renewed calculation of a model entity is triggered. mosaik calls the execution of the models in the way they are connected to each other and send values each way. If everything is finished for this timestep, mosaik advances to the next timestep and the simulation process carries on.

The implementation of the process within one simulation step can be better seen in the next figure. It is shown, that when a model is called, the inputs for the models are provided by mosaik and set by the simulator. Afterwards the models are stepped and ultimately the simulators are called to extract the (by mosaik requested) result outputs from the models.



2.1.2 Wiki

The Wiki provides a walkthrough for different tasks, as well as self-aid in case of common questions.

For a detailed start, we recommend fully reading this Wiki. It covers...

- **Basics** - Setup of a *programming environment*,
- **Usage** - Guides to *configure a scenario* and *run a simulation*,
- **Contribution** - Introduction to *git workflow* and adding *models/simulators/strategies*
- ... and much more like explanations to *Forecasts and Schedules* and a *glossary*

Installation and Setup

Installation of Python

1. Download Python version 3.10.X from [Python Downloads](#)
2. When the download is finished, double-click the installer.
3. Select *Install for all users* and click *Next*.
4. The default installation path is okay. Click *Next*.
5. In the *Customize Python* page, click on the *Python* node and select *Entire feature will be installed on local hard drive*. Make sure that *Add python.exe to Path* is enabled. Click *Next*.
 - If not, the Python Path has to be added to system variables by hand afterwards
6. When Windows asks you to allow the installation, do so. Wait for it to happen. Click *Finish*

Note: This will also install the Python package manager pip. For checking and if not, see [Pip getting started](#) (can also be used generally for working with pip).

Installation of Git

1. In order to work with version control management, you need to install Git
2. Visit the [Git Getting Started Page](#) and ...
3. Install Git by downloading the [Installer](#) and clicking through the setup
4. For Git steps/processes afterwards, have a look at the [Git Workflow](#) page

Installation and Setup of Python IDE (VSC)

Easier than using command window or PowerShell is the use of an IDE (integrated development environment) for Python, especially when working with the code.

1. Decide for an IDE. There are several good options: PyCharm, Visual Studio Code, Jupyter Notebook, IDLE, Spyder, Pydev
 - We recommend Visual Studio Code (VSC) for eELib, so this tutorial will be based on VSC
2. If needed, download VSC from the [VSC Homepage](#) and install it
3. Configuration of User Settings
 1. Install some Extensions (**Ctrl + Shift + X**)
 - Python (for working with python programming language)
 - autoDocstring (for simple creation of docstrings for classes and methods)
 - H5Web (for a quick and easy view of the HDF5 simulation output)
 - Other possibly helpful extensions: Black Formatter, Git Graph, GitLens, Rainbow CSV
 2. Settings -> Editor: Default Formatter -> set to “Black Formatter”
 3. Settings -> Text Editor -> Formatting -> Format on Save should be true
 4. Settings -> Features -> Notebook -> Format on Save should be true

5. For max line lenght of 100 set: Settings -> Text Editor -> Rulers -> click “Edit in settings.json” and then set ““editor.rulers”: [100]” (you can instantly see the vertical line shift to the right when saving the file)

Cloning eELib Repository to your Local Workspace

1. Clone the Git Repository with VSC: When all folders are closed, select *Clone (Git) Repository*
 - https address: “<https://gitlab.com/elenia1/elenia-energy-library>”
2. You can also use GitBash (or other Git programs) for cloning (personal choice, up to you)

```
$ git clone https://gitlab.com/elenia1/elenia-energy-library
```

3. Afterwards follow the steps you will be guided through, as you probably need to give your username and password for Gitlab

Note: The path to the project folder will now be noted as <*Project Folder*>.

Setup Working in VSC with eELib

1. Open VSC and navigate to <*Project Folder*>
2. Open new Terminal: PowerShell is recommended (GitBash or Command Window are possible too, but not as mighty)
 1. Run `python -m venv <_VENV-PATH_>`
 - For virtual environment path <*VENV-PATH*>, we typically use `.venv` (which for this tutorial we will now exemplarily do so)
 - Accept VSC for acknowledging new environment, if it is detected
 2. Run the activation script for Powershell: `.venv\Scripts\Activate.ps1`
 - In case Scripts can't be executed, you have to adjust the Execution Policy by running `Set-ExecutionPolicy Bypass -Scope CurrentUser -Force` and try again
 - (Command window has different activation file ‘activate.bat’)
 - Check: If successful, the prompt should now start with (`.venv`)
 - Check whether the correct python interpreter is selected: `python --version` (Output: Python 3.10.X)
3. Install requirements into the virtual environment
 - If VSC explorer isn't already in the repository folder, you have to navigate there
 - Run `pip install -r requirements.txt`
4. If a new release of pip is available, you can update it via `python.exe -m pip install --upgrade pip`
5. Check: If you open a Python file, the selected virtual environment is listed in the lower right corner in the blue row (`.venv`)
6. Install Configurations for Processes, that are executed before each commit
 - Run `pre-commit install`

Test successfull installation

1. You can test the functionality and correct installation by running a testcase
 - Open the file `test_scenario_building.py` in the examples folder and click on the *Run* sign in the upper right corner (Quick start typicall possible with F5)
 - (Or run `python test_scenario_building.py` in the terminal)
2. If you are not able to run the `test_scenario` and get the error no module named 'eelib' ...
 - If your are in your *<Project Folder>*: Execute `pip install -e`.
 - Otherwise you have to insert the path: Execute `pip install -e <Project Folder>`

Git Workflow

This wiki page will give detailed instruction on how to work with the commands in Git, especially via Visual Studio Code (VSC)! It will not provide a full overview of how the git process works but informs about the necessary commands.

Create Personal Access Token

1. In Gitlab, via 'Edit profile', you go to 'Access Tokens' and create a Token.
 - The name is irrelevant and the expiration date can be set to a year.
 - You can select all scopes.
2. The Token has to be saved somewhere, because you have to give it in order to establish a connection from your local repository to the online repository.

Cloning

The next thing that has to be done is cloning the online Git repository onto your local computer.

1. You can do this via Visual Studio Code by typing in `gitcl` in the command line and following the processes.
 - Use either the URL or SSH-key from the repository.
 - When asked for username and password you have to give your **GitLab username** and the **Personal Access Token**.
 - This process can also be done via GitBash, when going to the target folder and typing in `git clone <REPO-URL>`.
2. It is recommended to end this process by saving the Personal Access Token in this Git project by running `git remote set-url origin https://oauth2:[PersonalAccessToken]@<GIT-REPO>` via GitBash, then your Git program will not ask for the Token every time.
3. You should also set your username and mail adress for when using Git by running `git config --global user.name "Your Name"` resp. `git config --global user.email "youremail@yourdomain.de"`.

Visual Studio Code

- Visual Studio Code allows easy version management via Git.
- You should use the window “Source Control” (left side) to always see the current changes you did on the code.
- When using the Extension [Git Graph](#), you can also have an overview of all the changes that have been done in the repository (possibly by others too!).

Change the Branch

- Before any adaption to the code, you should always check your currently selected branch.
- The default is always the **main** branch, in which you should **not change anything!**
- Changing the selected branch can be done by the Command “Source Control -> Branches -> Switch to Another Branch” and then selecting that specific branch. Or you can use the command `check-out` to in order to switch to another branch.

Hint: You can only change the selected branch, when you currently have no changes in the files.

Saving Changes (Commit)

The next thing is saving changes, that were coded locally - this is done by ‘committing’ the code, which is still a local process but kind of saves the stage at the moment.

1. You have to “stage” the relevant code files by pressing the “plus” (+) sign.
2. Then type in a fitting commit message (What have you done? Short!).
3. Last thing is to hit the commit button (“check” sign).

Getting Changes from Online Repository (Pull)

When others made relevant code changes, which you might need, you can get their changes from the online repository by “pulling” them.

1. For that you must have everything committed - so do that first.
2. To pull the current state of the branch from the online repository, simply click on the 3 points and select “Pull”.
3. In case any merge conflicts occur, see step [Merge Changes Into Your Local Branch](#)

Sending Changes to Online Repository (Push)

- When having implemented relevant code changes, which other programmers/users might need, AFTER VALIDATING THEM you can (and should regularly) push your saved commits.
- This should only be done after pulling the online repository first.
- Also, all current changes have to be staged.
- To push, simply click on the 3 points and select “Push”.

Merge Changes Into Your Local Branch

- Merging Changes is generally needed, when two programmers changed parts of the same code and Git does not know, which “solutions” it should select.
- This process should be done **carefully**, as nobody wants to discard changes, that have been done by others.
- Merging can be needed in two cases: when you merge another branch into your own local branch, or when you pull the online repository status into your local state.
- In the process, click on the files with “*Merge Conflicts*”, go through the problems and try to find a solution that appropriately takes both solutions into account.
- If you have concerns, ask for help!
- Merges with merge conflicts always have to be committed after the conflicts have been solved, and the file is saved and staged.

Create a New Branch for each Topic

The *work flow* is supposed to include the creation of a new branch for each problem. So in case you want to create a new model, you create a branch named `model/[model_name]` and work on this problem only in this branch. Or if you want to fix something existing, create a branch named `bugfix/[problem_name]` etc.

This is a way to structurize the current work and additions to the joint use of the library in the `main` branch.

Compare the State of two Branches

When working on a topic in a specific branch, it can be beneficial before a merge request to review the changes that one made. So after merging the current state of the `main` branch into your own branch, you can compare these two branches (without creating a merge request first) by going to your branch in the Gitlab repository and clicking **Compare**. This can also help to check whether the merge of the `main` branch into your branch worked.

Merge Your Changes into the main Branch

When you

1. completed a task in a specific branch (don't use the `main` branch for that!)
2. and tested your stuff,

you can make this accessible for others via the `main` branch.

For that you should ...

1. ... merge the current state of the `main` branch into your (feature) branch.
2. ... push your changes into the remote branch.
3. ... go to the GitLab Repository and create a merge request for your branch into `main`. There you should also assign a *developer* to shortly check your updates and may even assign a *reviewer*.

The merge will then be completed and afterwards your changes are also part of the `main` branch.

Mosaik

mosaik, according to the [mosaik documentation](#) is a “flexible Smart Grid co-simulation framework”. It can combine various existing models to run large-scale scenarios - and this is what we intend it for in our use. mosaik can combine our prosumer models like electric vehicles, energy management systemens, grid calculations, and all the others. While we in our eELib focus on the implementation of power system models and energy management strategies, mosaik is used for simulatory behaviour, as explained in the [overview](#).

For introduction to mosaik you can or should have a look at its [tutorial](#). Recommended articles of this tutorial for the use within the eELib are:

1. Integrating a simulation model into the mosaik ecosystem
2. Creating and running simple simulation scenarios
3. (optionally helpful) Adding a control mechanism to a scenario
4. (optionally helpful) Integrating a control mechanism

Configure a Scenario With an Excel File

Caution: Still WIP and might not work.

Excel-file setup

1. Open Excel-file (`eelib\utils\simulation_setup\sim_config_data.xlsx`). This one is part of the [utils package](#).
2. The sheets **bus, load, ext_grid, trafo, line, sgen, storage** are used to configure the grid.



3. To **add a new entity** to the grid you create a new row and include the index name and the init_vals of the element. More information about the characteristics of the grid elements: <https://pandapower.readthedocs.io/en/v2.13.1/elements.html>

(Make sure you have at least **one transformer, one external grid and buses are connected through lines**)

	name	vn_kv	type	in_service	x	y
0	bus_0	20	b	True	1	0
1	bus_1	20	b	True	2	0
2	bus_2	0.40	b	True	3	0
3	bus_3	0.40	b	True	4	0
4	bus_4	0.40	b	True	5	-1
5	bus_5	0.40	b	True	6	-1
6	bus_6	0.40	b	True	7	-1
7	bus_7	0.40	b	True	6	0
8	bus_8	0.40	b	True	7	0
9	bus_9	0.40	b	True	8	0
10	bus_10	0.40	b	True	9	0
11	bus_11	0.40	b	True	6	1
12	bus_12	0.40	b	True	7	1

4. After configuring the grid you can add the model entities.
 1. Open the sheet ems and define the number of ems and connect them to a bus
 2. Households, charging stations or pv can be connected to a bus too (but only one per bus)
 3. Adding a new entity of a model type is similar to add a new grid element (important is to set the connection to an ems or a bus and differentiate between csv_reader model or exact mode type)
 4. Now set the init_vals for every entity of the model type

bus	ems	name	type	output_type	p_rated	strategy	p_rated_csv	p_rated_profile	cos_phi	filename	header_rows	date_format	start_time
0		2_charging_station_0	exact	AC	11000	max_P						2 YYYY-MM-DD HH:mm:01.01.2020 00:00	
1		4_charging_station_csv_0	csv				11000	11000	0.95	examples			
2	12	charging_station_csv_1	csv				11000	11000	0.95	examples		2 YYYY-MM-DD HH:mm:01.01.2020 00:00	

Create .json files for scenario

1. Open jupyter notebook eelib\\utils\\simulation_setup\\script_sim_setup.ipynb
2. Run the corresponding cells to import the packages and set the input and output paths:

To create a grid

1. Read the sheets from the excel file
2. Run the “create grid data file” cell
3. An image of the grid is shown underneath and the .json-file is saved at C:/Users/Public/Documents

To create model data file

1. Read the model type sheets from the excel file
2. Run “create model data file” cell
3. .json-file is saved at C:/Users/Public/Documents

To create connection file

1. Run the cell “Create model_grid_config file”

2. File is saved at C:/Users/Public/Documents
3. Now run a scenario file from examples folder, e.g. test_scenario_grid or test_scenario_building

Add a completely new model type

1. Create a new sheet for the model type in the excel file
2. Create entities and set the init_vals and the connection to a bus or ems for the new model type
3. Open the jupyter notebook eelib\\utils\\simulation_setup\\script_sim_setup.ipynb
 1. Read the new excel sheet

```
df_new_model_type = pd.read_excel(FILE_SCENARIO_INPUT, sheet_name="new_model_type", index_col=0)
```

2. Add new model entities to model_data file (if necessary differentiate between exact- and csv-model)

```
#create an empty list for the new model type
new_model_type = []
for i in df_new_model_type.index:
    # Add all init_vals for model type
    new_model_type_data = {
        "datafile": df_new_model_type.at[i, "datafile"],
        "start_time": df_new_model_type.at[i, "start_time"],
        "date_format": df_new_model_type.at[i, "date_format"],
        "header_rows": int(df_new_model_type.at[i, "header_rows"]),
    }
    new_model_type.append(new_model_type_data)
# add new model type list to dictionary
model_data= { ...
            new_model_type : new_model_type
            }
```

3. Add new model type to model_grid_config file

```
# create an empty list for the new model type
new_model_types = []
# loop over all entities
for j in df_new_model_type.index:
    # if the entity is connected with bus or ems the name of the entity is added to the list new_model_types
    if df.loads.at[i, "bus"] == df_new_model_type.at[j, "bus"] or ems_idx == df_new_model_type.at[j, "ems"]:
        new_model_type = df_new_model_type.at[j, "name"]
        new_model_types.append(new_model_type)
# add new model type list to dictionary
elements = {...
            new_model_type: new_model_types
            }
```

4. Now run the cells to create new .json files

Set Up and Run a Simulation

What files are needed for a simulation?

Scenario script

Start the simulators, build the models, create the connections and start mosaik. Exemplary scripts for building, grid etc. can be found in the `examples` folder. The setup of these scripts is explained below in the *Scenario Script Configuration* section.

```
⌚ test_scenario_building.py ×
examples > ⌚ test_scenario_building.py > ...
27  # define paths and filenames
28  DIR = sim_help.get_default_dirs(
29      os.path.realpath(os.path.dirname(__file__)), scenario="building", grid=None, format_db="hdf5"
30  )
31
32  # print paths
33  _logger.info(f"Selected model data: {DIR['MODEL_DATA']}")"
34  _logger.info(f"Results will be stored in {DIR['DATABASE_FILENAME']}")"
35
36
37  # Sim config.: Simulators and their used model types with the properties to store into DB
38 SIM_CONFIG = {
39      # used database, will be left out for model creation and connections
40      "DBSim": {"python": "eelib.data.database.hdf5:Hdf5Database"},
41      # all the used simulators and their models for this simulation
42      "EMSSim": {
43          "python": "eelib.core.control.EMS.EMS_simulator:Sim",
44          "models": {"ems": ["p_balance", "q_balance", "p_th_balance", "p_th_dem"]},
45      },
46      "CSVSim": {
47          "python": "eelib.data.csv_reader.csv_reader_simulator:Sim",
48          "models": {
49              "HouseholdCSV": ["p", "q"],
50              "PvCSV": ["p", "q"],
51              "ChargingStationCSV": ["p", "q"],
52              "HeatpumpCSV": ["p_el", "q_el"],
53              "HouseholdThermalCSV": ["p_th_room", "p_th_water"],
54          },
55      },
56      "CSSim": {
57          "python": "eelib.core.devices.charging_station.charging_station_simulator:Sim",
58          "models": {"ChargingStation": ["p"]},
59      }
}
```

Fig. 4: examples/test_scenario_building.py (01/24)

Model data file

Information on number of models and their parameterization.

This is stored as a dict with fields for each model type, named by the class of the model. E.g. the field “*HouseholdCSV*” contains a list of all household baseloads that read from a csv file. In the example below there is just one baseload, and if more of these should be integrated, we could add a second dict with initialization parameters for this model inside of the given list.

One exception is the Energy Management System (EMS), as they are all sorted within the “ems” section. Their differentiation is coming from the field “*strategy*”, which is referring to the chosen operating strategy of the EMS.

Listing 1: examples/data/model_data_scenario/model_data_building.json
(01/24)

```

1  {
2      "ems": [
3          {
4              "strategy": "HEMS_default",
5              "cs_strategy": "balanced"
6          }
7      ],
8      "HouseholdCSV": [
9          {
10             "p_rated": 4500,
11             "p_rated_profile": 4000,
12             "cos_phi": 1.0,
13             "datafile": "examples/data/load/4_persons_profile/load_34.csv",
14             "date_format": "YYYY-MM-DD HH:mm:ss",
15             "header_rows": 2,
16             "start_time": "2014-01-01 00:00:00"
17         }
18     ],
19     ...

```

Model connections

Information on the linking of model entities in the simulation. This includes the connections between grid buses, ems models, and the prosumer devices. It is stated, which devices are located at which grid connection point (by the naming of the corresponding load bus) and whether there is an EMS used. If no EMS is given at a loadbus (see “*0-load_1_2*” below), the devices are directly connection to the grid, but this should only be possible for some of the devices, as e.g. a single heat pump makes no sense.

Listing 2: examples/data/grid/grid_model_config.json (01/24)

```

1  {
2      "0-load_1_1": {
3          "ems": "HEMS_default_0",
4          "load": [
5              "HouseholdCSV_0"
6          ],
7          "household_thermal": [],
8          "pv": []
}

```

(continues on next page)

(continued from previous page)

```

9      "bss": [],
10     "hp": [],
11     "cs": [
12       "ChargingStation_0"
13     ],
14     "ev": [
15       "EV_0"
16     ]
17   },
18   "0-load_1_2": {
19     "ems": "",
20     "load": [
21       "HouseholdCSV_1"
22     ],
23   ...

```

Grid file

In .json format (possibly created via pandapower). Provides detail on the given buses and their connections via grid lines (plus their parameterization).

Listing 3: examples/data/grid/example_grid_kerber.json (01/24)

```

1 {
2   "_module": "pandapower.auxiliary",
3   "_class": "pandapowerNet",
4   "_object": {
5     "bus": {
6       "_module": "pandas.core.frame",
7       "_class": "DataFrame",
8       "_object": "{\\"columns\\": [\"name\", \"vn_kv\", \"type\", \"zone\", \"in_service\"], \\
9       \"index\\\": [0, 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17], \\
10      \"data\\\": [[\"Trafostation_OS\", \\
11        10.0, \"b\", null, true], [\"main_busbar\", 0.4, \"b\", null, true], [\"MUF_1_1\", 0.4, \"n\", \\
12        null, true], [\"loadbus_1_1\", 0.4, \"b\", null, true], [\"KV_1_2\", 0.4, \"b\", null, true], [\\
13        \"loadbus_1_2\", 0.4, \"b\", null, true], [\"MUF_1_3\", 0.4, \"n\", null, true], [\"loadbus_1_3\", \\
14        0.4, \"b\", null, true], [\"KV_1_4\", 0.4, \"b\", null, true], [\"loadbus_1_4\", 0.4, \"b\", null, \\
15        true], [\"MUF_1_5\", 0.4, \"n\", null, true], [\"loadbus_1_5\", 0.4, \"b\", null, true], [\"KV_1_6\", \\
16        0.4, \"b\", null, true], [\"loadbus_1_6\", 0.4, \"b\", null, true], [\"MUF_2_1\", 0.4, \"n\", \\
17        null, true], [\"loadbus_2_1\", 0.4, \"b\", null, true], [\"KV_2_2\", 0.4, \"b\", null, true], [\\
18        \"loadbus_2_2\", 0.4, \"b\", null, true]]}"

```

Tip: All files can be created (more easily) with a *Scenario Configurator* (.ipynb) via an excel file. Or use existing files and adapt the parameterization.

Configuration of a Scenario Script

Note: All of these code-blocks derive from examples/test_scenario_building.py as of (01/24) if not stated otherwise.

Setup

Listing 4: import of used packages (examples, like mosaik or logging during the simulation)

```
8 import os
9 import mosaik
10 import eelib.utils.simulation_helper as sim_help
11 from eelib.model_connections.connections import get_default_connections
12 import logging
```

Listing 5: Setting of paths for simulation data and used model simulators

```
27 # define paths and filenames
28 DIR = sim_help.get_default_dirs(
29     os.path.realpath(os.path.dirname(__file__)), scenario="building", grid=None, format_
30     ↴db="hdf5"
31 )
```

Listing 6: Define simulators and models for the simulation

```
37 # Sim config.: Simulators and their used model types with the properties to store into DB
38 SIM_CONFIG = {
39     # used database, will be left out for model creation and connections
40     "DBSim": {"python": "eelib.data.database.hdf5:Hdf5Database"}, 
41     # all the used simulators and their models for this simulation
42     "EMSSim": {
43         "python": "eelib.core.control.EMS.EMS_simulator:Sim",
44         "models": {"ems": ["p_balance", "q_balance", "p_th_balance", "p_th_dem"]},
45     },
46     "CSVSim": {
47         "python": "eelib.data.csv_reader.csv_reader_simulator:Sim",
48         "models": {
49             "HouseholdCSV": ["p", "q"],
50             "PvCSV": ["p", "q"],
51             "ChargingStationCSV": ["p", "q"],
52             "HeatpumpCSV": ["p_el", "q_el"],
53             "HouseholdThermalCSV": ["p_th_room", "p_th_water"],
54         },
55     },
56 }
```

(continues on next page)

(continued from previous page)

```
55 },
56 . . .
```

This is done in a format that fits both mosaik for orchestrating the simulation and also the handling of data and simulation setup. So in the “SIM_CONFIG” dict we first need to give all used simulators as the keys (e.g. “CSVSim” for all used csv readers). With the sub-key “python” we then provide the path to this simulator in our library (e.g. “eelib.data.csv_reader.csv_reader_simulator:Sim”). Under “models” we list all of the used model types within the simulation for this simulator (e.g. “HouseholdCSV”, “PvCSV”) and the attributes of them that should be stored within the database (e.g. [“p”, “q”] for active and reactive power of the PV system).

Listing 7: Configure start and end time of the simulation, step length, and whether to use forecasts. Model data and connections are read and SIM_CONFIG is handed to mosaik.

```
82 # Configuration of scenario: time and granularity
83 START = "2020-01-01 00:00:00"
84 END = "2020-01-04 00:00:00"
85 USE_FORECAST = False
86 STEP_SIZE_IN_SECONDS = 900 # 1=sec-steps, 3600=hour-steps, 900=15min-steps, 600=10min-
87 # steps
88 N_SECONDS = int(
89     (
90         arrow.get(END, "YYYY-MM-DD HH:mm:ss") - arrow.get(START, "YYYY-MM-DD HH:mm:ss")
91     ).total_seconds()
92 )
93 N_STEPS = int(N_SECONDS / STEP_SIZE_IN_SECONDS)
94 scenario_config = {
95     "start": START, # time of beginning for simulation
96     "end": END, # time of ending
97     "step_size": STEP_SIZE_IN_SECONDS,
98     "n_steps": N_STEPS,
99     "use_forecast": USE_FORECAST,
100    "bool_plot": False,
101 }
102 # Read Scenario file with data for model entities
103 with open(DIR["MODEL_DATA"]) as f:
104     model_data = json.load(f)
105
106 # Read configuration file with data for connections between prosumer devices
107 model_connect_config = get_default_connections()
108
109 # Create world
110 world = mosaik.World(SIM_CONFIG, debug=True)
```

With this *mosaik.World* we start the orchestrator mosaik and afterwards set up the simulation using mosaik. For this, we mostly use mosaik functionalities within the helper functions of the *eelib.utils.simulation_helper* folder. Regarding the order, we mostly first handle the exceptions of the models, like the output database, and afterwards use the helper functions for all of the other models. For a deeper understanding of what is done with these steps, you should have a look at the implementation of these helper functions and possibly even the setup of mosaik for creating the simulation.

Start Simulators for all used Models

```

120 # start all simulators/model factories with mosaik for data given in SIM_CONFIG
121 dict_simulators = sim_help.start_simulators(
122     sim_config=SIM_CONFIG, world=world, scenario_config=scenario_config
123 )

```

Initiate Model Entities using the created Simulators for each Device Type

```

133 # create all models based on given SIM_CONFIG
134 dict_entities = sim_help.create_entities(
135     sim_config=SIM_CONFIG, model_data=model_data, dict_simulators=dict_simulators
136 )

```

Connect Entities

The connections for each entity are listed in the `model_connect_config` data. Now tell mosaik about the and let mosaik create graphs for how the calculation procedure of the simulation is to be executed.

```

143 # connect all models to each other
144 sim_help.connect_entities(
145     world=world,
146     dict_entities=dict_entities,
147     model_connect_config=model_connect_config,
148     dict_simulators=dict_simulators,
149 )

```

Run Simulation

```

161 world.run(until=scenario_config["n_steps"], print_progress=True)

```

Just go Ahead and Run a Simulation

- You can run one of the `test_scenario`s in the `examples` folder
 - `building`: Just one single building with a bunch of different devices to see the operation of devices inside the household.
 - `grid`: Simple low voltage grid (2 feeders with six resp. two household connection points) to get an estimation of the impact of different operating strategies on the local grid.
- While running the simulation, some stuff is logged like creation of simulators, entities, and connections. Additionally, mosaik plots the progress of the whole simulation (like how many time steps are finished calculating).

- Adapting the parameterization in the *simulation files* can yield quite different results.
- Running one of the simulations will create a .hdf5 results data file in the folder /examples/results.
- You can view the information of this file via the [H5Web Extension](#) in Microsoft VSC and plot the profiles (stored under Series and the name of the corresponding simulator) of the used devices.
- In case you want, you can set the parameter *bool_plot* in the *scenario_config* dict to true (only do this for small simulations!), mosaik will then present 4 plots for the connections, the simulation process and the timely duration during the simulation.

Create your own simulation

1. Copy one of the *test scenarios* and delete all of the redundant simulators/devices/connections.
2. Set up corresponding *model* (and *grid*) data as well as a *model connection file*.

Configuration of a Model

A model, as explained in the [glossary](#), represents a real process or component in form of code. It follows the general structure of *Input - internal calculation - output*, which is triggered by its corresponding [simulator](#) that needs to be existent for using the model in simulations. The model is just representing the calculation steps and an entity (see the [glossary](#)) is the instantiation of a model. So within a scenario it is possible to have multiple entities (like battery storages) for one model type (battery storage model).

This page explains the structure of a _model.py to enable you to create your own model. As there can be different implementations of a device type (like storage system), there can be more than one class within a _model.py (like a very detailed model and a generic model).

Note: All code-blocks derive from charging_station_model.py as of (01/24) if not stated otherwise.

Imports

Listing 8: Import relevant packages for the model calculation

```
1 import warnings
2 import math
3 from eelib.utils import cos_phi_fix
```

Class definition

Listing 9: Short explanation, listing of all model parameters with their allowed values for initialization (+ method to return these).

```
13 class ChargingStation:
14     """Models a charging station for electric vehicles of different types."""
15
16     # Valid values and types for each parameter
```

(continues on next page)

(continued from previous page)

```

17 _VALID_PARAMETERS = {
18     "p_rated": {"types": [float], "values": (0, math.inf)},
19     "output_type": {"types": [str], "values": ["AC", "DC"]},
20     "charge_efficiency": {"types": [float, int], "values": (0, 1)},
21     "discharge_efficiency": {"types": [float, int], "values": (0, 1)},
22     "cos_phi": {"types": [float, int], "values": (0, 1)},
23 }
24
25 @classmethod
26 def get_valid_parameters(cls):
27     """Returns dictionary containing valid parameter types and values.
28
29     Returns:
30         dict: valid parameters for this model
31     """
32     return cls._VALID_PARAMETERS

```

E.g. the rated power `p_rated` of a charging station has to be a floating point value or should be non-negative. The efficiency should have a value between zero and one (100%). These values are used when creating a model in simulations to check for correct values.

Initialization method `__init__()`

Listing 10: takes parameter values as inputs

```

55 def __init__(
56     self,
57     ename: str,
58     p_rated: int,
59     output_type: str = "AC",
60     charge_efficiency: float = 0.99,
61     discharge_efficiency: float = 0.99,
62     cos_phi: float = 1.0,
63     step_size=60 * 15, # step size in seconds
64 ):

```

Listing 11: creates entity of this model by setting the properties and initializing attributes

```

78 # Set attributes of init_vals to static properties
79 self.ename = ename
80 self.p_rated = p_rated # rated active power (AC/DC) [W]
81 self.output_type = output_type # source AC/DC [-]
82 self.discharge_efficiency = discharge_efficiency # discharging efficiency [-]
83 self.charge_efficiency = charge_efficiency # charging efficiency [-]
84 self.cos_phi = cos_phi
85
86 # initialize dynamic output properties
87 self.p = 0 # Active Power (after control) [W]

```

(continues on next page)

(continued from previous page)

```

88     self.q = 0 # Reactive Power (after control) [W]
89     self.p_device = {} # active power for every vehicle [W]
90     self.p_min = 0 # Minimal active Power [W]
91     self.p_max = 0 # Maximal active Power [W]
92
93     ...
94
95     # save time step length and current time step
96     self.step_size = step_size
97     self.time = 0

```

Model methods

Listing 12: Type-specific function like calculation of power limits, aging, efficiency, adaption of stored energy etc.

```

99     def _calc_power_limits(self):
100         """Calculate the power limits for the charging station with the input thats coming
101         ↪from the
102         electric vehicles.
103
103     Raises:
104         ValueError: If the power limits of at least one connected ev do not work
105         ↪together.
106         """
106
107     # calculate current efficiency depending on the direction of power flow
108     self._calc_current_efficiency()
109
109     # in case no ev is connected to cs - no active power flexibility
110     self.p_min = 0
111     self.p_max = 0
112     for ev_id, ev_data in self.ev_data.items():
113         # check for each ev if connected - consider their limits, efficiency and
114         ↪nominal power
115         if ev_data.appearance:
116             # check if min. and max. power are correct
117             if ev_data.p_min > ev_data.p_max:
118                 raise ValueError(f"Min. and max. power of ev {ev_id} do not comply.")
119             # handle the power limits
120             self.p_min = max(
121                 self.p_min + ev_data.p_min / self.efficiency,
122                 -self.p_rated,
123             )
124             self.p_max = min(
125                 self.p_max + ev_data.p_max / self.efficiency,
126                 self.p_rated,
127             )

```

(continues on next page)

(continued from previous page)

128
129 * * *

step() method

Within the `step()` method, the calculation processes are executed for the model entity.

This example is coming from the `storage_model.py` (01/24).

Listing 13: For handling of the processes of the model (its calculation) within a time step

```
226 def step(self, time):
227     """Performs simulation step of eELib battery model.
228     Calculates all of the Dynamic Properties based on the Input Properties.
229
230     Args:
231         time (int): Current simulation time
232     """

```

Listing 14: At first: Always handling of a new time step (if entity was called for first time, do some processes once, like adapting energy). This is needed for storages etc., but may not be needed for other model types.

```
233 # handle current time step
234 if not self.time == time:
235     self.time = time
236
237     # adapt energy content from last time step (+ self-discharge)
238     if self.p >= 0: # charging
239         self.e_bat_step_volume = (
240             self.p * self.charge_efficiency * (self.step_size / 3600)
241         )
242     else: # discharging
243         self.e_bat_step_volume = (
244             self.p / self.discharge_efficiency * (self.step_size / 3600)
245         )
246     self.e_bat += self.e_bat_step_volume
247
248     # Calculate battery cycles
249     self.bat_cycles += abs(self.e_bat_step_volume / self.e_cycle)
250
251     # Calculate battery state of health and aging properties
252     if self.status_aging:
253         self.__calculate_aging_status()
```

Listing 15: Call model-specific methods in supposed order

```

259 # Set active power and energy within limits
260 self.__set_power_within_limit()
261 self.__set_energy_within_limit()
262 self.soc = self.e_bat / self.e_bat_usable
263
264 self.__calc_charging_efficiency()
265
266 self.__calc_power_limits()

```

Checklist for adding / enhancing a model

What changes?

adapting current implementation?

Try to make use of the existing properties and methods of the model

adding new implementation (e.g. new method) or need for new properties?

1. Add the part of code to the model
2. Write proper comments and documentation (docstrings for every method!)
3. Write a corresponding test function!

New packages have been added?

add them to the requirements.txt file

Where to add?

New model attributes need to be ...

1. ... added to the META of the simulator.
2. If they are also input data, add them to the model_data of the test scenarios (examples/data/model_data_scenario) as well as the VALID_PARAMETERS of the model.

New connections between properties of different models ...

- ... need to be integrated to the model_connections/model_connect_config.json file, simply paste them in the direction of the connection.
- ... in case of connections in both direction, the setup of strong (first sent value) and weak (at beginning only done with default value) connection has to be set in model_connections/connect_directions_config.json file. Always use lower-case letters for the model names!

New models need to be integrated ...

1. ... into the test scenario scripts (in the SIM_CONFIG).
2. ... into the model_data of the test scenarios (examples/data/model_data_scenario).
3. ... into the model_connections/model_connect_config.json file with their connections to/from other models. If the direction of the connection is of importance, there may be a need to adapt the simulation_helper functions connect_entities() and connect_entities_of_two_model_types().
4. ... into the simulator META data.

-
5. ... with a unit test file that checks all the relevant model functionalities.

Configuration of a Simulator

The simulator of a model, as explained in the [glossary](#), works as out interface to communicate between the orchestrator of the simulation and the model entities. This means, that the simulator for the PV system model sends input values to the pv systems, initiates the model calculations and collects output values to return to the orchestrator (e.g. for sending the power values to the connected energy management systems). As there may be multiple entities of a model connected to a single simulator, you only need one simulator of a model type for a simulation, as this simulator makes the communication for all entities of its model type. Hence, a `_simulator.py` is always paired with a `_model.py`.

This page explains the structure of a `_simulator.py` to enable you to create a simulator for your own model.

Note: All code-blocks derive from `charging_station_simulator.py` as of (01/24) if not stated otherwise.

Import mosaik and model

Listing 16: Import of the mosaik simulator base class `mosaik_api_v3` and the corresponding model + additional imports

```

1 import mosaik_api_v3
2 from eelib.core.devices.charging_station import charging_station_model
3 import eelib.utils.validation as vld
4 from copy import deepcopy

```

Listing of model META

Listing 17: State of simulator (whether it is time-discrete or event-based/hybrid), see the [glossary](#)

```

17 META = {
18     "type": "hybrid",

```

Listing 18: Listing of **ALL** attributes for each modeltype: At first, all attributes of the model class...

```

19 "models": {
20     "ChargingStation": {
21         "public": True,
22         "params": ["init_vals"],
23         "attrs": [
24             "p",
25             "step_size",
26             "time",
27             ...

```

Listing 19: ... **input attributes** also listed in "trigger" list ...

```
46 "trigger": [
47     "p_set",
48     "ev_data",
49 ], # input attributes
```

Listing 20: ... **output attributes** also listed in ""non-persistent" list.

```
56 "non-persistent": [
57     "p",
58     "p_min",
59     "p_max",
60     "cs_data",
61 ], # output attributes
```

Initialization of simulator class

Listing 21: Constructor `__init__` for this simulator and the initialization function `init()`

```
72 class Sim(mosaik_api_v3.Simulator):
73     """Simulator class for eELib charging station model."""
74
75     def __init__(self):
76         """Constructs an object of the Charging-Station:Sim class."""
77
78         super(Sim, self).__init__(META)
79
80         ...
81
82     def init(self, sid, scenario_config, time_resolution=1.0):
83         """Initializes parameters for an object of the Charging-Station:Sim class."""
84
85         ...
```

Following are the so called **core functions** `create()`, `step()` and `get_data()` that are found in every `_simulator.py`.

Caution: All **core functions** of the simulators are called by mosaik and need to be existent!

Creation of model entities in `create()`

Listing 22: Creation of model entities by assigning ID and name, creating it by its model type, and storing the entity data

```

111 def create(self, num, model_type, init_vals):
112     """Creates entities of the eELib charging station model."""
113
114     # generated next unused ID for entity
115     next_eid = len(self.entities)
116
117     # create empty list for created entities
118     entities_orchestrator = []
119
120     for i in range(next_eid, next_eid + num):
121         # create entity by specified name and ID
122         ename = "%s%s%d" % (model_type, "_", i)
123         full_id = self.sid + "." + ename
124
125         # get class of specific model and create entity with init values after ↴validation
126         entity_cls = getattr(charging_station_model, model_type)
127         vld.validate_init_parameters(entity_cls, init_vals[i])
128         entity = entity_cls(
129             ename,
130             **init_vals[i],
131             step_size=self.scenario_config["step_size"],
132
133         # add info to the simulators entity-list and current entities
134         self.entities[ename] = {
135             "ename": ename,
136             "etype": model_type,
137             "model": entity,
138             "full_id": full_id,
139         }
140         entities_orchestrator.append({"eid": ename, "type": model_type})
141
142     return entities_orchestrator

```

Stepping of models in `step()`

Within the `step()` method, inputs coming from mosaik are set into the model entity attributes they are intended for. Afterwards, the entities are called and their calculation is executed with the models' `step()` method.

This example is coming from the `storage_simulator.py` (01/24).

Listing 23: Take input data and set values of entities, then call the model calculation

```

175 # assign property values for each entity and attribute with entity ID
176 # process input signals: for the entities (eid), attr is a dict for attributes to be set

```

(continues on next page)

(continued from previous page)

```

177 for eid, attrs in inputs.items():
178     # for the attributes, setter is a dict for entities with corresponding set values
179     for attr, setter in attrs.items():
180         # set values corresponding to its type
181         ...
182
183 # call step function for each entity in the list
184 for ename, entity_dict in self.entities.items():
185     entity_dict["model"].step(time)

```

Note: You might return the next timestep for when this model should be called again. This is needed for time-based models (e.g. when reading data from a csv file, the next value should be read and send out) and optional for event-based models (e.g. the adaption of energy levels for a storage model is needed, but a heatpump could maybe just be triggered by a new set value).

Handling of output data in get_data()

Listing 24: From a defined set of output properties given by the outputs parameter from mosaik, the values of the transmitting entities are read and stored into a data dict that is returned

```

233 for transmitter_ename, attrs in outputs.items():
234     # get name for current entity and create dict field
235     entry = self.entities[transmitter_ename]
236     if transmitter_ename not in self.output_cache:
237         self.output_cache[transmitter_ename] = {}
238
239     # loop over all targeted attributes and check if info is available
240     for attr in attrs:
241         if attr not in self.meta["models"][type(entry["model"]).__name__]["attrs"]:
242             raise ValueError("Unknown output attribute: %s" % attr)
243
244         # create empty field for cache and output data
245         if attr not in self.output_cache[transmitter_ename]:
246             self.output_cache[transmitter_ename][attr] = {}
247
248         output_data_to_save = getattr(entry["model"], attr)
249
250         # check if this value changed
251         ...
252
253     # check if nothing is to be send out - send output 1 step later to avoid waiting for
254     # data
255     if not flag_output_changed:
256         if self.time == self.scenario_config["n_steps"] - 1: # is last time step?
257             data["time"] = self.time + 1
258         else:

```

(continues on next page)

(continued from previous page)

```

258     data = {"time": self.time}
259
260     return data

```

For each time step, the output data is continuously stored and compared to the lastly sent data (`output_cache`) such that if nothing new is to be send out, only the time step will be send. In case of the last time step, we need to adjust the signal by transmitting not the current but the next time step to avoid a loop of endless calling between the simulators.

Implementing an EMS strategy

Energy Management Strategies are handled by Energy Management Systems (EMS). To implement a new strategy, additions in multiple places are necessary.

1. Adapt the `EMS_model.py` file and implement the operating strategy

Create a new class that is inheriting from the general `HEMS` class. Don't forget to add the strategy in the `valid` parameter of the HEMS ABC class.

Listing 25: eelib/core/control/EMS/EMS_model.py (01/24)

```

290 class HEMS_default(HEMS):
291     """Default strategy for Energy Management System.
292     Should be copied and adapted for the use of a specific EMS concept.
293     """
294
295     @classmethod
296     def get_valid_parameters(cls):
297         """Returns dictionary containing valid parameter types and values.
298
299         Returns:
300             dict: valid parameters for this model
301         """
302
303         # use parent's parameter list and modify them for this class
304         result = HEMS.get_valid_parameters().copy()
305         result.update({})
306         return result
307
308     def __init__(self, ename: str, step_size: int = 900, **kwargs):
309         """Initializes the eELib HEMS default model.
310
311         Args:
312             ename (str): name of the entity to create
313             step_size (int): length of a simulation step in seconds
314             **kwargs: initial values for the HEMS entity
315
316         Raises:
317             ValueError: Error if selected strategy does not comply with model type.
318         """
319

```

(continues on next page)

(continued from previous page)

```

320     # check given strategy
321     if "strategy" in kwargs.keys() and kwargs["strategy"] != "HEMS_default":
322         raise ValueError("Created a HEMS_default entity with strategy not 'HEMS_"
323                         "default'!")
324     else:
325         kwargs["strategy"] = "HEMS_default" # set strategy if not already given
326
327     # call init function of super HEMS class
328     super().__init__(ename=ename, step_size=step_size, **kwargs)

```

Add a `step()` function that first calls the HEMS `step()` and afterwards implement the functionalities of your operating strategy

Listing 26: eelib/core/control/EMS/EMS_model.py (01/24)

```

329 def step(self, time):
330     """Calculates power set values for each connected component according to the_
331     ↪strategy.
332
333     Args:
334         time (int): Current simulation time
335
336     # execute general processes (aggregation of power values etc.)
337     super().step(time)
338
339     # from here on: execute strategy-specific processes
340     ...

```

2. Add the strategy and its input to the model_data of the scenarios

Listing 27: examples/data/model_data_scenario/model_data_building.json (01/24)

```

1 {
2     "ems": [
3         {
4             "strategy": "HEMS_default",
5             "cs_strategy": "balanced"
6         }
7     ],
8     ...

```

3. Add your EMS class to the `model_connections/model_connect_config.json` file

Add the data that is **sent out**...

Listing 28: eelib/model_connections/model_connect_config.json
(01/24)

```

10 "HEMS_default": {
11     "PVLib": [["p_set_pv", "p_set"]],
12     "BSS": [
13         [
14             "p_set_storage",
15             "p_set"
16         ]
17     ],
18     "ChargingStation": [
19         [
20             "p_set_charging_station",
21             "p_set"
22         ]
23     ],
24     "Heatpump": [
25         [
26             "p_th_set_heatpump",
27             "p_th_set"
28         ]
29     ],
30     "grid_load": [[["p_balance", "p_w"], ["q_balance", "q_var"]]]
31 },

```

... but also to every model, which **data is sent to your HEMS!**

Listing 29: e.g. but not only the BSS

```

111 "BSS": {
112     "HEMS_default": [
113         [
114             "p_discharge_max",
115             "p_min"
116         ],
117         [
118             "p_charge_max",
119             "p_max"
120         ],
121         [
122             "p",
123             "p"
124         ]
125     ],
126     ...
127 },

```

1. Add the model with its name and (input/output) attributes to the META of the EMS_simulator

Listing 30: eelib/core/control/EMS/EMS_simulator.py (01/24)


```

14 META = {
15     "type": "hybrid",
16     "models": {
50         "HEMS_default": {
51             "public": True,
52             "params": ["init_vals"],
53             "attrs": [
54                 "q",
55                 "p",
56                 "p_max",
57                 "p_min",
58                 "p_set_storage",
59                 "p_set_charging_station",
60                 "p_set_pv",
61                 "p_balance",
62                 "q_balance",
63                 "bss_data",
64                 "pv_data",
65                 "cs_data",
66                 "p_th",
67             ],
}

```

Forecasts and Schedules

Implemented into the eELib is a possibility to calculate a *forecast* and *schedule* for devices, EMSs, and the grid. For this, a forecast model is given to calculate requested forecasts. Additionally, the calculation of schedules can be implemented in each (control) model.



Integration into scenario

Forecasts and schedules can be integrated into simulations like the `examples/test_scenario_***.py` files exemplarily show. In there, one has to declare the forecast simulator to mosaik via the `SIM_CONFIG`. Additionally, one has to set the parameter `USE_FORECAST` in the scenario configuration to true.

Listing 31: simulator configuration [test_scenario_building.py 01/24]

```

43 # Sim config.: Simulators and their used model types with the properties to store into DB
44 SIM_CONFIG = {
45     # used database, will be left out for model creation and connections
46     "DBSim": {"python": "eelib.data.database.hdf5:Hdf5Database"}, 
47     # forecast, will be left out for model creation and connections
48     "ForecastSim": {
49         "python": "eelib.core.control.forecast_simulator:Sim",
50         "models": {"Forecast": []},
51     },

```

Listing 32: scenario configuration [test_scenario_building.py 01/24]

```

93 # Configuration of scenario: time and granularity
94 START = "2020-01-01 00:00:00"
95 END = "2020-01-04 00:00:00"
96 STEP_SIZE_IN_SECONDS = 900 # 1=sec-steps, 3600=hour-steps, 900=15min-steps, 600=10min-
97 →steps
USE_FORECAST = True

```

After this, the forecast simulator and model will be created and the connections to the models will be instantiated.

Forecast Model

The forecast model and its simulator are implemented in the folder `eelib/core/control/forecast`. The implemented behaviour is quite simple and straight-forward, as all model entities of the simulation are stored within the forecast entity (as deep-copies) via the `add_forecasted_entity()` method. This allows to create forecasts by simply iterating over all requested forecasts for all entities, stepping the model for the requested timesteps and collecting the values (of the model entity) for the requested time steps. After that, the forecast model simply returns those calculated forecasts.

Listing 33: forecast calculation [forecast_model.py 01/24]

```

64 # check if request for a forecast was sent
65 if self.forecast_request == {}:
66     self.forecast = {} # no forecast requested, simply return
67 else:
68     # clear earlier forecasts
69     self.forecast = {}
70
71 # go by all entities to create a forecast for
72 for forecast_getter_id, forecast_req_eid_dict in self.forecast_request.items():
73     # create empty dict for forecasts connected to this request entity
74     self.forecast[forecast_getter_id] = {}
75     # check if no forecast requested

```

(continues on next page)

(continued from previous page)

```

76     if forecast_req_eid_dict == {}:
77         continue
78
79     # go by all forecasted model entities
80     for forecast_eid, forecast_info in forecast_req_eid_dict.items():
81         # check if forecast can be done for this model type
82         if forecast_eid in self.forecast_eid.keys():
83             # create structure for forecast of each attribute for this entity
84             forecast_save = {}
85             for attr in forecast_info["attr"]:
86                 forecast_save[attr] = []
87
88             # store the copy of this model entity to execute the stepping
89             entity = self.forecast_eid[forecast_eid]
90
91             # run the model for each time step and collect the calculated attr values
92             for t in forecast_info["t"]:
93                 entity.step(t)
94                 for attr in forecast_info["attr"]:
95                     forecast_save[attr].append(getattr(entity, attr))

```

Integration into (Control) Models

For the forecast model to take effect, the forecasts have to be requested by other models, e.g. the energy management system. Additionally, the calculated forecasts should afterwards be used for strategic behaviour (in operating strategies).

First of all, the mosaik needs to create a connection between the model and the forecast model. This is done in the `connect_to_forecast()` function of the simulation helpers. Here, there is a connection added from EMS to the forecast model for the `forecast_request` attribute, while a `forecast` attribute is send back the other way around. All other models are simply added to the forecast entity such that forecasts can be calculated.

Listing 34: forecast connection function [simulation_helper.py 01/24]

```

470 def connect_to_forecast(
471     world: object,
472     dict_entities: dict,
473     dict_simulators: dict,
474     forecast: object,
475     forecast_sim: object,
476 ):
477     """Create connections for the forecasts to work.
478     Includes mosaik connections to ems model and adding of the model entities to the
479     forecasts list.
480
481     Args:
482         world (object): mosaik world object to orchestrate the simulation process
483         dict_entities (dict): dict of all used model entity objects
484         dict_simulators (dict): dict of all used simulators with their ModelFactory-objects
485         forecast (object): forecast model entity
486         forecast_sim (object): simulator for the forecast model
487     """

```

(continues on next page)

(continued from previous page)

```

487
488     # create connections for each entity of each model type
489     for model_name, ent_list in dict_entities.items():
490         for entity in ent_list:
491             # for ems create connections to forecast entity
492             if "ems" in model_name or "EMS" in model_name:
493                 world.connect(entity, forecast, "forecast_request")
494                 world.connect(
495                     forecast,
496                     entity,
497                     "forecast",
498                     weak=True,
499                     initial_data={"forecast": {forecast.full_id: {}}}),
500                 )
501             # for other models (devices) add those entities to the forecast entity list
502         else:
503             forecast_sim.add_forecasted_entity(
504                 forecast.eid,
505                 {entity.full_id: dict_simulators[model_name].get_entity_by_id(entity.eid)})
506             ↵,
507         )

```

Additionally, forecasts have to be requested by the ems, which should be done only in the corresponding time steps.

Listing 35: forecast request by EMS [EMS_model.py 01/24]

```

340     # request forecasts if needed
341     if self.use_forecast and self.calc_forecast:
342         self.forecast_request = {}
343         for model_type, entity_list in self.controlled_eid_by_type.items():
344             if model_type in self.forecastedAttrs.keys():
345                 # add forecast request for every entity of this model type
346                 for e_full_id in entity_list.keys():
347                     self.forecast_request[e_full_id] = {
348                         "attr": self.forecastedAttrs[model_type],
349                         "t": range(self.forecast_start, self.forecast_end),
350                     }

```

Due to the connection by mosaik, the forecasts are calculated and afterwards send back, such that they should be processed. It is now also possible to calculate schedules with set values for the devices that no forecast can be directly extracted from (charging station, heatpump, battery).

Listing 36: handling of forecasts and calculation of schedules in EMS
[EMS_model.py 01/24]

```

352     # CALC SCHEDULE WITH UNCONTROLLED (CSV) DEVICES
353     if self.forecast != {} and self.calc_forecast is True:
354         # calculate the residual load schedule including all not controllable devices
355         schedule_residual_uncontrollable = schedule_help.residual_calc_schedule_
356             ↵uncontrollable(...)
357             # calc schedules for charging station

```

(continues on next page)

(continued from previous page)

```

358 schedule_help.cs_calc_schedule_uncontrolled(...)
359
360 # calc schedules for heatpump
361 th_residual_forecast = schedule_help.thermal_calc_forecast_residual(...)
362 schedule_help.hp_calc_schedule(...)
363
364 # get schedule from battery storage based on residual load schedule
365 schedule_help.bss_calc_schedule(...)

```

FAQ & Glossary

Glossary

Model

Representation of real processes (assuming simplifications), using the general procedure of “*Input - internal calculation - output*”.

Orchestrator

Coordination of the whole simulation procedure and coupling of the models (**mosaik**).

Simulator

API/interface for communication between the orchestrator mosaik and the entities of the specific model.

Entity

Created instance of a model type. In “ename”, “etype”, “eid” etc. the “e” stands for entity.

PSC

We use the **passive sign convention** (german: **Verbraucherzaehlpfeilsystem**), therefore loads are positive while generation is negative.

Forecast

Prediction of a behaviour for a defined time horizon in the future, e.g. power values for the upcoming 24h steps for a household base load from a csv reader.

Schedule

Calculated set values for a defined time horizon in the future, e.g. target power values for the upcoming 24h steps for a battery storage system.

time-based

Used for time-discrete simulation of models, e.g. if just some data is collected to be transmitted to other models.

event-based/hybrid

Used for triggered simulation of models, e.g. if model calculation can be triggered by inputs like the receiving of a power set value.

Parameters used in test scenarios

START

simulation starting time (e.g. 2023-01-01 00:00:00)

END

simulation ending time (e.g. 2023-01-02 00:00:00 for a full day calculation)

N_STEPS

number of steps that should be simulated, calculated from start and end time (e.g. 96 steps for a day with 15 min time steps)

STEP_SIZE_IN_SECONDS

length of one (pre-defined) time step in seconds (e.g. 15 min steps: 15*60 sec = 900 sec)

USE_FORECAST

True-False value whether to consider forecasts in the simulation or not

FAQ

What is the process of building Model-Factories?

```
examplesim = world.start("ExampleSim", eidprefix="Model")
```

The resulting `examplesim` is an entity of the class `mosaik.scenario.ModelFactory`. It can create and store the entities of an example model.

What can one do in case of an ImportError when running the example scenarios?

```
pip install -e .
```

What attributes does a model have?

For that you should have a look at the META of the simulator or optionally within the model class itself.

Listing 37: e.g. EMS_simulator.py (01/24)

```
13 # SIMULATION META DATA
14 META = {
15     "type": "hybrid",
16     "models": {
17         "HEMS": {
18             "public": True,
19             "params": ["init_vals"],
20             "attrs": [
21                 "q",
22                 "p",
23                 "p_max",
24                 "p_min",
25             ...
26         }
27     }
28 }
```

What inputs does a model have?

Have a look at the `VALID_PARAMETERS` stored in each model class:

Listing 38: e.g. EMS_model.py (01/24)

```
20 # Valid values and types for each parameter that apply for all subclasses
21 _VALID_PARAMETERS = {
22     "cs_strategy": {
```

(continues on next page)

(continued from previous page)

```

23     "types": [str],
24     "values": ["max_p", "balanced", "night_charging", "solar_charging"],
25   },
26   "bss_strategy": {
27     "types": [None, str],
28     "values": [None, "reduce_curtailment"],
29   },
30 }
```

Exemplarily the `model_data` of the test scenarios set (at least some of) these parameters and their initial values for the models:

Listing 39: e.g. `model_data_building.json` (01/24)

```

1  {
2    "ems": [
3      {
4        "cs_strategy": "balanced"
5      }
6    ],
7 }
```

What connections does a model have?

For that the eELib provides the `model_connections/model_connect_config.json` file, where all of the FROM-TO-CONNECTIONS are given for each model type implemented in the eELib:

Listing 40: e.g. `model_connect_config.json` (01/24)

```

10  "HEMS_default": {
11    "PVLib": [["p_set_pv", "p_set"]],
12    "BSS": [
13      [
14        "p_set_storage",
15        "p_set"
16      ]
17    ],
18    "ChargingStation": [
19      [
20        "p_set_charging_station",
21        "p_set"
22      ]
23    ],
24    "Heatpump": [
25      [
26        "p_th_set_heatpump",
27        "p_th_set"
28      ]
29    ],
30    "grid_load": [[["p_balance", "p_w"], ["q_balance", "q_var"]]]
31 }
```

Listing 41: e.g. model_connect_config.json (01/24)

```

111 "BSS": {
112   "HEMS_default": [
113     [
114       "p_discharge_max",
115       "p_min"
116     ],
117     [
118       "p_charge_max",
119       "p_max"
120     ],
121     [
122       "p",
123       "p"
124     ],
125   ],
126 }

```

Extracted from these two examples above can be the sending of values for attributes p, p_min and p_max from BSS to HEMS and the return of a value for p_set.

Units

Make use of the SI-units!!

- **Power:** W
- **Time (e.g. simulation time):** s
- **Energy:** Wh
- ...

2.1.3 API Reference

The API reference provides detailed descriptions of eElab's classes and methods. This is taken from the implementations of the models, which can be taken from the *public Gitlab-Repository <<https://gitlab.com/elenia1/elenia-energy-library>>*.

eelib

This stores the main part of the elenia Energy Library, as it contains the models and all other functionalities.

Subpackages

`eelib.core`

Here, all of the models are stored. This is divided into the devices (like PV system or electric vehicle), control models (like energy management system), grid models (like grid control) and market models (like electricity providers).

Subpackages

`eelib.core.control`

Subpackages

`eelib.core.control.EMS`

Submodules

`eelib.core.control.EMS.EMS_bss_helper`

Helper functions for handling of battery storage systems in EMS.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Functions

<code>bss_calc_balance</code> (→ float)	Calculates the set power values of storage based on given p_balance.
<code>bss_strategy_reduce_curtailment</code> (p_balance, p_max, p_min)	This strategy reduces curtailment of the solar power system
<code>bss_set_energy_within_limit</code> (→ float)	Check that battery energy limits are not surpassed.
<code>bss_calc_e_bat</code> (→ float)	Calculates the energy level of the forecasted battery storage system.
<code>bss_calc_p_limits</code> (→ tuple[float, float])	Calculates the bss active power limits for the forecast using input "bss_e_bat_usable".

`bss_calc_balance(p_balance: float, p_max: float, p_min: float) → float`

Calculates the set power values of storage based on given p_balance. Resulting in charging and discharging values.

Parameters

- **p_balance** (*float*) – Input p_balance which storage tries to level

- **p_min** (*float*) – Discharge rate of storage
- **p_max** (*float*) – Charge rate of storage

Returns

calculated power set value of bss to level p_balance

Return type

float

Note: This function was created based on the function `__set_power_within_limit()` in `storage_model`.

bss_strategy_reduce_curtailment(*p_balance*: float, *p_max*: float, *p_min*: float, *bss_charging_limit*: float = 0.6)

This strategy reduces curtailment of the solar power system by reducing the bss' charging power. This decreases self-sufficiency but also the curtailment due to EEG2021 (e.g. feed-in is only allowed at max. 70% of installed power for uncontrolled solar power systems). This operation strategy should not be used in combination with electric vehicle charging. Suitable limits are 30%-60%.

Parameters

- **p_balance** (*float*) – input balance which bss needs to level
- **p_max** (*float*) – maximum charging power of bss
- **p_min** (*float*) – maximum discharging power of bss
- **bss_charging_limit** (*float*) – Charging limit of batter storage. Defaults to 0.6.

Returns

reduced charging power for battery storage

Return type

int

bss_set_energy_within_limit(*bss_data*: eelib.data.BSSData) → float

Check that battery energy limits are not surpassed. Similiar to function in `storage_model.py`.

Parameters

bss_data (BSSData) – extract from bss dataclass

Returns

energy level of the bss after scheduling step

Return type

float

Note: This function was created based on the function `__set_energy_within_limit()` in `storage_model`.

bss_calc_e_bat(*step_size*: int, *bss_data*: eelib.data.BSSData) → float

Calculates the energy level of the forecasted battery storage system.

Parameters

- **step_size** (*int*) – simulation step_size
- **bss_data** (BSSData) – extract of dataclass for currently scheduled bss

Returns

energy level of forecasted bss

Return type
float

Note: This function was created based on the function `step()` in `storage_model`.

bss_calc_p_limits(*step_size*: int, *bss_data*: *eelib.data.BSSData*) → tuple[float, float]

Calculates the bss active power limits for the forecast using input “`bss_e_bat_usable`”.

Parameters

- **step_size** (int) – simulation step_size
- **bss_data** (*BSSData*) – extract of dataclass for currently scheduled bss

Returns

maximum charging power of bss float: minimum charging (resp. max. discharging) power of bss

Return type
float

Note: This function was created based on the function `__calc_power_limits()` in `storage_model`.

eelib.core.control.EMS.EMS_car_helper

Helper functions for handling of cars in EMS.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Functions

<code>car_calc_e_bat</code> (→ float)	Calculates the energy amount of electric car after power influence (from last step).
<code>car_set_energy_within_limit</code> (→ float)	Check that battery energy limits are not surpassed.
<code>car_calc_power_limits</code> (→ tuple[float, float])	Calculate the maximum (dis)charging power for the car battery.
<code>car_calc_power</code> (→ float)	Calculate the power at the current time step within the (dis)charging limits.

car_calc_e_bat(*step_size*: int, *ev_data*: *eelib.data.EVData*) → float

Calculates the energy amount of electric car after power influence (from last step).

Parameters

- **step_size** (int) – simulation step_size

- **ev_data** ([EVData](#)) – contains all information of electric vehicles

Returns

new energy level of electric vehicle (for next step)

Return type

float

NOTE: This function was created based on the function step() in car_model

car_set_energy_within_limit(*ev_data*: [eelib.data.EVData](#)) → float

Check that battery energy limits are not surpassed.

Parameters

- **ev_data** ([EVData](#)) – contains all information of electric vehicles

Returns

updated energy level of electric vehicle

Return type

float

NOTE: This function was created based on the function set_energy_within_limit() in car_model.

car_calc_power_limits(*step_size*: int, *ev_data*: [eelib.data.EVData](#)) → tuple[float, float]

Calculate the maximum (dis)charging power for the car battery. depending on the power limits and the current stored energy.

Parameters

- **step_size** (int) – simulation step_size
- **ev_data** ([EVData](#)) – contains all information of electric vehicles

Returns

minimum charging (resp. max. discharging) power of EV float: maximum (charging) power of EV

Return type

float

NOTE: This function was created based on the function _calc_power_limits() in car_model.

car_calc_power(*step_size*: int, *consumption_step*: float, *p_set*: float, *ev_data*: [eelib.data.EVData](#)) → float

Calculate the power at the current time step within the (dis)charging limits.

Parameters

- **step_size** (int) – simulation step_size
- **consumption_step** (float) – consumption at the current time step
- **p_set** (float) – set value for charging power of car
- **ev_data** ([EVData](#)) – contains all information of electric vehicles

Returns

electric power of the vehicle

Return type

float

Note: This function was created based on the function `__calc_power()` in `car_model`.

eelib.core.control.EMS.EMS_cs_helper

Helper functions for handling of charging stations in EMS.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Functions

<code>cs_strategy_balanced_charging()</code>	The forecast-based charging strategy estimates the total standing time of the connected
<code>cs_strategy_night_charging()</code>	The night charging strategy extends the charging process similar to forecast-based
<code>cs_strategy_solar_charging()</code>	The solar charging strategy is initiated within times of solar energy surplus. The
<code>cs_distribute_charging_power(→ dict)</code>	Distributes the charging power across all connected cars.
<code>cs_calc_power_limits(→ tuple[float, float])</code>	Calculate the power limits for the charging station with the input that's coming from the
<code>cs_calc_current_efficiency(→ float)</code>	Calculates the charging efficiency for charging station from static properties.

`cs_strategy_balanced_charging()`

The forecast-based charging strategy estimates the total standing time of the connected EV at home and then calculates the minimal charging power needed to fully charge the EV up to the moment of the next departure.

`cs_strategy_night_charging()`

The night charging strategy extends the charging process similar to forecast-based charging. The strategy is solely activated and processed overnight between 20:00 and 05:00 when grid load is typically lower in residential areas. When the EV is not available overnight, maximum power charging is instead activated.

`cs_strategy_solar_charging()`

The solar charging strategy is initiated within times of solar energy surplus. The cs model receives the information of such a surplus from its control model (e.g. EMS).

`cs_distribute_charging_power(forecast: dict, t: int, cs_data: eelib.data.CSDData) → dict`

Distributes the charging power across all connected cars. For this, the distribution is done evenly unless the power limits of the cars are exceeded.

Parameters

- **forecast** (`dict`) – collected forecast from EMS
- **t** (`int`) – control variable in range of current forecast

- **cs_data** ([CSDData](#)) – contains all information of charging station

Raises

- **ValueError** – If Vehicles charging power does not match the power of the charging station
- **ValueError** – If set charging power does not fit the power limits of the connected evs
- **ValueError** – If charging station has power value although no car is connected
- **ValueError** – If sum of vehicle power does not match power

Returns

individual charging power for all connected cars

Return type

dict

Note: This function was created based on the function `_distribute_charging_power()` in `charging_station_model`.

cs_calc_power_limits(*forecast: dict, t: int, cs_data: eelib.data.CSDData*) → tuple[float, float]

Calculate the power limits for the charging station with the input that's coming from the electric vehicles.

Parameters

- **forecast** (*dict*) – collected forecast from EMS
- **t** (*int*) – control variable in range of current forecast
- **cs_data** ([CSDData](#)) – contains all information of charging stations

Raises

ValueError – If the power limits of at least one connected ev do not work together.

Returns

maximum charging power of charging station float: maximum discharging (resp. minimum charging) power of charging station

Return type

float

Note: This function was created based on the function `_calc_power_limits()` in `charging_station_model`.

cs_calc_current_efficiency(*cs_data: eelib.data.CSDData*) → float

Calculates the charging efficiency for charging station from static properties. Based on the active power.

Parameters

cs_data ([CSDData](#)) – contains all information of charging station

Returns

efficiency for dis/charging process of cs

Return type

float

Note: This function was created based on the function `_calc_current_efficiency()` in `charging_station_model`.

eelib.core.control.EMS.EMS_hp_helper

Helper functions for handling of heatpumps in EMS.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Functions

<code>hp_set_power_with_limits(→ float)</code>	Set the thermal power of a heatpump with regard to its three limits (max, min, min_on).
<code>set_hp_time(→ int)</code>	Update on-/off-time of heatpump with regard to its current power output.
<code>calc_hp_power_limits(hp_p_rated, hp_p_min_th_rel, hp_state)</code>	Set thermal power limits of heatpump with regard to state.
<code>set_hp_state(→ str)</code>	Update state of heatpump with regard to its on- or off-time and minimum state time.

hp_set_power_with_limits(*hp_p_th_max: float*, *hp_p_th_min_on: float*, *hp_p_th_min: float*, *hp_p_th_target: float*) → float

Set the thermal power of a heatpump with regard to its three limits (max, min, min_on).

Parameters

- **hp_p_th_max** (*float*) – maximum thermal power
- **hp_p_th_min_on** (*float*) – minimum thermal power in on-state
- **hp_p_th_min** (*float*) – minimum thermal power overall
- **hp_p_th_target** (*float*) – desired power value

Returns

thermal power set value according to power limits

Return type

float

Note: This function was created based on the function `step()` in `heatpump_model`.

set_hp_time(*step_size: int*, *p_th_set: float*, *hp_time_on: int*, *hp_time_off: int*) → int

Update on-/off-time of heatpump with regard to its current power output.

Parameters

- **step_size** (*int*) – current simulation step size
- **p_th_set** (*float*) – current thermal power output
- **hp_time_on** (*int*) – current time in on-state [s]

- **hp_time_off** (*int*) – current time in off-state [s]

Returns

- (1) updated time in on-state [s]
- (2) updated time in off-state [s]

Return type

int, int

Note: This function was created based on the function `step()` in `heatpump_model`.

calc_hp_power_limits(*hp_p_rated: float, hp_p_min_th_rel: float, hp_state: str*)

Set thermal power limits of heatpump with regard to state.

Parameters

- **hp_p_rated** (*float*) – rated thermal power of heatpump
- **hp_p_min_th_rel** (*float*) – relative minimum thermal power in on-state (regarding rated)
- **hp_state** (*str*) – current state of the heatpump

Returns

- (1) maximum thermal power
- (2) minimum thermal power in on-state
- (3) minimum thermal power

Return type

float, float, float

Note: This function was created based on the function `__calc_thermal_limits()` in `heatpump_model`.

set_hp_state(*p_th_set: float, hp_time_on: int, hp_time_off: int, hp_time_min: int*) → str

Update state of heatpump with regard to its on- or off-time and minimum state time.

Parameters

- **p_th_set** (*float*) – current thermal power output
- **hp_time_on** (*int*) – current time in on-state [s]
- **hp_time_off** (*int*) – current time in off-state [s]
- **hp_time_min** (*int*) – minimum time for one state [s]

Returns

updated state of the heatpump

Return type

str

Note: This function was created based on the function `step()` in `heatpump_model`.

eelib.core.control.EMS.EMS_model

The eElab EMS model was developed as an energy management system on the building level and is therefore connected to all of the building's components. The control gathers all of the component's power flows, calculates the energy balance at the building node and the component's flexibility, and then sends out power set values in each step. Hereby, available solar power is favored to grid consumption, as well as charging / discharging limits of the charging stations, and batteries are considered.

Regarding charging stations, different charging strategies are implemented: Default / Maximum power charging, balanced charging, solar charging and night charging.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<code>HEMS</code>	Models an home energy managament system on building level.
<code>HEMS_default</code>	Default strategy for Energy Management System.
<code>GCP_Aggregator_HEMS</code>	Aggregation of power flows for depiction of uncontrolled devices in a building.
<code>HEMS_forecast_base</code>	Baseclass for EMS strategies using forecasts (and optimizations).
<code>HEMS_forecast_default</code>	Default forecast strategy for Energy Management System.
<code>HEMS_forecast_opt</code>	Optimization-based forecast/schedule strategy for Energy Management System.

class HEMS(*ename*: str, *step_size*: int, *cs_strategy*: str = 'max_p', *bss_strategy*: str = 'surplus')

Bases: abc.ABC

Models an home energy managament system on building level.

VALID_PARAMETERS

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

add_controlled_entity(*entities_dict*: dict)

Adds a controlled entity to the corresponding EMS's lists (controlled components and type-specific).

Parameters

entities_dict (dict) – Input list with all models of a type (e.g. charging_station) which will be connected to the controller.

_get_component_by_type(type: str)
Gets all controlled components of passed type.

Parameters
type (str) – Query to determine all controlled components of this type.

Returns
Returns all entities of queried type.

Return type
dict

abstract step(time: int)
Handles stepping of energy management systems by checking power values.

Parameters
time (int) – Current simulation time

_calc_power_energy(time: int)
Gathers current power flows, aggregates limits, and calculates energy balances.

Parameters
time (int) – Current simulation time

_set_pv_max()
Calculate pv system setpoints for all devices by using the maximum power.

_set_cs_p()
Calculate charging station setpoints using the chosen charging strategy.

_set_hp_p_th()
Calculate heatpump thermal power setpoints by reducing needed power at this step.

_set_bss_p()
Calculate battery storage system setpoints for all devices using the chosen strategy.

_reset_financial_values()
Reset all financial values (at the beginning of a new timestep).

_handle_incoming_signals()
Retrieve tariff settings for this timestep from an incoming tariff signal.

_calc_financial_output()
Calculate financial values like cost, profit and revenue for this timestep.

class HEMS_default(ename: str, step_size: int = 900, **kwargs)
Bases: [HEMS](#)

Default strategy for Energy Management System. Should be copied and adapted for the use of a specific EMS concept.

classmethod get_valid_parameters()
Returns dictionary containing valid parameter types and values.

Returns
valid parameters for this model

Return type
dict

step(*time*: int)

Calculates power set values for each connected component according to the strategy.

Parameters

time (int) – Current simulation time

class GCP_Aggregator_HEMS(*ename*: str, *step_size*: int = 900, **kwargs)

Bases: [HEMS](#)

Aggregation of power flows for depiction of uncontrolled devices in a building.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(*time*)

Aggregation of power values.

Parameters

time (int) – Current simulation time

class HEMS_forecast_base(*ename*: str, *step_size*: int, *forecast_horizon_hours*: int = 24,

forecast_frequency_hours: int = 24, *forecast_type*: str = 'household_only',
cs_strategy: str = 'max_p', *bss_strategy*: str = 'surplus')

Bases: [HEMS](#)

Baseclass for EMS strategies using forecasts (and optimizations).

forecast_types**classmethod get_valid_parameters()**

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

_request_forecast()

Set models with their attributes and time horizon for forecast request.

_set_schedule_values()

Take schedules of the devices and convert them into set values.

_set_power_in_limits(*power*: float, *p_min*: float, *p_max*: float) → float

Set a power value with regard to a maximum and minimum value, if given.

Parameters

- **power** (float) – current power value to start with
- **p_min** (float) – minimum power limit
- **p_max** (float) – maximum power limit

Returns

power value within the limiting bounds

Return type
float

_set_schedule_values_pv()
Take schedules of pv systems and convert them to set values by using the power limits.

_set_schedule_values_cs()
Take schedules of charging stations and convert to set values by using the limits.

_set_schedule_values_hp()
Take schedules of heatpumps and convert them to set values by using the power limits.

_set_schedule_values_bss()
Take schedules of battery storage systems and convert to set values using the limits.

abstract step(time: int)
Gathers current energy flows and calculates energy balances.

Parameters
time (int) – Current simulation time

class HEMS_forecast_default(ename: str, step_size: int = 900, **kwargs)
Bases: *HEMS_forecast_base*
Default forecast strategy for Energy Management System. Should be copied and adapted for the use of a specific EMS concept.

classmethod get_valid_parameters()
Returns dictionary containing valid parameter types and values.

Returns
valid parameters for this model

Return type
dict

step(time: int)
Calculates power set values for each connected component according to the strategy.

Parameters
time (int) – Current simulation time

class HEMS_forecast_opt(ename: str, step_size: int = 900, **kwargs)
Bases: *HEMS_forecast_base*
Optimization-based forecast/schedule strategy for Energy Management System.

classmethod get_valid_parameters()
Returns dictionary containing valid parameter types and values.

Returns
valid parameters for this model

Return type
dict

step(time: int)
Calculates power set values for each connected component according to the strategy.

Parameters
time (int) – Current simulation time

eelib.core.control.EMS.EMS_simulator

Mosaik interface for the eELib energy management system (EMS) model. Simulator for communication between orchestrator (mosaik) and EMS entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<i>Sim</i>	Simulator class for eELib EMS model.
------------	--------------------------------------

Attributes

<i>META</i>
<i>ADAPTION_TOLERANCE</i>

META

ADAPTION_TOLERANCE

class Sim

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib EMS model.

Parameters

`mosaik_api_v3(module)` – defines communication between mosaik and simulator

Yields

`object` – Initializes a mosaik event to return `set_data`.

init(sid, scenario_config, time_resolution=1.0)

Initializes parameters for an object of the EMS:Sim class.

Parameters

- `sid(str)` – ID of the created entity of the simulator (e.g. EMSSim-0)
- `scenario_config(dict)` – scenario configuration data, like resolution or step size
- `time_resolution(float)` – fitting of the step size to the simulation scenario step size.

Returns

description of the simulator

Return type

meta

create(*num, model_type, init_vals=None*)

Creates entities of the eELib EMS model. Core function of mosaik.

Parameters

- **num** (*int*) – number of models to be created
- **model_type** (*str*) – type of created entity (e.g. “HEMS”)
- **init_vals** (*list*) – list with initial values for each EMS entity, defaults to None

Returns

created entities

Return type

dict

get_entity_by_id(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters**entity_id** (*str*) – id of the entity to be searched for**Returns**

entity model if found, None otherwise

Return type

object

step(*time, inputs, max_advance*)

Performs simulation step calling the eELib EMS model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict*) – allocation of set values to specific models
- **max_advance** (*int, optional*) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Raises**TypeError** – if value_dict containing set values has an unknown format**Returns**

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs*)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters**outputs** (*dict*) – dictionary with data outputs from each control model**Raises****ValueError** – error if attribute not in model metadata**Returns**

dictionary with simulation outputs

Return type

dict

add_controlled_entity(control_entity_eid: str, entity_dict: dict)

Adds entities (e.g. pv systems) to the specific control unit entity.

Parameters

- **control_entity_eid** (str) – entity id of control unit entity
- **entity_dict** (dict) – Dictionary of created models to be added to the control unit entity

eelib.core.control.EMS.schedule_helper

Helper functions for the creation of schedules in EMS.

Pyomo released under 3-clause BSD license

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Functions**

<code>calc_forecast_residual</code> (→ numpy.ndarray)	Calculates the residual forecast for the "p"-values of all devices' forecasts.
<code>calc_forecast_thermal_residual</code> (→ numpy.ndarray)	Calculates the residual forecast for the thermal demand ("p_th"-values).
<code>bss_calc_schedule</code> (→ dict)	Calculates the schedule for the p_set values of the bss.
<code>pv_calc_schedule</code> (→ dict)	Calculates the schedule for all pv systems using the forecast (maximum power).
<code>hp_calc_schedule</code> (→ dict)	Calculates the schedule for the thermal power set values of the heatpump.
<code>cs_calc_schedule_uncontrolled</code> (step_size, forecast, ...)	Calculates the schedule for all connected charging stations and its connected cars.
<code>calc_schedule_opt</code> (tariff, cs_data, bss_data, ...)	Calculates an optimal schedule for all connected devices.

Attributes

`_logger`

`_logger`

calc_forecast_residual(*forecast: dict, forecast_horizon: int*) → numpy.ndarray

Calculates the residual forecast for the “p”-values of all devices’ forecasts.

Parameters

- **forecast** (*dict*) – input forecasts to calculate schedule
- **forecast_horizon** (*int*) – time steps in which forecast is created

Returns

residual electrical power values from forecasts for attribute “p” for devices

Return type

np.ndarray

calc_forecast_thermal_residual(*forecast: dict, forecast_horizon: int*) → numpy.ndarray

Calculates the residual forecast for the thermal demand (“p_th”-values).

Parameters

- **forecast** (*dict*) – input forecasts to calculate schedule
- **forecast_horizon** (*int*) – time steps in which forecast is created

Returns

residual thermal demand values from forecast

Return type

np.ndarray

bss_calc_schedule(*step_size: int, schedule_p_res: list, bss_data: dict*) → dict

Calculates the schedule for the p_set values of the bss.

Parameters

- **step_size** (*int*) – simulation step_size
- **schedule_p_res** (*list*) – Input schedule of residual load.
- **bss_data** (*dict*) – battery information at start of forecast with structure {id: BSSData}

Returns

Schedule with p_set values of the bss in the forecast horizon.

Return type

dict

pv_calc_schedule(*forecast: dict, pv_data: dict*) → dict

Calculates the schedule for all pv systems using the forecast (maximum power).

Parameters

- **forecast** (*dict*) – collected forecast from EMS
- **pv_data** (*dict*) – contains all information of pv systems with structure {id: PVData}

Returns

Schedule with power set values of the pv systems in the forecast horizon.

Return type

dict

hp_calc_schedule(*step_size: int, th_demand_profile: list, energy_demand_th: float, hp_data: dict*) → dict

Calculates the schedule for the thermal power set values of the heatpump.

Parameters

- **step_size** (*int*) – simulation step_size
- **th_demand_profile** (*list*) – input profile of the thermal power demand.
- **energy_demand_th** (*float*) – current thermic energy demand
- **hp_data** (*dict*) – contains all information of heatpumps with structure {id: HPData}

Returns

Schedule with thermal and electrical set values of the hps in the forecast horizon.

Return type

dict

cs_calc_schedule_uncontrolled(*step_size: int, forecast: dict, forecast_horizon: int, cs_data: dict*)

Calculates the schedule for all connected charging stations and its connected cars. Uses the forecast of the appearance and the cars consumption. NOTE: For this schedule the car is always charged with max. power.

Parameters

- **step_size** (*int*) – simulation step size in seconds
- **forecast** (*dict*) – collected forecast from EMS
- **forecast_horizon** (*int*) – length of the forecast period
- **cs_data** (*dict*) – contains all information of charging stations with structure {id: CSData}

Returns

Schedule with power set values of the charging stations in the forecast horizon.

Return type

dict

calc_schedule_opt(*step_size: int, forecast: dict, forecast_horizon: int, opt: eelib.data.OptimOptions = OptimOptions(), tariff: eelib.data.TariffSignal = TariffSignal(), cs_data: dict = {}, bss_data: dict = {}, pv_data: dict = {}, hp_data: dict = {}, control_signals: eelib.data.ControlSignalEMS = ControlSignalEMS()*) → dict

Calculates an optimal schedule for all connected devices.

Parameters

- **step_size** (*int*) – simulation step_size
- **forecast** (*dict*) – collected forecasts from EMS
- **forecast_horizon** (*int*) – timesteps for which forecast should be calculated
- **opt** (*OptimOptions*) – information about optimization setup (whats used and what not)
- **tariff** (*TariffSignal*) – electricity price signal. Defaults to TariffSignal().
- **cs_data** (*dict*) – info of charging stations, like {id: CSData}. Defaults to {}.
- **bss_data** (*dict*) – info of battery storage systems, like {id: BSSData}. Defaults to {}.
- **pv_data** (*dict*) – info of pv systems, like {id: PVData}. Defaults to {}.
- **hp_data** (*dict*) – info of heatpumps, like {id: HPData}. Defaults to {}.
- **control_signals** (*ControlSignalEMS*) – Control signals sent to EMS with lists for power limits.

Raises

ValueError – constructed optimization problem could not be solved by solver

Returns

Schedule with power set values of the connected devices in the forecast horizon.

Return type

dict

eelib.core.control.grid

Submodules

eelib.core.control.grid.grid_ems_model

The eELib grid EMS model is some sort of an implementation for the grid operator, as it is the grid energy management system. The control unit gathers the power flow results of the grid and can send out different kind of control signals, like set values or prices.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

GridEMS

Models a grid energy managament system.

class GridEMS(ename: str, strategy: str, grid_model_config: dict, use_14a_enwg: bool = True, grid_tariff_model: str = 'flat-rate', energy_price_static: float = 0.08, capacity_fee_dem: float = 0.0, capacity_fee_gen: float = 0.0, capacity_fee_horizon_sec: int = 3600 * 24, step_size: int = 900)

Bases: object

Models a grid energy managament system.

_VALID_PARAMETERS

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(time)

Gathers current grid status, handles it and calculates output values.

Parameters

time (int) – Current simulation time

_create_grid_tariff_signal()

Create the grid tariff signal to send to retail electricity providers and households.

Raises

ValueError – In case grid tariff model is not implemented

eelib.core.control.grid.grid_ems_simulator

Mosaik interface for the eELib grid energy management system model. Simulator for communication between orchestrator (mosaik) and grid EMS entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes****Sim**

Simulator class for eELib grid EMS model.

Attributes**META****ADAPTION_TOLERANCE****META****ADAPTION_TOLERANCE****class Sim**

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib grid EMS model.

Parameters

`mosaik_api_v3(module)` – defines communication between mosaik and simulator

Yields

`object` – Initializes a mosaik event to return `set_data`.

init(sid, scenario_config, time_resolution=1.0)

Initializes parameters for an object of the `grid_ems:Sim` class.

Parameters

- **sid** (*str*) – ID of the created entity of the simulator (e.g. GridEMSSim-0)
- **scenario_config** (*dict*) – scenario configuration data, like resolution or step size
- **time_resolution** (*float*) – fitting of the step size to the simulation scenario step size.

Returns

description of the simulator

Return type

meta

create(*num, model_type, init_vals=None*)

Creates entities of the eELib grid EMS model. Core function of mosaik.

Parameters

- **num** (*int*) – number of models to be created
- **model_type** (*str*) – type of created entity (e.g. “grid_ems”)
- **init_vals** (*list*) – list with initial values for each grid EMS entity, defaults to None

Returns

created entities

Return type

dict

get_entity_by_id(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (*str*) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(*time, inputs, max_advance*)

Performs simulation step calling the eELib grid EMS model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict*) – allocation of set values to specific models
- **max_advance** (*int, optional*) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs*)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters

outputs (*dict*) – dictionary with data outputs from each control model

Raises

ValueError – error if attribute not in model metadata

Returns

dictionary with simulation outputs

Return type

dict

add_controlled_entity(control_entity_eid: str, entity_dict: dict)

Adds entities (e.g. pv systems) to the specific control unit entity.

Parameters

- **control_entity_eid** (str) – entity id of control unit entity
- **entity_dict** (dict) – Dictionary of created models to be added to the control unit entity

eelib.core.devices**Subpackages****eelib.core.devices.car****Submodules****eelib.core.devices.car.car_model**

eELib car models the mobility and charging behavior of EV. The EV's electricity demand is derived from profiles generated by the open-source tool emopby. The model calculates its soc in every step, based on the cars consumption and possible charging power derived from charging station.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

<i>EV</i>	Models an electric vehicle and its change of soc depending on driving and charging.
-----------	---

Attributes

TOLERANCE_OVERCHARGED

TOLERANCE_OVERCHARGED

```
class EV(ename: str, start_time: str, file_emobpy: str, step_size: int = 60 * 15, n_steps: int = 1, soc_init: float = 0.5, set_emobpy_val: bool = True, soc_min: float = 0.02, e_max: int = 50000, p_nom_discharge_max: int = -11000, p_nom_charge_max: int = 11000, dcharge_efficiency: float = 0.95, charge_efficiency: float = 0.99)
```

Models an electric vehicle and its change of soc depending on driving and charging.

VALID_PARAMETERS

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

__set_emobpy_data(n_steps: int)

Collect data from the emobpy pickle file and save it into the model.

Parameters

n_steps (int) – number of steps for the simulation

Raises

- **IndexError** – When the time window of the pickle file does not match the simulation window
- **ValueError** – when the time resolutions of simulation and pickle file do not match

step(time)

Performs simulation step of eELib ev model.

Parameters

time (int) – Current simulation time

__check_appearance()

Check whether the EV is currently connected to the charging point or not.

__calc_next_arrival()

Calculates when the EV is arriving (the index) for the next time.

__calc_appearance_duration()

Calculate the number of time steps that the EV is still going to be connected to the charging station from now on until the next trip.

__calc_power()

Calculate the power at the current time step within the (dis)charging limits.

__set_energy_within_limit()

Check that battery energy limits are not surpassed.

`__calc_power_limits()`

Calculate the maximum (dis)charging power for the ev battery depending on the power limits and the current stored energy.

`__calc_bev_consumption_period()`

Calculate the electr. consumption of the BEV while at home for the next trip.

`eelib.core.devices.car.car_simulator`

Mosaik interface for the eELib car model. Simulator for communication between orchestrator (mosaik) and car entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<code>Sim</code>	Simulator class for eELib car model.
------------------	--------------------------------------

Attributes

<code>ADAPTION_TOLERANCE</code>	
<code>META</code>	

`ADAPTION_TOLERANCE`

`META`

`class Sim`

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib car model.

Parameters

`mosaik_api_v3(module)` – defines communication between mosaik and simulator

Raises

`ValueError` – Unknown output attribute, when not described in META of simulator

`init(sid, scenario_config, time_resolution=1.0)`

Initializes parameters for an object of the Car:Sim class.

Parameters

- **sid** (*str*) – Id of the created instance of the load simulator (e.g. CarSim-0).
- **scenario_config** (*dict*) – scenario configuration data, like resolution or step size.
- **time_resolution** (*float*) – fitting of the step size to the simulation scenario step size.

Returns

description of the simulator

Return type

meta

create(*num, model_type, init_vals*)

Creates instances of the eELib car model.

Parameters

- **num** (*int*) – Number of car models to be created
- **model_type** (*str*) – Description of the created instance (here “Car”)
- **init_vals** (*list*) – List (length=num) with initial values for each car model

Returns

created entities

Return type

dict

get_entity_by_id(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (*str*) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(*time, inputs, max_advance*)

Performs simulation step calling the eELib-car model.

Parameters

- **time** (*int*) – Current simulation time according to step size. Given by MOSAIK.
- **inputs** (*dict*) – Is a dictionary, that maps entity IDs to data dictionaries which map attribute names to lists of values. Given by MOSAIK.
- **max_advance** (*int, optional*) – Is the simulation time until the simulator can safely advance its internal time without causing any causality errors.

Raises

- **ValueError** – Error if incoming input has wrong format or includes more than one set value
- **TypeError** – value_dict has unknown format

Returns

New time stamp (time increased by step size)

Return type

int

get_data(outputs)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters

outputs (*dict*) – Dictionary with data outputs from each car model

Raises

ValueError – Error if attribute not in model metadata

Returns

Dictionary with simulation outputs

Return type

dict

eelib.core.devices.charging_station**Submodules****eelib.core.devices.charging_station.charging_station_model**

eELib charging station model is built to manage the charging processes of EVs.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes****ChargingStation**

Models a charging station for electric vehicles of different types.

```
class ChargingStation(ename: str, p_rated: int, output_type: str = 'AC', charge_efficiency: float = 1.0,
                      discharge_efficiency: float = 1.0, cos_phi: float = 1.0, step_size=60 * 15)
```

Models a charging station for electric vehicles of different types.

_VALID_PARAMETERS**classmethod get_valid_parameters()**

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

`_calc_power_limits()`

Calculate the power limits for the charging station with the input that's coming from the electric vehicles.

Raises

- **ValueError** – If the power limits of at least one connected ev do not work together.

`_distribute_charging_power()`

Distributes the charging power self.p across all connected cars. For this, the distribution is done evenly unless the power limits of the cars are exceeded.

Raises

- **ValueError** – If Vehicles charging power does not match the power of the charging station
- **ValueError** – If set charging power does not fit the power limits of the connected evs
- **ValueError** – If charging station has power value although no car is connected

`_calc_current_efficiency()`

For the current timestep and based on the active power flow calculate the present efficiency for the charging station.

`step(time)`

Performs simulation step of eELib cs model, using the power limits, set values and assigning power to charged cars.

Parameters

time (*int*) – Current simulation time in seconds

`eelib.core.devices.charging_station.charging_station_simulator`

Mosaik interface for the eELib charging station model. Simulator for communication between orchestrator (mosaik) and charging station entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

<i>Sim</i>	Simulator class for eELib charging station model.
------------	---

Attributes

ADAPTION_TOLERANCE

META

ADAPTION_TOLERANCE

META

class Sim

Bases: mosaik_api_v3.Simulator

Simulator class for eELib charging station model.

Parameters

mosaik_api_v3 (*module*) – defines communication between mosaik and simulator

Raises

ValueError – Unknown output attribute, when not described in META of simulator.

init(*sid, scenario_config, time_resolution=1.0*)

Initializes parameters for an object of the Charging-Station:Sim class.

Parameters

- **sid** (*str*) – Id of the created instance of the simulator (e.g. CSSim-0)
- **scenario_config** (*dict*) – scenario configuration data, like resolution or step size
- **time_resolution** (*float*) – Time resolution of current scenario.

Returns

description of the simulator

Return type

meta

create(*num, model_type, init_vals*)

Creates entities of the eELib charging station model. Core function of mosaik.

Parameters

- **num** (*int*) – Number of cs models to be created
- **model_type** (*str*) – type of created instance (e.g. “charging_station”)
- **init_vals** (*list*) – list with initial values for each charging_station entity

Returns

created entities

Return type

dict

get_entity_by_id(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (*str*) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(*time, inputs, max_advance*)

Performs simulation step calling the eELib charging_station model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict, optional*) – allocation of return values to specific models
- **max_advance** (*int, optional*) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Raises

- **ValueError** – Error if more than one set value is tried to be given to entity
- **TypeError** – value_dict has unknown format

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs*)

Gets the data for the next connected model. Core function of mosaik.

Parameters

outputs (*dict*) – dictionary with data outputs from each entity

Raises

ValueError – error if attribute not in model metadata

Returns

dictionary with simulation outputs

Return type

dict

eelib.core.devices.heatpump

Submodules

eelib.core.devices.heatpump.heatpump_model

eELib heat pump model for calculation of the thermal generation and electrical load of a heat pump. The model approximates the thermal calculations with power values and their impact on temperatures.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<code>Heatpump</code>	Models a heatpump.
<code>class Heatpump(ename: str, p_rated_th=10000, modulation=1, p_min_th_rel=0.5, time_min=2100, cop=3.60584, cos_phi: float = 1.0, step_size=60 * 15)</code>	
	Models a heatpump.
	_VALID_PARAMETERS
	classmethod get_valid_parameters()
	Returns dictionary containing valid parameter types and values.
	Returns
	valid parameters for this model
	Return type
	dict
	__set_state()
	Set the state of the heatpump with regard to the current power on on/off time.
	__calc_thermal_limits()
	Calculate the thermal maximum and minimum power of the heatpump.
	step(time)
	Calculating of current thermal and active power values, as well as the minimum and maximal values while differentiating between modulation or on/off heatpump.
	Parameters
	time (int) – Current simulation time
eelib.core.devices.heatpump.heatpump_simulator	
Mosaik interface for the eELib heatpump model. Simulator for communication between orchestrator (mosaik) and heatpump entities.	
Within this interface mosaik functionalities are used. Copyright (c) LGPL	
 Author: elenia@TUBS	
Copyright 2024 elenia	
This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.	

Module Contents

Classes

`Sim`

Simulator class for eELib heatpump model.

Attributes

`ADAPTION_TOLERANCE`

`META`

`ADAPTION_TOLERANCE`

`META`

`class Sim`

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib heatpump model.

Parameters

`mosaik_api_v3(module)` – defines communication between mosaik and simulator

Raises

`ValueError` – Unknown output attribute, when not described in META of simulator

`init(sid, scenario_config, time_resolution=1.0)`

Initializes parameters for an object of the Heatpump:Sim class.

Parameters

- `sid(str)` – ID of the created entity of the simulator (e.g. LoadSim-0)
- `scenario_config(dict)` – scenario configuration data, like resolution or step size
- `time_resolution(float)` – Time resolution of current scenario.

Returns

description of the simulator

Return type

meta

`create(num, model_type, init_vals)`

Creates entities of the eELib load model. Core function of mosaik.

Parameters

- `num(int)` – number of load models to created
- `model_type(str)` – type of created instance (e.g. “household”)
- `init_vals(list)` – list with initial values for each load entity

Returns

created entities

Return type

dict

get_entity_by_id(entity_id: str)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (str) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(time, inputs, max_advance)

Performs simulation step calling the eELib load model. Core function of mosaik.

Parameters

- **time** (int) – current simulation time (given by mosaik)
- **inputs** (dict, optional) – allocation of return values to specific models (NOT NEEDED FOR LOAD MODEL)
- **max_advance** (int, optional) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Raises

- **ValueError** – Error if more than one set value is tried to be given to entity
- **TypeError** – value_dict has unknown format

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(outputs)

Gets the data for the next connected model. Core function of mosaik.

Parameters

outputs (dict) – dictionary with data outputs from each entity

Raises

ValueError – error if attribute not in model metadata

Returns

dictionary with simulation outputs

Return type

dict

eelib.core.devices.pv**Submodules****eelib.core.devices.pv.pv_lib_model**

eELib pvlib photovoltaic model. The pv module and inverter are both modeled together.

Caution: It contains weather data from different years between 2005 and 2016 and handles them as if they all belong to the same simulated year.

See <https://pvlib-python.readthedocs.io/en/stable/index.html> for further reference: William F. Holmgren, Clifford W. Hansen, and Mark A. Mikofski. ‘pvlib python: a python package for modeling solar energy systems.’ Journal of Open Source Software, 3(29), 884, (2018). <https://doi.org/10.5281/zenodo.8368494>

Copyright (c) 2023 pvlib python Contributors Copyright (c) 2014 PVLIB python Development Team Copyright (c) 2013 Sandia National Laboratories

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

<i>PVLibBase</i>	Baseclass model for pv lib model implementations.
<i>PVLib</i>	An electrical photovoltaic system model from pv lib.
<i>PVLibExact</i>	An electrical photovoltaic system model from pv lib using specific modules and inverters.

```
class PVLibBase(ename: str, latitude: float = 57.38, longitude: float = 36.23, start_time: str = '2016-01-01 00:00:00', timezone: str = 'Etc/GMT-1', azimuth: float = 180, tilt: float = 35.0, cos_phi: float = 0.9, step_size: int = 60 * 15)
```

Bases: abc.ABC

Baseclass model for pv lib model implementations.

_VALID_PARAMETERS

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

_retrieve_weather_step(*time: int*)

Calculate current weather data.

Parameters

time (*int*) – Current simulation time step

_set_power()

Set active power from set value or to maximum and within limits, set reactive power.

abstract step(*time: int*)

Handles stepping of pvlib entity.

Parameters

time (*int*) – Current simulation time

class PVLib(*ename: str, p_rated: float = 10000, latitude: float = 57.38, longitude: float = 36.23, start_time: str = '2016-01-01 00:00:00', timezone: str = 'Etc/GMT-1', azimuth: float = 180, tilt: float = 35.0, gamma_pdc: float = -0.004, cos_phi: float = 0.9, inverter_efficiency: float = 0.96, losses_standby: float = 3.6, min_power: float = 56.0, step_size: int = 60 * 15*)

Bases: *PVLibBase*

An electrical photovoltaic system model from pv lib.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(*time: int*)

Performs simulation step of eELib pv_lib model. Simply extracts the value corresponding to the current simulation time.

Parameters

time (*int*) – Current simulation time

class PVLibExact(*ename: str, latitude: float = 57.38, longitude: float = 36.23, altitude_m: float = 75, module_name: str = 'SunPower_SPR_220__PVL____2006__', num_modules_per_string: int = 9, num_strings: int = 4, inverter_name: str = 'SMA_America__SB5000US__240V__', num_inverters: int = 2, start_time: str = '2016-01-01 00:00:00', timezone: str = 'Etc/GMT-1', azimuth: float = 180, tilt: float = 35, cos_phi: float = 0.9, step_size: int = 60 * 15*)

Bases: *PVLibBase*

An electrical photovoltaic system model from pv lib using specific modules and inverters.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(*time: int*)

Performs simulation step of eELib pv_lib model. Simply extracts the value corresponding to the current simulation time.

Parameters

time (*int*) – Current simulation time

eeelib.core.devices.pv.pv_lib_simulator

Mosaik interface for the eELib pvlib pv model. Simulator for communication between orchestrator (mosaik) and pv_lib entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes****Sim**

Simulator class for eELib pv_lib model.

Attributes**ADAPTION_TOLERANCE****META****ADAPTION_TOLERANCE****META****class Sim**

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib pv_lib model.

Parameters

mosaik_api_v3 (*module*) – defines communication between mosaik and simulator

init(*sid, scenario_config, time_resolution=1.0*)

Initializes parameters for an object of the PVLib:Sim class.

Parameters

- **sid** (*str*) – Id of the created instance of the pv_lib simulator (e.g. PVLibSim-0)
- **scenario_config** (*dict*) – scenario configuration data, like resolution or step size.
- **time_resolution** (*float*) – Time resolution of current mosaik scenario.

Returns

meta description of the simulator

Return type

meta

create(*num*, *model_type*, *init_vals*)

Creates instances of the eELib pv_lib model.

Parameters

- **num** (*int*) – Number of pv_lib models to be created
- **model_type** (*str*) – Description of the created pv_lib instance
- **init_vals** (*list*) – List (length=*num*) with initial values for each pv_lib model

Returns

return created entities

Return type

dict

get_entity_by_id(*entity_id*: *str*)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (*str*) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(*time*, *inputs*, *max_advance*)

Performs simulation step calling the eELib pv_lib model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict*, *optional*) – allocation of return values to specific models
- **max_advance** (*int*, *optional*) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Raises

- **ValueError** – Error if more than one set value is tried to be given to entity
- **TypeError** – if value_dict containing set values has an unknown format

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs*)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters

outputs (*dict*) – Dictionary with data outputs from each pv_lib model

Raises

ValueError – Error if attribute not in model metadata

Returns

Dictionary with simulation outputs

Return type

dict

eelib.core.devices.storage**Submodules****eelib.core.devices.storage.storage_model**

eELib battery storage system (BSS) model. The battery and inverter are both modeled together. Among other things , dynamic efficiency is taken into account.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes****BSS**

An electrical storage system model can be instantiated with default values or with a map of

```
class BSS(ename: str, soc_init=0.5, e_bat_rated=10000, p_rated_discharge_max=-8000,
          p_rated_charge_max=8000, discharge_efficiency_init=0.95, charge_efficiency_init=0.95,
          status_curve=False, loss_rate=0.02, dod_max=0.95, status_aging=False, soh_init=1.0,
          soh_cycles_max=0.8, bat_cycles_max=5000, bat_cycles_init=0, step_size=60 * 15,
          bat2ac_efficiency=None, ac2bat_efficiency=None)
```

An electrical storage system model can be instantiated with default values or with a map of initial values. An energy management model can be used to determine p_set values.

_VALID_PARAMETERS**classmethod get_valid_parameters()**

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

`__set_power_within_limit()`
Sets the active power limit of the battery based on its rated charge and discharge capacities and the current active power setpoint.

`__set_energy_within_limit()`
Check that battery energy limits are not surpassed.

`__calc_charging_efficiency()`
Sets dynamic (dis)charging efficiency levels (“charge_efficiency” / “discharge_efficiency”).

`__calc_power_limits()`
Sets (dis)charging power limits.

`step(time)`
Performs simulation step of eELib battery model. Calculates all of the Dynamic Properties based on the Input Properties.

Parameters

`time (int)` – Current simulation time

`__calculate_aging_status()`

Calculates the state of health (soh) and then checks if the soh limit has been reached.

```
soh = soh_init - #cycles * aging_of_one_cycle  
aging_of_one_cycle = (soh_init - soh_end) / #max_cycles
```

Raises

`ValueError` – When minimum soh has been reached for the battery

`__calc_discharge_efficiency()`

Calculation of dynamic discharging efficiency (bat2ac_efficiency).

`__calc_charge_efficiency()`

Calculation of dynamic charging efficiency (ac2bat_efficiency).

`eelib.core.devices.storage.storage_simulator`

Mosaik interface for the eELib storage model. Simulator for communication between orchestrator (mosaik) and storage entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

Sim

Simulator class for eELib storage model.

Attributes

ADAPTION_TOLERANCE

META

ADAPTION_TOLERANCE

META

class Sim

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib storage model.

Parameters

`mosaik_api_v3(module)` – defines communication between mosaik and simulator

`init(sid, scenario_config, time_resolution=1.0)`

Initializes parameters for an object of the Storage:Sim class.

Parameters

- `sid (str)` – Id of the created instance of the storage simulator (e.g. StorageSim-0)
- `scenario_config (dict)` – scenario configuration data, like resolution or step size.
- `time_resolution (float)` – Time resolution of current mosaik scenario.

Returns

meta description of the simulator

Return type

meta

`create(num, model_type, init_vals)`

Creates instances of the eELib storage model.

Parameters

- `num (int)` – Number of storage models to be created
- `model_type (str)` – Description of the created mosaik-storage instance
- `init_vals (list)` – List (length=num) with initial values for each storage model

Returns

return created entities

Return type

dict

get_entity_by_id(entity_id: str)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (str) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(time, inputs, max_advance)

Performs simulation step calling the eELib storage model. Core function of mosaik.

Parameters

- **time** (int) – current simulation time (given by mosaik)
- **inputs** (dict, optional) – allocation of return values to specific models
- **max_advance** (int, optional) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Raises

- **ValueError** – Error if more than one set value is tried to be given to entity
- **TypeError** – if value_dict containing set values has an unknown format

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(outputs)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters

outputs (dict) – Dictionary with data outputs from each storage model

Raises

ValueError – Error if attribute not in model metadata

Returns

Dictionary with simulation outputs

Return type

dict

eelib.core.forecast**Submodules****eelib.core.forecast.forecast_model**

eELib model for creation of forecast.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

<i>Forecast</i>	Models a forecast creation/calculation.
-----------------	---

Attributes

_logger

_logger

class Forecast(ename: str, step_size: int)

Models a forecast creation/calculation.

_VALID_PARAMETERS

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(time: int)

Perform simulation step for the forecast model.

Parameters

time (int) – Current simulation time

Raises

TypeError – Forecast is requested for an entity that is not added to forecast list

add_forecasted_entity(entity_dict: dict)

Adds a entity for the forecast to the corresponding forecast' lists.

Parameters

entity_dict (dict) – Input list with all entities of a type (e.g. pv) for which a forecast will be made.

eelib.core.forecast.forecast_simulator

Mosaik interface for the eELib energy management system (EMS) forecast. Simulator for communication between orchestrator (mosaik) and forecast.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

Sim

Simulator class for eELib forecast model.

Attributes

META

ADAPTION_TOLERANCE

META

ADAPTION_TOLERANCE

class Sim

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib forecast model.

Parameters

mosaik_api_v3 (module) – defines communication between mosaik and simulator

init(sid, scenario_config, time_resolution=1.0)

Initializer for Prognosis:Sim class.

Parameters

- **sid (str)** – ID of the created entity of the simulator (e.g. PrognosisSim-0)

- **scenario_config** (*dict*) – scenario configuration data, like resolution or step size
- **time_resolution** (*float*) – fitting of the step size to the simulation scenario step size.

Returns

description of the simulator

Return type

meta

create(*num, model_type='forecast', init_vals=None*)

Creates entities of the eELib forecast model. Core function of mosaik.

Parameters

- **num** (*int*) – number of models to be created
- **model_type** (*str*) – type of created entity, defaults to “forecast”
- **init_vals** (*list*) – list with initial values for each EMS entity, defaults to None

Returns

created entities

Return type

dict

get_entity_by_id(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (*str*) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(*time, inputs, max_advance*)

Performs simulation step calling the eELib forecast model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict*) – allocation of set values to specific models
- **max_advance** (*int*) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Raises

TypeError – if input has unknown format

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs: dict*)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters

outputs (*dict*) – dictionary with data outputs from each prognosed model

Raises

ValueError – error if attribute not in model metadata

Returns

dictionary with simulation outputs

Return type

dict

add_forecasted_entity(*prognosed_entity_id*: str, *entity_dict*: dict)

Adds entities (e.g. pv systems) to the specific forecast unit.

Parameters

- **prognosed_entity_id** (str) – Dictionary of forecast entity
- **entity_dict** (dict) – Dictionary of created models to be added to the forecast entity

eelib.core.grid

Subpackages

eelib.core.grid.pandapower

Submodules

eelib.core.grid.pandapower.pandapower_model

eELib pandapower grid model (oriented at mosaik_pandapower). Grid import could happen through Json files, and the file should exist in the working directory.

In pandapower library there exist a list of standard grids for direct import and simulation: <https://pandapower.readthedocs.io/en/v2.1.0/networks.html>

Copyright (c) 2018 by University of Kassel and Fraunhofer Institute for Energy Economics and Energy System Technology (IEE) Kassel and individual contributors

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

Pandapower

An electrical grid model in pandapower style.

Attributes

`OUTPUT_ATTRS`

`RENAMING_ATTRS`

`OUTPUT_ATTRS`

`RENAMING_ATTRS`

`class Pandapower(ename: str, gridfile: str, sim_start: str)`

Bases: `object`

An electrical grid model in pandapower style.

`_VALID_PARAMETERS`

`LIM`

`classmethod get_valid_parameters()`

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

`dict`

`_load_case(path)`

Loads a pandapower grid. The grid should be ready in a json file or an example grid.

Parameters

`path (str)` – file path to the grid file

Raises

`ValueError` – if given grid directory/file cannot be opened

`_get_slack()`

Create entity of the slack bus.

Returns

zero with index of slack bus

Return type

`tuple`

`_get_buses()`

Create entities of the buses.

Returns

indices of busses with their nominal voltage in kV

Return type

`list`

_get_loads()
Create load entities.

Returns
list of load with tuples about bus index, active/reactive power, scaling factor and their status

Return type
list

_get_lines()
Create branches entities.

Returns
list of grid lines with tuples about bus indices, their length, impedance/reactance/capacitance, maximum current and their status

Return type
list

_get_trafos()
Create trafo entities.

Returns
list of trafos with tuples about bus indices, max. power, nominal voltages, short circuit voltages, iron losses, open-loop current, phase shift, tap status and their status

Return type
list

set_inputs(etype, idx, data, static)
Setting the input from the simulator.

Parameters

- **etype** (*string*) – entity type of element to be set
- **idx** (*int*) – index of element in element list
- **data** (*dict*) – input data to be set, key (parameter) and corresponding value
- **static** (*dict*) – static values of this entity

Raises
ValueError – Error if no possible entity type was given

_powerflow()
Conduct power flow for the saved grid with its options from pandapower.

step(time)
Performs simulation step of eELib pandapower grid model.

Parameters
time (*int*) – Current simulation time

_store_power_flow_results()
Retrieve the results of the power flow and store them.

_get_powerflow_result_component(eid)
Retrieve the results of the power flow for a specific component.

Parameters
eid (*str*) – Entity ID of the component to be searched for

Returns

dict with the results from the power flow for the component

Return type

(dict)

_get_grid_status()

Analyse the status of the grid and its component at the current step in time.

_get_status_bus(*comp_idx: int*) → dict

Analyse the status of a grid bus at the current step in time.

Parameters

comp_idx (int) – index of the (bus) component in the corresponding grid.bus table

Returns

Status for the bus including limits and congestion status

Return type

dict

_get_status_line(*comp_idx: int, comp_type: str*) → dict

Analyse the status of a grid line at the current step in time.

Parameters

- **comp_idx (int)** – index of the (line) component in the grid.line/.trafo table
- **comp_type (str)** – whether it is a trafo or a line

Returns

description

Return type

dict

_calc_ptdf()

Calculate the DC Power Transfer Distribution Matrix of the Grid. Using function from pandapower.pypower. Only works after the calculation of a powerflow, as the “_ppc” matrix is calculated there. Orientation is as follows: One list for every branch (consequence), one element in each list for every bus (cause). E.g. for a 3-Bus radial grid the matrix will look like this: [[0, -1, -1], [0, 0, -1], [0, 0, 0]].

_calc_vpif()

Calculate the AC Voltage Power Impact Factor Matrix of the (current) Grid. The jacobian matrix is calculated in every iteration of pandapower powerflow calculation. The matrix of the last iteration is stored and will be accessed here as a sensitivity of adaptions. Only works after the calculation of a powerflow, as the “_ppc” matrix is calculated there. Direction corresponds to PSC (power consumption decreases voltage magnitude). Orientation is as follows: One list for every bus (consequence, adjustment of vm_pu), one element in each list for every bus times two (cause, first adaption of active power P afterwards adaption of reactive power Q). E.g. for a 2-bus grid the matrix will look like this: [[B1dP->B1dVm, B2dP->B1dVm, B1dQ->B1dVm, B2dQ->B1dVm], [B1dP->B2dVm, B2dP->B2dVm, B1dQ->B2dVm, B2dQ->B2dVm]].

eelib.core.grid.pandapower.pandapower_simulator

Mosaik interface for the eELib pandapower grid model. Simulator for communication between orchestrator (mosaik) and pandapower grid entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<i>Sim</i>	Simulator class for eELib pandapower grid model.
------------	--

Attributes

<i>ADAPTION_TOLERANCE</i>
<i>META</i>

ADAPTION_TOLERANCE

META

class Sim

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib pandapower grid model.

Parameters

`mosaik_api_v3(module)` – defines communication between mosaik and simulator

`init(sid, scenario_config, time_resolution=1.0, trigger=False)`

Initializes parameters for an object of the Pandapower:Sim class.

Parameters

- `sid(str)` – Id of the entity of the pandapower grid simulator (e.g. PandapowerSim-0)
- `scenario_config(dict)` – scenario configuration data, like resolution or step size.
- `time_resolution(float)` – Time resolution of current mosaik scenario.
- `trigger(boolean)` – Whether power flow is triggered by events

Returns

meta description of the simulator

Return type

meta

create(*num*, *model_type*, *gridfile*, *sim_start=None*)

Creates instances of the eELib pandapower model.

Parameters

- **num** (*int*) – Number of pandapower models to be created
- **model_type** (*str*) – Description of the created eELib-pandapower instance
- **gridfile** (*str*) – directory of the file with the grid data
- **sim_start** (*str*) – date of the simulation start

Returns

return created entities

Return type

dict

setup_done()

Adjust entity IDs and activate components at the end of the grid setup.

Yields*related_components* – grid components that are in relation to one another (e.g. bus and connected line)**get_entity_by_id**(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters**entity_id** (*str*) – id of the entity to be searched for**Returns**

entity model if found, None otherwise

Return type

object

step(*time*, *inputs*, *max_advance*)

Performs simulation step calling the eELib pandapower grid model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict, optional*) – allocation of return values to specific models
- **max_advance** (*int, optional*) – simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs*)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters**outputs** (*dict*) – Dictionary with data outputs from each storage model

Raises

- **ValueError** – Error if attribute not in model metadata
- **KeyError** – Error if component entity could not be found in pandapower grid

Returns

Dictionary with simulation outputs

Return type

dict

eelib.core.market**Subpackages****eelib.core.market.retail_electricity_provider****Submodules****eelib.core.market.retail_electricity_provider.rep_model**

eELib retail electricity provider models the behavior of provider for electricity. This basically is reduced to a provider for households and maybe small business companies.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

RetailElectricityProvider	Models a retail electricity provider with tariff signals and market information.
----------------------------------	--

```
class RetailElectricityProvider(ename: str, step_size: int = 60 * 15, n_steps: int = 24 * 4, tariff_type: str = 'static', elec_price: float = 0.35, feedin_tariff: float = 0.07)
```

Models a retail electricity provider with tariff signals and market information.

```
market_info_attrs = ['price_weighted_avg', 'price_low', 'price_high', 'price_last']
```

```
_VALID_PARAMETERS
```

```
classmethod get_valid_parameters()
```

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

`add_market_entity(market_dict: dict)`

Adds a market entity to the corresponding list.

Parameters**`market_dict (dict)`** – Input list with all market models**`step(time)`**

Performs simulation step of eELib REP model.

Parameters**`time (int)`** – Current simulation time**`_calc_tariff_output()`**

Combine values and market info for a tariff signal for this time step.

Raises

- **`ValueError`** – If variable tariffs are chosen (not yet implemented!)
- **`ValueError`** – If dynamic tariffs are chosen (not yet implemented!)

`__request_forecast()`

Set markets with the needed attributes and time horizon for forecast request.

`eelib.core.market.retail_electricity_provider.rep_simulator`

Mosaik interface for the eELib retail electricity provider model. Simulator for communication between orchestrator (mosaik) and REP entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes****`Sim`**

Simulator class for eELib retail electricity provider model.

Attributes

ADAPTION_TOLERANCE

META

ADAPTION_TOLERANCE

META

class Sim

Bases: mosaik_api_v3.Simulator

Simulator class for eELib retail electricity provider model.

Parameters

mosaik_api_v3 (*module*) – defines communication between mosaik and simulator

Raises

ValueError – Unknown output attribute, when not described in META of simulator

init(*sid, scenario_config, time_resolution=1.0*)

Initializes parameters for an object of the REP:Sim class.

Parameters

- **sid** (*str*) – Id of the created instance of the load simulator (e.g. REPSim-0).
- **scenario_config** (*dict*) – scenario configuration data, like resolution or step size.
- **time_resolution** (*float*) – fitting of the step size to the simulation scenario step size.

Returns

description of the simulator

Return type

meta

create(*num, model_type, init_vals*)

Creates instances of the eELib retail electricity provider model.

Parameters

- **num** (*int*) – Number of REP models to be created
- **model_type** (*str*) – Description of the created instance (here “RetailElectricityProvider”)
- **init_vals** (*list*) – List (length=num) with initial values for each REP model

Returns

created entities

Return type

dict

get_entity_by_id(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters

entity_id (*str*) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(*time*, *inputs*, *max_advance*)

Performs simulation step calling the eELib retail electricity provider model.

Parameters

- **time** (*int*) – Current simulation time according to step size. Given by MOSAIK.
- **inputs** (*dict*) – Is a dictionary, that maps entity IDs to data dictionaries which map attribute names to lists of values. Given by MOSAIK.
- **max_advance** (*int, optional*) – Is the simulation time until the simulator can safely advance it's internal time without causing any causality errors.

Raises

TypeError – value_dict has unknown format

Returns

New time stamp (time increased by step size)

Return type

int

get_data(*outputs*)

Gets the data for the next concatenated model. Core function of mosaik.

Parameters

outputs (*dict*) – Dictionary with data outputs from each REP model

Raises

ValueError – Error if attribute not in model metadata

Returns

Dictionary with simulation outputs

Return type

dict

add_market_entity(*market_entity_eid*: str, *market_dict*: dict)

Adds market entities (e.g. market csv reader) to the specific REP entity.

Parameters

- **market_entity_eid** (*str*) – entity id of REP entity
- **market_dict** (*dict*) – Dictionary of market models to be added to the REP entity

eelib.data

This contains all models that are “just” retrieving input data (like a simple csv-reader). It also includes the functionalities for simulation data to be collected and assessed and dataclasses for structured exchange of data between the models.

Subpackages**eelib.data.csv_reader****Submodules****eelib.data.csv_reader.csv_reader_model**

eELib csv-reader model for reading-in .csv-files to imitate different model types (e.g. PV, household or heatpump).

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

<i>CSVReader</i>	Parent class for reading-in .csv-files.
<i>GenericCSV</i>	CSV-Data-Reader for profiles. Inherits from class csv_reader.
<i>RatedCSV</i>	CSV-Data-Reader for profiles. Inherits from class csv_reader.
<i>PowerCSV</i>	CSV-Data-Reader for power profiles. Inherits from class csv_reader.
<i>HouseholdCSV</i>	CSV-Data-Reader for household load profiles. Inherits from class csv_reader.
<i>PvCSV</i>	CSV-Data-Reader for pv-generation profiles. Inherits from class CSVReader.
<i>HeatpumpCSV</i>	CSV-Data-Reader for heatpump load profiles.
<i>ChargingStationCSV</i>	CSV-Data-Reader for charging_station profiles. Inherits from class CSVReader.
<i>HouseholdThermalCSV</i>	CSV-Data-Reader for thermal demand profiles. Inherits from class RatedCSV.
<i>MarketIntradayContinuousCSV</i>	CSV-Data-Reader for intraday continuous market data. Inherits from class CSVReader.

```
class CSVReader(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD  
HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15)
```

Parent class for reading-in .csv-files.

Raises

- **FileNotFoundException** – when .csv-file cannot be opened (e.g. path or data corrupted)
- **ValueError** – when start date is not in .csv-file
- **IndexError** – when end of .csv-file is reached before simulation end

VALID_PARAMETERS

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

_open_csv() → None

Opens the .csv-file and loads data set.

Raises

FileNotFoundException – when .csv-file cannot be read

_check_data() → None

Checks if row in opened .csv-file contains the simulation start date.

Raises

ValueError – Start date is not in .csv-file

_resample_data() → None

step(time) → None

Performs simulation step of eELib csv_reader model, which is returning the averaged read values in the .csv-file.

Parameters

time (int) – Current simulation time in seconds.

class GenericCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15)

Bases: [CSVReader](#)

CSV-Data-Reader for profiles. Inherits from class csv_reader. Sets each column of the csv file as attribute.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(time) → None

Performs simulation step of generic csv reader model, which is setting the attr according to the columns in csv file.

Parameters

time (int) – Current simulation time in seconds.

```
class RatedCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD  
HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15, p_rated: int = 4500, p_rated_profile: int  
= 4500)
```

Bases: *CSVReader*

CSV-Data-Reader for profiles. Inherits from class `csv_reader`. Adds support for scaling to `p_rated`.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

_apply_p_rated() → None

Apply scaling factor (`p_rated/p_rated_profile`).

```
class PowerCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD  
HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15, p_rated: int = 4500, p_rated_profile: int  
= 4500, cos_phi: float = 1.0)
```

Bases: *RatedCSV*

CSV-Data-Reader for power profiles. Inherits from class `csv_reader`.

Adds support for calculating reactive power.

Assumptions:

- first column is `p`
- second column is `q`, if csv has more than one column

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

_set_reactive_power() → None

Calculate reactive power if not given in csv file and if `cos_phi` is set.

step(time)

Performs simulation step of eELib load model, which is returning the read active/reactive power value of the .csv-file.

Parameters

`time (int)` – Current simulation time in seconds.

```
class HouseholdCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str =  
'YYYY-MM-DD HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15, p_rated: int =  
4500, p_rated_profile: int = 4500, cos_phi: float = 1.0)
```

Bases: *PowerCSV*

CSV-Data-Reader for household load profiles. Inherits from class `csv_reader`.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

```
class PvCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD
HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15, p_rated: int = 4500, p_rated_profile: int =
4500, cos_phi: float = 1.0)
```

Bases: *PowerCSV*

CSV-Data-Reader for pv-generation profiles. Inherits from class CSVReader.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(time)

Performs simulation step of eELib load model, which is returning the read active/reactive power value of the .csv-file.

Parameters

time (int) – Current simulation time in seconds.

```
class HeatpumpCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD
HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15, p_rated: int = 4000, p_rated_profile:
int = 4000, cos_phi: float = 0.95)
```

Bases: *PowerCSV*

CSV-Data-Reader for heatpump load profiles.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(time)

Performs simulation step of eELib load model, which is returning the read active/reactive power value of the .csv-file.

Parameters

time (int) – Current simulation time in seconds.

```
class ChargingStationCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str =
'YYYY-MM-DD HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15, p_rated: int =
4500, p_rated_profile: int = 4500, cos_phi: float = 1.0)
```

Bases: *PowerCSV*

CSV-Data-Reader for charging_station profiles. Inherits from class CSVReader.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

class HouseholdThermalCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15, p_rated: int = 20000, p_rated_profile: int = 20000)

Bases: *RatedCSV*

CSV-Data-Reader for thermal demand profiles. Inherits from class RatedCSV.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(time)

Performs simulation step of eELib charging_station model, which is returning the read active power value of the .csv-file.

Parameters

time (int) – Current simulation time in seconds.

class MarketIntradayContinuousCSV(ename: str, datafile: str, header_rows: int, start_time: str, date_format: str = 'YYYY-MM-DD HH:mm:ss', delimiter: str = ',', step_size: int = 60 * 15)

Bases: *CSVReader*

CSV-Data-Reader for intraday continuous market data. Inherits from class CSVReader.

Implementation as a price-taking market: The participants have no influence or impact on the market price and participants have to accept the prevailing market price. As decentralized power systems are investigated, this assumption is fine as the whole intraday market includes many sellers (with the identical product ‘electricity’). See e.g. <https://www.economicsonline.co.uk/definitions/price-taker.html/> for more information.

The prices are given in the unit ‘EUR/MWh’.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

step(time)

Performs simulation step of model, which is returning the read value of the .csv-file.

Parameters

time (int) – Current simulation time in seconds.

eelib.data.csv_reader.csv_reader_simulator

Mosaik interface for the eELib csv-reader model. Simulator for communication between orchestrator (mosaik) and csv-reader entities.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<i>Sim</i>	Simulator class for eELib csv-reader model.
------------	---

Attributes

<i>META</i>

META

class Sim

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib csv-reader model.

Parameters

`mosaik_api_v3(module)` – defines communication between mosaik and simulator

Raises

`ValueError` – Unknown output attribute, when not described in META of simulator

`init(sid, scenario_config, time_resolution=1.0)`

Initializes parameters for an object of the CSV-Reader:Sim class.

Parameters

- `sid(str)` – ID of the created entity of the simulator (e.g. LoadSim-0)
- `scenario_config(dict)` – scenario configuration data, like resolution or step size
- `time_resolution(float)` – Time resolution of current scenario.

Returns

description of the simulator

Return type

meta

create(*num, model_type, init_vals*)

Creates entities of the eELib csv-reader model. Core function of mosaik.

Parameters

- **num** (*int*) – number of load models to be created
- **model_type** (*str*) – type of created instance (e.g. “household”)
- **init_vals** (*list*) – list with initial values for each csv-reader entity

Returns

created entities

Return type

dict

get_entity_by_id(*entity_id: str*)

Searches for a requested entity id and gives back the entity model.

Parameters

- **entity_id** (*str*) – id of the entity to be searched for

Returns

entity model if found, None otherwise

Return type

object

step(*time, inputs, max_advance*)

Performs simulation step calling the eELib csv-reader model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict, optional*) – allocation of return values to specific models (NOT NEEDED FOR CSV-READER MODEL)
- **max_advance** (*int, optional*) – simulation time until the simulator can safely advance it’s internal time without causing any causality errors.

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs*)

Gets the data for the next connected model. Core function of mosaik.

Parameters

- **outputs** (*dict*) – dictionary with data outputs from each entity

Raises

ValueError – error if attribute not in model metadata

Returns

dictionary with simulation outputs

Return type

dict

eelib.data.database**Submodules****eelib.data.database.hdf5**

Interface for the event-based HDF5 database.

Within this interface mosaik functionalities are used. Copyright (c) LGPL

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes**

<i>Hdf5Database</i>	HDF5 Database class
---------------------	---------------------

Attributes

```
meta
```

```
meta
```

class Hdf5Database

Bases: `mosaik_api.Simulator`

HDF5 Database class Inherits mosaik simulator class for management.

init(*sid*, *time_resolution*, *scenario_config*, *series_path*=(None, None))

Initialize HDF5 Database Entity.

Parameters

- **sid** (*str*) – string id of the entity to be created
- **time_resolution** (*float*) – timely resolution of the simulation scenario
- **scenario_config** (*dict*) – configurations of the simulation
- **series_path** (*tuple*) – path for the series to be stored. Defaults to (None, None).

Returns

meta description of the simulator

Return type

meta

create(*num*, *model*, *filename*, *buf_size*=1000, *dataset_opts*=None)

Creates instances of the HDF5 output database.

Parameters

- **num** (*int*) – Number of hdf5 db models to be created
- **model** (*str*) – Description of the created hdf5 db entity
- **filename** (*str*) – Directory of the hdf5 file
- **buf_size** (*int*) – Number of elements to be stored before writing into DB. Defaults to 1000
- **dataset_opts** (*dict*) – Potential set of options for the dataset. Defaults to None.

Raises

- **ValueError** – Error if more than one hdf5 DB is to be created
- **ValueError** – Error if an unknown model type (not Database) is given

Returns

description of the hdf5 DB entity with ID, type and relations

Return type

dict

setup_done()

Check if setup of the DB is done.

Yields

list – related entity for the simulator (given by mosaik)

step(*time*, *inputs*, *max_advance*)

Performs simulation step saving/buffering data and storing it into the DB. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict*) – allocation of return values to specific models
- **max_advance** (*int*) – simulation time until the simulator can safely advance its internal time without causing any causality errors.

Returns

next time step (when orchestrator calls again)

Return type

int

_store_relations()

Query relations graph and store it in the database.

Yields

list – related entities of simulator (given by mosaik)

_create_dataset(*src_id*, *attr*, *dtype*, *ds_size*, *buf*, *buf_size*)

Create a dataset for the attribute *attr* of entity *src_id*. The dataset will use the type *dtype* and will have the size *ds_size*. Also initialize the buffer *buf* with size *buf_size*.

Parameters

- **src_id** (*str*) – entity for the dataset to be stored in hdf5 file

- **attr** (*str*) – attribute to be saved
- **dtype** (*type*) – Type of the attribute
- **ds_size** (*int*) – number of data elements to be stored
- **buf** (*dict*) – storing of buffered elements within a list
- **buf_size** (*int*) – number of elements to be buffered before storing

_get_group(*eid*)

Get or create group for entity *eid*.

Parameters

eid (*str*) – entity identification string

Returns

hdf5 file group element for data to be stored into

Return type

Group

_get_supergroup(*eid*)

Get or create supergroup for entity *eid* using pattern.

Parameters

eid (*str*) – entity identification string

Raises

ValueError – Error if entity ID was not given in correct format

Returns

supergroup for the data to be stored into

Return type

SuperGroup

_store_dict(*group*, *dictionary*, *dataset_name*)

Store a dictionary as a dataset in a given group.

Parameters

- **dictionary** (*dict*) – dictionary to be stored
- **group** (*Group*) – the group to store the data in
- **dataset_name** (*str*) – the name of the dataset

_store_json(*group*, *data*, *dataset_name*)

Store json-like data as a dataset in a given group.

Parameters

- **data** (*Any*) – data to be stored
- **group** (*Group*) – the group to store the data in
- **dataset_name** (*str*) – the name of the dataset

_get_entity_path(*eid*)

Get the database path to a searched entity by its ID.

Parameters

eid (*str*) – identification number of the entity to be searched

Returns
path to the entity

Return type
str

`eelib.data.dataclass`

Submodules

`eelib.data.dataclass._base`

Base Class for Dataclasses used in eELib.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

`BaseData`

Baseclass for Dataclasses.

`class BaseData`

Bases: abc.ABC

Baseclass for Dataclasses.

`check_adaption_tolerance(adaption_tolerance: float, dict_cache: dict, dict_to_check: dict = None) → bool`

Compares the input data with its cache based on the individual values.

Parameters

- `adaption_tolerance (float)` – fixed adaption tolerance for comparison of values
- `dict_cache (dict)` – cached dataclass to be compared
- `dict_to_check (dict)` – Subdict to be checked, substitutes dataclass if existent. Defaults to None.

Raises

`TypeError` – if format for dataclass value is unknown

Returns

True if value of new dataclass has changed

Return type

bool

eelib.data.dataclass.control

Dataclasses for control signals used in eELib.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Classes***ControlSignalEMS*

Dataclass for Control Signals sent to an Energy Management System.

class ControlSignalEMS

Bases: *eelib.data.dataclass._base.BaseData*

Dataclass for Control Signals sent to an Energy Management System. The lists always have to be of the same length!

steps (list): timesteps where control signal is active
 p_max (list): maximum active power for those time steps [kW]
 p_min (list): minimum active power for those time steps [kW]
 penalty_cost (float): penalty costs in case of non-compliancy [EUR/kW]

```
steps: list[int]
p_max: list[float]
p_min: list[float]
penalty_cost: float
```

eelib.data.dataclass.devices

Dataclasses for devices' data used in eELib.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<i>BaseDeviceData</i>	Baseclass for Dataclasses of the devices.
<i>BSSData</i>	Dataclass for eELib BSS model.
<i>EVData</i>	Dataclass for eELib EV model.
<i>CSDData</i>	Dataclass for eELib charging station model.
<i>HPData</i>	Dataclass for eELib heatpump model.
<i>PVData</i>	Dataclass for eELib pv(lib) model.

class BaseDeviceData

Bases: *eelib.data.dataclass._base.BaseData*

Baseclass for Dataclasses of the devices.

p (float): current active power
p_min (float): minimum active power limit
p_max (float): maximum active power limit

p: float

p_min: float

p_max: float

class BSSData

Bases: *BaseDeviceData*

Dataclass for eELib BSS model.

e_bat_rated (float): rated energy amount of bss
p_rated_charge_max (float): maximum charge power of bss
p_rated_discharge_max (float): maximum discharge power of bss
loss_rate (float): self-discharge (per month) of bss
self_discharge_step (float): self-discharge rate (per simulation step) of bss
dod_max (float): maximum depth of discharge
status_aging (float): whether to account for aging of battery
soh_cycles_max (float): state of health at end of lifetime
bat_cycles_max (float): maximum cycles to reach end of lifetime
soc_min (float): lower soc level of bss
bat2ac_efficiency (list[float]): exponential discharging efficiency values
ac2bat_efficiency (list[float]): exponential charging efficiency values

charge_efficiency (float): charging efficiency
discharge_efficiency (float): discharging efficiency
soh (float): state of health
bat_cycles (int): number of cycles accumulated by the battery
e_bat (float): current energy amount stored
e_bat_usable (float): usable energy amount of bss considering ageing

e_bat_rated: int

p_rated_discharge_max: int

p_rated_charge_max: int

loss_rate: float

self_discharge_step: float

dod_max: float

status_aging: bool

soh_cycles_max: float

```

bat_cycles_max: int
soc_min: float
bat2ac_efficiency: list[float] | None
ac2bat_efficiency: list[float] | None
charge_efficiency: float
discharge_efficiency: float
soh: float
bat_cycles: int
e_bat: float
e_bat_usable: float

class EVData
Bases: BaseDeviceData
Dataclass for eELib EV model.

soc_min (float): minimum soc level of car e_max (float): rated energy level of car battery p_nom_charge_max (float): maximum charging power of car p_nom_discharge_max (float): maximum discharging power of car charge_efficiency (float): charge efficiency of car dcharge_efficiency (float): discharge efficiency of car e_bat (float): energy amount of the car appearance (bool): where car is available at charging point or not

soc_min: float
e_max: float
p_nom_discharge_max: float
p_nom_charge_max: float
dcharge_efficiency: float
charge_efficiency: float
e_bat: float
appearance: bool

class CSData
Bases: BaseDeviceData
Dataclass for eELib charging station model.

charge_efficiency (float): charge efficiency of charging station discharge_efficiency (float): discharge efficiency of charging station p_rated (float): rated power of charging station

ev_data (dict): information about all the connected electric vehicles q (float): current reactive power

discharge_efficiency: float
charge_efficiency: float
p_rated: float

```

```
ev_data: dict[str:EVData]
q: float

class HPData
Bases: BaseDeviceData
Dataclass for eELib heatpump model.

p_rated (float): rated thermal power of heatpumps p_min_th_rel (float): relative minimum power (of rated power) for modulating heatpumps time_min (int): minimum on/off-time for heatpumps

time_on (int): current on-time for heatpumps time_off (int): current off-time for heatpumps state (str): current state of heatpumps (on, off, must-on or must-off) cop (float): current coefficient of power for heatpumps p_th (float): current thermal power p_th_min (float): minimum thermal power limit p_th_min_on (float): minimum thermal power limit in on-state p_min_on (float): minimum electrical power limit in on-state p_th_max (float): maximum thermal power limit q (float): current reactive power

p_rated_th: float
p_min_th_rel: float
time_min: int
time_on: int
time_off: int
state: str
cop: float
p_th: float
p_th_min: float
p_th_min_on: float
p_min_on: float
p_th_max: float
q: float

class PVData
Bases: BaseDeviceData
Dataclass for eELib pv(lib) model.

p_rated (float): rated power of system
q (float): current reactive power

p_rated: float
q: float
```

eelib.data.dataclass.options

Dataclasses for options used in eELib.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<i>OptimOptions</i>	Dataclass for Options of an Energy Management System Optimization.
---------------------	--

class OptimOptions

Bases: *eelib.data.dataclass._base.BaseData*

Dataclass for Options of an Energy Management System Optimization.

consider_thermal (bool): whether to consider the thermal balance for the optimization
 thermal_energy_start (float): thermal energy demand before first schedule step
 thermal_energy_restriction (bool): restrict the thermal energy within this energy range [kWh_th]
 th_e_penalty (float): penalty for th. energy demand surpassing the restricting limits

ev_direct_cha (bool): incent. dir. charging with max. power with min. desc. obj. func. value
 bss_direct_cha (bool): incent. dir. charging using a min. descending obj. function value
 dir_cha_desc_factor (float): descending obj. func. factor for charging power (bss, ev)

ev_end_energy_penalty (float): penalty factor if ev not entirely filled at the last step
 bss_end_energy_incentive (bool): incent. stored bss energy at last step (avoid disch. into grid)

round_int (int): number of integers to round the optimization results to

consider_thermal: bool

thermal_energy_start: float

thermal_energy_restriction: float

th_e_penalty: float

ev_direct_cha: bool

bss_direct_cha: bool

dir_cha_desc_factor: float

ev_end_energy_penalty: float

bss_end_energy_incentive: bool

round_int: int

eelib.data.dataclass.tariff

Dataclasses for tariffs and market data used in eELib.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<code>MarketData</code>	Dataclass for Market Data.
<code>Tariff</code>	Dataclass for Prosumer Tariff.
<code>TariffSignal</code>	Dataclass for Tariff that is sent as a Signal to a Household.
<code>GridTariff</code>	Dataclass for Grid Usage Fees.
<code>GridTariffSignal</code>	Dataclass for Signal regarding Grid Usage Fees.

`class MarketData`

Bases: `eelib.data.dataclass._base.BaseData`

Dataclass for Market Data.

`price_weighted_avg` (float): weighted average price
`price_low` (float): lowest market price
`price_high` (float): highest market price
`price_last` (float): last market price

`price_weighted_avg: float`
`price_low: float`
`price_high: float`
`price_last: float`

`class Tariff`

Bases: `eelib.data.dataclass._base.BaseData`

Dataclass for Prosumer Tariff.

`elec_price` (float): electricity consumption price info [EUR/kWh]. Defaults to 35ct/kWh
`feedin_tariff` (float): electricity feed-in price info [EUR/kWh]. Defaults to 7ct/kWh
`capacity_fee_dem` (float): Price for max. power demand at connection [EUR/kW]. Defaults to 0
`capacity_fee_gen` (float): Price for max. power generation at connection [EUR/kW]. Defaults to 0
`capacity_fee_horizon_sec` (int): Horizon for capacity fee [seconds]. Defaults to 86400 (1 day)

`elec_price: float`
`feedin_tariff: float`
`capacity_fee_dem: float`
`capacity_fee_gen: float`

```
capacity_fee_horizon_sec: int
```

```
class TariffSignal
```

Bases: `eelib.data.dataclass._base.BaseData`

Dataclass for Tariff that is sent as a Signal to a Household.

`bool_is_list` (bool): Whether signal is for multi-step tariff. Defaults to False
`elec_price` (float, list): electricity consumption price info [EUR/kWh]. Defaults to 0.35
`feedin_tariff` (float, list): electricity feed-in price info [EUR/kWh]. Defaults to 0.07
`steps` (list): timesteps for the corresponding list of prices. Defaults to empty list
`capacity_fee_dem` (float): Price for max. power demand at connection [EUR/kW]. Defaults to 0
`capacity_fee_gen` (float): Price for max. power generation at connection [EUR/kW]. Defaults to 0
`capacity_fee_horizon_sec` (int): Horizon for capacity fee [seconds]. Defaults to 86400 (1 day)

```
bool_is_list: bool
```

```
elec_price: float | list
```

```
feedin_tariff: float | list
```

```
steps: list
```

```
capacity_fee_dem: float
```

```
capacity_fee_gen: float
```

```
capacity_fee_horizon_sec: int
```

```
class GridTariff
```

Bases: `eelib.data.dataclass._base.BaseData`

Dataclass for Grid Usage Fees.

`grid_tariff_model` (str): which control model is selected for households. Defaults to “flat-rate”
`energy_price` (float): Energy-dependent price for electr. consump. [EUR/kWh]. Defaults to 8ct/kWh
`capacity_fee_dem` (float): Price for max. power demand at connection [EUR/kW]. Defaults to 0
`capacity_fee_gen` (float): Price for max. power generation at connection [EUR/kW]. Defaults to 0
`capacity_fee_horizon_sec` (int): Horizon for capacity fee [seconds]. Defaults to 86400 (1 day)

```
grid_tariff_model: str
```

```
energy_price: float
```

```
capacity_fee_dem: float
```

```
capacity_fee_gen: float
```

```
capacity_fee_horizon_sec: int
```

```
class GridTariffSignal
```

Bases: `eelib.data.dataclass._base.BaseData`

Dataclass for Signal regarding Grid Usage Fees.

`bool_is_list` (bool): Whether signal is for multi-step tariff. Defaults to False
`energy_price` (float, list): Energy-dependent price for el. cons. [EUR/kWh]. Defaults to 8ct/kWh
`steps` (list): timesteps for the corresponding list of prices. Defaults to empty list
`capacity_fee_dem` (float): Price for max. power demand at connection [EUR/kW]. Defaults to 0
`capacity_fee_gen` (float): Price for max. power generation at connection [EUR/kW]. Defaults to 0
`capacity_fee_horizon_sec` (int): Horizon for capacity fee [seconds]. Defaults to 86400 (1 day)

```
bool_is_list: bool
energy_price: float | list
steps: list
capacity_fee_dem: float
capacity_fee_gen: float
capacity_fee_horizon_sec: int
```

eelib.data.influx_reader

Submodules

eelib.data.influx_reader.influx_reader_model

eELib Influx-reader models for reading-in from Influx database to imitate different model types. Specializations for certain model types like Household series.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<i>GenericInflux</i>	Class for reading data from an influxdb.
<i>RatedInflux</i>	Influx-Data-Reader for profiles. Inherits from class GenericInflux.
<i>PowerInflux</i>	Influx-Data-Reader for power profiles. Inherits from class RatedInflux.
<i>HouseholdInflux</i>	Influx-Data-Reader for household load profiles. Inherits from class PowerInflux.
<i>PvInflux</i>	Influx-Data-Reader for pv load profiles. Inherits from class PowerInflux.

Attributes

`_logger`

`_logger`

```
class GenericInflux(ename: str, step_size: int, measurement_name: str, tags: dict[str, str], fields: list[str],
                     start_time: str, end_time: str, influx_url: str | None = None, influx_token: str | None = None,
                     influx_org: str | None = None, influx_bucket: str | None = None)
```

Class for reading data from an influxdb.

`_VALID_PARAMETERS`

`classmethod get_valid_parameters()`

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

`__del__()`

Close the client after the reader's job is done.

`static generate_tag_filter(tags: dict[str, str] = None) → str`

Generates tag filters for Influx query.

Parameters

`tags (dict[str, str], optional)` – Tags to generate filter.

Returns

Tag selection part of Influx query.

Return type

str

`generate_influx_query(measurement_name: str, start_time: str, end_time: str, resolution: int, tags: dict[str, str] = None, fields: list[str] = None) → str`

Generates influx query based on given parameters.

Parameters

- `measurement_name (str)` – Name of the series.
- `start_time (str)` – Start time of the series slice.
- `end_time (str)` – End time of the series slice.
- `resolution (int)` – Time resolution used for aggregation.
- `tags (dict[str, str], optional)` – Tags with keys and values. Defaults to None.
- `fields (list[str], optional)` – Fields of the series. Defaults to None.

Returns

Influx query

Return type

str

_read_db(measurement_name: str, tags: dict[str, str], fields: list[str], start_time: str, end_time: str, resolution: int)

Filters data in the database based on given parameters and returns the result as a dataframe.

Parameters

- **measurement_name (str)** – Name to filter _measurement
- **tags (dict[str, str])** – Tags to filter, e.g. “type”: “load”
- **fields (list[str])** – Fields to select
- **start_time (str)** – Range start time
- **end_time (str)** – Range end time
- **resolution (int)** – time resolution to aggregate

Returns

query result with DateTime index and one column for each field.

Return type

pd.DataFrame

step(time)

Performs simulation step of eELib influx_reader model.

Parameters**time (int)** – Current simulation time**Raises****IndexError** – when end of data is reached before simulation end**class RatedInflux(ename: str, step_size: int, measurement_name: str, tags: dict[str, str], fields: list[str], start_time: str, end_time: str, p_rated: int = 4500, p_rated_profile: int = 4500, influx_url: str | None = None, influx_token: str | None = None, influx_org: str | None = None, influx_bucket: str | None = None)**Bases: *GenericInflux*

Influx-Data-Reader for profiles. Inherits from class GenericInflux. Adds support for scaling to p_rated.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

_apply_p_rated() → None

Apply scaling factor (p_rated/p_rated_profile).

class PowerInflux(ename: str, step_size: int, measurement_name: str, tags: dict[str, str], fields: list[str], start_time: str, end_time: str, p_rated: int = 4500, p_rated_profile: int = 4500, cos_phi: float = 1.0, influx_url: str | None = None, influx_token: str | None = None, influx_org: str | None = None, influx_bucket: str | None = None)Bases: *RatedInflux*

Influx-Data-Reader for power profiles. Inherits from class RatedInflux.

Adds support for calculating reactive power. Assumptions: - first field is p - second field is q, if more than one field is given

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

_set_reactive_power() → None

Calculate reactive power if not given as field of that series in influx and if cos_phi is set.

step(time)

Performs simulation step of eELib load model, which is returning the read active/reactive power value of the series read from Influx database.

Parameters

time (int) – Current simulation time in seconds.

```
class HouseholdInflux(ename: str, step_size: int, measurement_name: str, fields: list[str], start_time: str, end_time: str, p_rated: int = 4500, p_rated_profile: int = 4500, cos_phi: float = 1, influx_url: str | None = None, influx_token: str | None = None, influx_org: str | None = None, influx_bucket: str | None = None)
```

Bases: *PowerInflux*

Influx-Data-Reader for household load profiles. Inherits from class PowerInflux. Data in Influx Database must have a tag with key value pair {‘type’: ‘load’}.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

```
class PvInflux(ename: str, step_size: int, measurement_name: str, fields: list[str], start_time: str, end_time: str, p_rated: int = 4500, p_rated_profile: int = 4500, cos_phi: float = 1, influx_url: str | None = None, influx_token: str | None = None, influx_org: str | None = None, influx_bucket: str | None = None)
```

Bases: *PowerInflux*

Influx-Data-Reader for pv load profiles. Inherits from class PowerInflux. Data in Influx Database must have a tag with key value pair {‘type’: ‘pv’}.

classmethod get_valid_parameters()

Returns dictionary containing valid parameter types and values.

Returns

valid parameters for this model

Return type

dict

eelib.data.influx_reader.influx_reader_simulator

Mosaik interface for the eELib influx-reader model. Simulator for communication between orchestrator (mosaik) and influx-reader entities.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

<i>Sim</i>	Simulator class for eELib influx-reader model.
------------	--

Functions

<i>set_meta_attrs</i> (init_vals)	Method to dynamically set the attributes of the simulator.
-----------------------------------	--

Attributes

<i>META</i>

META

set_meta_attrs(*init_vals*)

Method to dynamically set the attributes of the simulator. Should be called before the simulation begins.

Parameters

init_vals (*dict*) – initial variables and their values.

class Sim

Bases: `mosaik_api_v3.Simulator`

Simulator class for eELib influx-reader model.

Parameters

mosaik_api_v3 (*module*) – defines communication between mosaik and simulator

Raises

ValueError – Unknown output attribute, when not described in META of simulator

init(*sid, scenario_config, time_resolution=1.0*)

Initializer for influx-Reader:Sim class.

Parameters

- **sid** (*str*) – ID of the created entity of the simulator (e.g. LoadSim-0)
- **scenario_config** (*dict*) – scenario configuration data, like resolution or step size
- **time_resolution** (*float*) – Time resolution of current scenario.

Returns

description of the simulator

Return type

meta

create(*num, model_type, init_vals*)

Creates entities of the eELib influx-reader model. Core function of mosaik.

Parameters

- **num** (*int*) – number of load models to be created
- **model_type** (*str*) – type of created instance (e.g. “household”)
- **init_vals** (*list*) – list with initial values for each influx-reader entity

Returns

created entities

Return type

dict

step(*time, inputs, max_advance=1*)

Performs simulation step calling the eELib influx-reader model. Core function of mosaik.

Parameters

- **time** (*int*) – current simulation time (given by mosaik)
- **inputs** (*dict, optional*) – allocation of return values to specific models
- **max_advance** (*int, optional*) – simulation time until the simulator can safely advance it’s internal time without causing any causality errors.

Returns

next time step (when orchestrator calls again)

Return type

int

get_data(*outputs*)

Gets the data for the next connected model. Core function of mosaik.

Parameters

outputs (*dict*) – dictionary with data outputs from each entity

Raises

ValueError – error if attribute not in model metadata

Returns

dictionary with simulation outputs

Return type

dict

eelib.data.input**Submodules****eelib.data.input.extract**

Helper module to extract data from different sources.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Functions****extract_htw**(→ dict[str, pandas.DataFrame])

Extract data from public htw Matlab files.

extract_htw(*mat_file*: str, *idx*: int | range | Sequence | None = None) → dict[str, pandas.DataFrame]

Extract data from public htw Matlab files.

Parameters

- **mat_file** (str) – String to path of HTW Matlab file.
- **idx** (*Optional[int | range | Sequence], optional*) – Idx to extract, defaults to None.

Returns

Dict of DataFrames.

Return type

dict[str, pd.DataFrame]

eelib.data.input.load

Helper module. Influx Db Connector to load data to Influx Database.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

`InfluxDbStorage`

Influx Db Connector class to write pandas dataframes.

Attributes

`data_path`

```
class InfluxDbStorage(influx_url: str | None = None, influx_token: str | None = None, influx_org: str | None = None, influx_bucket: str | None = None)
```

Influx Db Connector class to write pandas dataframes.

`__del__()`

Delete client connection on delete.

`write_pandas_dataframe(df: pandas.DataFrame, name: str, tags: dict[str, str]) → None`

Write pandas dataframe to influx database.

Parameters

- `df (pd.DataFrame)` – Df to write to Influx.
- `name (str)` – Name of the series.
- `tags (dict[str, str])` – Tags to add when writing to Influx.

`data_path = '.'`

Submodules

`eelib.data.collector`

Simple collector simulator based on the one defined within the mosaik tutorial: <https://mosaik.readthedocs.io/en/latest/>
Prints all inputs immediately.

@author: elenia@TUBS

Module Contents

Classes

`Collector`

Collector simualtor to provide simple prints in each step.

Attributes

META

META

class Collector

Bases: mosaik_api_v3.Simulator

Collector simualtor to provide simple prints in each step.

init(sid, time_resolution)

Init of a simulator instance.

Parameters

- **sid** (_type_) – _description_
- **time_resolution** (_type_) – _description_

Returns

description

Return type

type

create(num, model)

Create mosaik sim of the collector.

Parameters

- **num** (_type_) – _description_
- **model** (_type_) – _description_

Raises

RuntimeError – If more than one simulators should be initialized.

Returns

eid and simulator

Return type

dict

step(time, inputs, max_advance)

Step method of the collector simulator. Prints all inputs.

Parameters

- **time** (_type_) – _description_
- **inputs** (_type_) – _description_
- **max_advance** (_type_) – _description_

Returns

max advance until next call of the simulator.

Return type

int

eelib.model_connections**Submodules****eelib.model_connections.connections**

Module to load connection config.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Functions**

<code>get_default_connections(→ dict)</code>	Load default connection config from model_connect_config.json file.
<code>get_connection_directions_config(→ dict)</code>	Load set directions for connections from connect_directions_config.json file.

Attributes

<code>conf</code>

get_default_connections() → dict

Load default connection config from model_connect_config.json file.

Returns

Model connect config as Python dict.

Return type

dict

get_connection_directions_config() → dict

Load set directions for connections from connect_directions_config.json file.

Returns

Connect direction config as Python dict, with fields “ALWAYS_WEAK”, “ALWAYS_STRONG”, and “STRONG_DIR”.

Return type

dict

conf

eelib.utils

Contains helper functions and classes.

e.g. provide unified colors, return file content in a necessary format

Subpackages**eelib.utils.ancillary_services****Submodules****eelib.utils.ancillary_services.voltage_control_concepts**

Methods for various concepts for voltage control of inverter-based devices.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Functions**

<code>cos_phi_fix(p, cos_phi)</code>	Calculate reactive power output from active power and a fix cosinus phi (power factor).
--------------------------------------	---

`cos_phi_fix(p: float, cos_phi: float)`

Calculate reactive power output from active power and a fix cosinus phi (power factor). Negative active power (generation!) leads to positive reactive power (inductive behaviour). Positive active power (demand!) leads to negative reactive power (capacitive behaviour).

Parameters

- `p (float)` – active power of device (>0 is demand, <0 is generation)
- `cos_phi (float)` – power factor, value between 0 (not included!) and 1

Raises

`ValueError` – If cos_phi is outside of range from 0 to 1

Returns

reactive power output from device

Return type

float

eelib.utils.eval

Here the functionalities for evaluating and plotting/presenting outputs of simulations are stored, mostly in accessible and modifiable python scripts or jupyter notebooks.

Submodules

eelib.utils.eval.evaluation_utils

Useful helper methods for evaluating .hdf5 results in jupyter notebooks.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Functions

<code>find_corresponding_component_dict(series_group [...])</code>	Tries to infer the component that corresponds to a <code>series_group_name</code> using a dictionary of
<code>find_corresponding_component(series_group_name)</code>	Tries to infer the component that corresponds to a <code>series_group_name</code> using a pre-defined
<code>make_compact(df)</code>	The function returns a compacted version of the non-compact output of <code>hdf5_file_as_pandas()</code>
<code>hdf5_file_as_pandas(path[, pseudonyms, compact, ...])</code>	Return a dataframe representation of the hdf5 file.
<code>get_config(→ dict)</code>	Return scenario configuration of the hdf5 file.
<code>get_timeseries(dataframe, unit, component[, number])</code>	Extracts timeseries data from non-compact dataframe using component name, number and unit.
<code>convert_hdf5_to_csv(input_path, output_path[, ...])</code>	Converts an hdf5 file with the proper format into a csv file. Uses non-compact representation
<code>timestep_to_datetime(timestep, zero_datetime, step_size)</code>	Converts a (numpy list of) timestep(s) to a (numpy list of) actual date(s).
<code>save_figure(fig, ax, filename, path[, figsize, dpi, ...])</code>	Saves a Matplotlib figure with standardized sizing and format.
<code>_read_config(hdf5_data)</code>	Return dictionary corresponding to scenario_config.

Attributes

```
NAME_COM_DICT
```

NAME_COM_DICT

find_corresponding_component_dict(series_group_name: str, name_com_dict: dict = NAME_COM_DICT)

Tries to infer the component that corresponds to a `series_group_name` using a dictionary of regular expressions and components.

Parameters

- `series_group_name` (str) – the name of the series group inside the hdf5 file.
- `name_com_dict` (dict) – dictionary linking regular expressions to components. Defaults to NAME_COM_DICT.

Returns

A string representation of the component, i.e. the value corresponding to the first regular expression in `name_com_dict` that matches the `series_group_name`. Returns “*Unidentified*”, if no proper value is found.

Return type

str

find_corresponding_component(series_group_name: str)

Tries to infer the component that corresponds to a `series_group_name` using a pre-defined regular expression.

Parameters

`series_group_name` (str) – the name of the series group inside the .hdf5 file.

Returns

- (1) A string representation of the component. “*Unidentified*”, if no proper value is found.
- (2) The number of the component.

Return type

str, int

make_compact(df: pandas.DataFrame)

The function returns a compacted version of the non-compact output of `hdf5_file_as_pandas()` so the rows represent elements of timeseries and columns represent compacted names for each.

Parameters

`df` (DataFrame) – non-compact dataframe.

Returns

compacted dataframe.

Return type

DataFrame

hdf5_file_as_pandas(path: str, pseudonyms=True, compact=False, datetime_col=False)

Return a dataframe representation of the hdf5 file.

Parameters

- `path` (str) – path of the hdf5 file.

- **pseudonyms** (*bool*) – If set to *True* the function also tries to infer the component corresponding to each timeseries group in the file and adds it as a column to the beginning of the dataframe. Uses *find_corresponding_component()*. Defaults to *True*.
- **compact** (*bool*) – If set to *True* the function returns a compacted version of the pandas dataframe so the rows represent elements of timeseries and columns represent compacted names for each. Defaults to *False*.
- **datetime_col** (*bool*) – If set to *True* the function adds a column to dataframe to display the actual date and time in addition to timesteps. Only works if *compact=True*. Defaults to *False*.

Returns

A dataframe representation of the data inside the hdf5 file.

Return type

pandas.DataFrame

get_config(*path: str*) → *dict*

Return scenario configuration of the hdf5 file.

Parameters

path (*str*) – path of the hdf5 file.

Returns

scenario configuration dict.

Return type

dict

get_timeseries(*dataframe: pandas.DataFrame, unit: str, component: str, number: int = 0*)

Extracts timeseries data from non-compact dataframe using component name, number and unit.

Parameters

- **dataframe** (*DataFrame*) – the dataframe generated from *hdf5_file_as_pandas()* method.
- **unit** (*str*) – the name of the unit.
- **component** (*str*) – the name of the component.
- **number** (*int*) – the number of the component. Defaults to 0.

Raises

- **KeyError** – if the column “Component” does not exist.
- **ValueError** – if there are multiple or zero timeseries matching the inputs.

Returns

the timeseries corresponding to the received component and unit.

Return type

list

convert_hdf5_to_csv(*input_path: str, output_path: str, pseudonyms=True, sep=',', na_rep=' ', compact=False, datetime_col=False*)

Converts an hdf5 file with the proper format into a csv file. Uses non-compact representation unless specified.

Parameters

- **input_path** (*str*) – path for input hdf5 file.
- **output_path** (*str*) – path for the output csv file.

- **pseudonyms** (*bool*) – If set to *True* the function also tries to infer the component corresponding to each timeseries group in the file and adds it as a column to the beginning of the dataframe. Defaults to True.
- **sep** (*str*) – String of length 1. Field delimiter for the output file. Defaults to ‘;’.
- **na_rep** (*str*) – Missing data representation. Defaults to ‘’.
- **compact** (*bool*) – Whether function returns a compacted version of the data - rows represent elements of timeseries and columns represent compacted names for each. Defaults to False
- **datetime_col** (*bool*) – Whether the function adds a column to dataframe to display the actual date and time in addition to timesteps. Only works if compact=True. Defaults to False

timestep_to_datetime(*timestep*, *zero_datetime*: *datetime.datetime*, *step_size*: *int*)

Converts a (numpy list of) timestep(s) to a (numpy list of) actual date(s).

Parameters

- **timestep** – a timestep or a numpy array of timesteps.
- **zero_datetime** (*datetime*) – the datetime corresponding to timestep 0. Inclusion of zero in the list is not mandatory.
- **step_size** (*int*) – size of each timestep in seconds.

Returns

calculated date(s) corresponding to timestep(s).

Return type

`numpy.datetime64`

save_figure(*fig*, *ax*, *filename*, *path*, *figsize*=(15, 5), *dpi*=300, *format*='svg', *rasterized*=*True*)

Saves a Matplotlib figure with standardized sizing and format.

Parameters

- **fig** (*Figure*) – Matplotlib figure to be saved.
- **ax** (*Axes*) – Matplotlib ax.
- **filename** (*str*) – Name of the output file.
- **path** (*str*) – path of the output file.
- **figsize** (*tuple*) – Size of the figure in inches (width, height).
- **dpi** (*int*) – Dots per inch for image resolution.
- **format** (*str*) – Output file format (e.g., ‘svg’, ‘png’, ‘jpg’, etc.).
- **rasterized** (*bool*) – Whether to rasterize vector elements (*True*) or not (*False*).

_read_config(*hdf5_data*)

Return dictionary corresponding to scenario_config.

Parameters

hdf5_data – data read from an hdf5 file using h5py.

Returns

the scenario_config as stored.

Return type

`dict`

Submodules

`eeelib.utils.colormap`

Provides an elenia colormap to use standardized colors across the project.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Functions

`register_and_use_elenia_colormap()`

Register the elenia colormap and set it as matplotlib.pyplot's default.

Attributes

`PRIM_ELENIA_CMAP`

`SEC_ELENIA_CMAP`

`ELENIA_CMAP`

`PRIM_DISC_CMAP`

`SEC_DISC_CMAP`

`DISC_CMAP`

`PRIM_INT_CMAP`

`SEC_INT_CMAP`

`RED_GREEN_INT_CMAP`

`RED_GREEN_RED_INT_CMAP`

`PRIM_ELENIA_CMAP = ['#005374', '#00709B', '#66B4D3', '#BE1E3C', '#711C2F']`

`SEC_ELENIA_CMAP = ['#711C2F', '#D46700', '#E3B225', '#ACC13A', '#6D8300', '#00534A', '#003F57', '#00709B', ...]`

`ELENIA_CMAP`

`PRIM_DISC_CMAP`

`SEC_DISC_CMAP`

`DISC_CMAP`

`PRIM_INT_CMAP`

`SEC_INT_CMAP`

`RED_GREEN_INT_CMAP`

`RED_GREEN_RED_INT_CMAP`

`register_and_use_elenia_colormap()`

Register the elenia colormap and set it as matplotlib.pyplot's default.

`eeelib.utils.logging_helpers`

Logging helper with custom format and functions to set logger.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Classes

`CustomFormatter`

CustomFormatter with different colors for logging levels.

Functions

`clear_logger()`

Function to remove existing loggers.

`set_console_logger([level])`

Set console output logger.

`set_file_logger([level, filename])`

Set file logger.

Attributes

LOGGING_FORMAT

```
LOGGING_FORMAT = '%(asctime)s | %(levelname)-9s| %(threadName)s | %(name)s:%(lineno)d -\n%(message)s'
```

```
class CustomFormatter(fmt=None, datefmt=None, style='%', validate=True, *, defaults=None)
```

Bases: `logging.Formatter`

CustomFormatter with different colors for logging levels. Specialization of `logging.Formatter`.

```
grey = '\x1b[38;20m'
```

```
yellow = '\x1b[33;20m'
```

```
red = '\x1b[31;20m'
```

```
bold_red = '\x1b[31;1m'
```

```
reset = '\x1b[0m'
```

format_str

FMTS

format(*record*)

Overrides `format` method.

Parameters

record (*_type_*) – record to log.

Returns

Formatted log string.

Return type

`str`

clear_logger()

Function to remove existing loggers.

set_console_logger(*level*: int = `logging.DEBUG`)

Set console output logger. All messages will be printed to `StdOut`.

Parameters

level (*int*) – Logging level. Defaults to `logging.DEBUG`.

set_file_logger(*level*: int = `logging.DEBUG`, *filename*: str = 'eELib.log')

Set file logger. All messages will be written to the file with given filename.

Parameters

- **level** (*int*) – Logging level. Defaults to `logging.DEBUG`.

- **filename** (*str*) – Logfile filename. Defaults to “eELib.log”.

eeelib.utils.read_pickle

Reads .pickle files.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Functions****`read_pickle(path)`**

Read the whole data from a stored pickle file.

`read_pickle(path: str)`

Read the whole data from a stored pickle file.

Parameters

path (*str*) – path to pickle file

Raises

FileNotFoundException – Error if given pickle file path is not existent

Returns

stored data from pickle file

Return type

data

eeelib.utils.resample

Methods for inter- or extrapolating timeseries data (in pandas Dataframe format).

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Functions****`get_resolution_pandas_timeseries(→ int)`**

Computes the time resolution of a given timeseries.

`resample_pandas_timeseries_agg(→`

pan-

das.DataFrame)

Resample a given DataFrame to a target time resolution.

Attributes`_logger`**_logger****get_resolution_pandas_timeseries**(*timeseries*: pandas.DataFrame | pandas.Series) → int

Computes the time resolution of a given timeseries.

TODO (1) handle if not DataFrame or Series (2) handle if not a DatetimeIndex

Parameters**timeseries** (pd.DataFrame / pd.Series) – pandas Timeseries to determine resolution**Returns**

time resolution in seconds

Return type

int

resample_pandas_timeseries_agg(*df*: pandas.DataFrame, *target_resolution*: int, *ffill_columns*: list = [], *distribute_columns*: list = [], *key*: str = "") → pandas.DataFrame

Resample a given DataFrame to a target time resolution.

Columns that must be uniformly distributed or just filled forward

Parameters

- **df** (pd.DataFrame) – The df to be resampled.
- **target_resolution** (int) – The resolution to be sampled in (seconds).
- **ffill_columns** (list) – Columns to be filled forward. Defaults to [].
- **distribute_columns** (list) – Columns to be distributed. Defaults to [].
- **key** (str) – Key to describe the series (just for logging). Defaults to “”.

Returns

the resampled DataFrame

Return type

pd.DataFrame

eelib.utils.simulation_helper

Helper methods for retrieving simulation objects from lists or listing available entities.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents**Functions**

<code>get_entity_by_id(e_list, e_id)</code>	Provides an entity with regard to a given id from the entity list.
<code>get_entity_by_id_from_dict_list(e_dict_list, e_id)</code>	Provides an entity with regard to a given id from the entity list.
<code>create_plots(world, dir_graphs, bool_plot[, ...])</code>	Create some plots after the simulation.
<code>start_simulators(→ dict)</code>	Start all model factories for the simulators listed in SIM_CONFIG and one for each model.
<code>create_entities(→ dict)</code>	Create all models based on simulators and their models dict given in sim_config.
<code>create_entities_of_model(→ list)</code>	Create model entities for a given ModelFactory object with regard to model name and input.
<code>get_grid_components(→ dict)</code>	Collect all components of a specific grid.
<code>check_model_connect_config(model_connect_config)</code>	Check the layout and input of a connection configuration for models.
<code>connect_entities(world, dict_entities, ...)</code>	Connect all model entities to each other based on the created models and their connections.
<code>set_connection_direction(→ tuple[str, str])</code>	Orders the weak-strong direction of two models by its model names to begin with.
<code>connect_entities_in_grid(grid_model_config, grid, ...)</code>	Connect all entities for a simulation containing a power grid.
<code>connect_entities_to_db(sim_config, database, ...)</code>	Connects all models (model entities) to the database.
<code>connect_grid_to_db(sim_config_grid, database, ...)</code>	Connects all grid components to the database.
<code>connect_to_forecast(world, dict_entities, ...)</code>	Create connections for the forecasts to work.
<code>connect_entities_of_two_model_types(world, ...[, ...])</code>	Connect the elements of two lists in both directions (if needed) via mosaik.
<code>get_default_dirs(→ dict)</code>	Gathers all needed directories resp. its paths based on eELib's default structure.

Attributes`_logger``_logger``get_entity_by_id(e_list: list, e_id: str)`

Provides an entity with regard to a given id from the entity list.

Parameters

- **e_list** (*list*) – list of entities to be searched in
- **e_id** (*str*) – id of the entity that we search for

Returns

- (1) model entity if found, otherwise None
- (2) dict for the model entity (eid, full_id, type) if found, otherwise None

Return type

entity, dict

get_entity_by_id_from_dict_list(*e_dict_list*: dict, *e_id*: str)

Provides an entity with regard to a given id from the entity list.

Parameters

- **e_dict_list** (dict) – dict with lists of entities (sorted by type) to be searched in
- **e_id** (str) – id of the entity that we search for

Returns

- (1) model entity if found, otherwise None
- (2) dict for the model entity (eid, full_id, type) if found, otherwise None

Return type

entity, dict

create_plots(*world*: object, *dir_graphs*: str, *bool_plot*: bool, *slices_execution*: list = [0, 4])

Create some plots after the simulation. Especially the execution_graph take some time to create and should not be created for every simulation.

Parameters

- **world** (object) – mosaik world object to orchestrate the simulation process
- **dir_graphs** (str) – direction where to save the create plots
- **bool_plot** (bool) – whether to create the plots or not
- **slices_execution** (list) – list of length 2 to assign start and end index of the execution graph to plot. Defaults to [0, 4].

start_simulators(*sim_config*: dict, *world*: object, *scenario_config*: dict) → dict

Start all model factories for the simulators listed in SIM_CONFIG and one for each model.

Parameters

- **sim_config** (dict) – Information about the used simulators and their models
- **world** (object) – mosaik world object to orchestrate the simulation process
- **scenario_config** (dict) – parameters for the simulation scenario

Returns

Contains all ModelFactories sorted by the name of the corresponding model

Return type

dict

create_entities(*sim_config*: dict, *model_data*: dict, *dict_simulators*: dict, *grid_model_config*: dict = {}) → dict

Create all models based on simulators and their models dict given in sim_config.

Parameters

- **sim_config** (dict) – Information about the used simulators and their models
- **model_data** (dict) – dict containing all information about the to-be-created model entities
- **dict_simulators** (dict) – dict of all used simulators with their ModelFactory-objects

- **grid_model_config** (*dict*) – contains assigning the devices (by its type) to loads in the grid

Raises

KeyError – If a model is to be created but does not exist for this simulator (ModelFactory)

Returns

contains all created entities sorted by their model type

Return type

dict

create_entities_of_model(*model_factory: object, model_name: str, init_vals: list*) → *list*

Create model entities for a given ModelFactory object with regard to model name and input.

Parameters

- **model_factory** (*object*) – ModelFactory for a model
- **model_name** (*str*) – name of the model to create entities for
- **init_vals** (*list*) – initial values of the model (attributes to set)

Raises

- **KeyError** – If the ModelFactory has no such model type
- **TypeError** – If the initial values were given in the wrong format

Returns

all created model entities in one list (empty if no entity to create)

Return type

list

get_grid_components(*grid_comps_list: list*) → *dict*

Collect all components of a specific grid.

Parameters

grid_comps_list (*list*) – list of all grid components to collect from

Returns

containing all grid components separated by type

Return type

dict

check_model_connect_config(*model_connect_config: list*)

Check the layout and input of a connection configuration for models.

Parameters

model_connect_config (*list*) – list of the model properties to connect

Raises

- **TypeError** – If the connection config is no list
- **TypeError** – If an element of the connection config is neither a string nor a tuple
- **TypeError** – If an connection config element is a tuple but not consisting of two strings

connect_entities(*world: object, dict_entities: dict, model_connect_config: dict, dict_simulators: dict*)

Connect all model entities to each other based on the created models and their connections.

Parameters

- **world** (*object*) – mosaik world object to orchestrate the simulation process
- **dict_entities** (*dict*) – dict of all used model entity objects as lists, sorted by their type
- **model_connect_config** (*dict*) – dict of all connected attributes between each model type
- **dict_simulators** (*dict*) – dict of all used simulators with their ModelFactory-objects

set_connection_direction(*name_from_init*: str, *name_to_init*: str) → tuple[str, str]

Orders the weak-strong direction of two models by its model names to begin with.

Parameters

- **name_from_init** (*str*) – name of model in initial from-position
- **name_to_init** (*str*) – name of model in initial to-position

Raises

ValueError – if no decision was found for connection of these two models

Returns

names of models, first FROM- and second TO-position

Return type

tuple[str, str]

connect_entities_in_grid(*grid_model_config*: dict, *grid*: object, *grid_loads*: list, *world*: object, *model_connect_conf*: dict, *dict_entities*: dict, *dict_simulators*: dict, *architecture_models*: list = ['RetailElectricityProvider', 'GridEMS'])

Connect all entities for a simulation containing a power grid. Includes connection between the devices in the grid and between devices (or EMS) and grid loads.

Parameters

- **grid_model_config** (*dict*) – contains assigning the devices (by its type) to loads in the grid
- **grid** (*object*) – power grid entity
- **grid_loads** (*list*) – list of all load objects in the power grid
- **world** (*object*) – mosaik world object to orchestrate the simulation process
- **model_connect_conf** (*dict*) – dict of all connected attributes between each model type
- **dict_entities** (*dict*) – dict of all used model entity objects as lists, sorted by their type
- **dict_simulators** (*dict*) – dict of all used simulators with their ModelFactory-objects
- **architecture_models** (*list*) – all superordinate models to connect to each other and every ems

Raises

- **ValueError** – If more than one grid ems is created.
- **ValueError** – If more than one retail electricity provider is created.
- **KeyError** – No entity was created for a desired connection in the grid.
- **KeyError** – Given grid load name from model_connect_conf not found in grid loads list.
- **ValueError** – There are electric vehicles but no charging stations at a connection point.
- **KeyError** – A grid load is planned to be connected to two different entities.

connect_entities_to_db(*sim_config: dict, world: object, database: object, dict_entities: dict*)

Connects all models (model entities) to the database.

Parameters

- **sim_config** (*dict*) – Information about the used simulators and their models
- **world** (*object*) – mosaik world object to orchestrate the simulation process
- **database** (*object*) – model object of the database for the simulation
- **dict_entities** (*dict*) – dict of all used model entity objects

connect_grid_to_db(*sim_config_grid: dict, world: object, database: object, dict_comps: dict*)

Connects all grid components to the database.

Parameters

- **sim_config_grid** (*dict*) – Information about the used grid simulator and the components with a list of their output attributes
- **world** (*object*) – mosaik world object to orchestrate the simulation process
- **database** (*object*) – model object of the database for the simulation
- **dict_comps** (*dict*) – dict of all used grid component entity objects, sorted by their type

connect_to_forecast(*world: object, dict_entities: dict, dict_simulators: dict, forecast: object, forecast_sim: object, connect_models_names: list*)

Create connections for the forecasts to work. Includes mosaik connections to ems model and adding of the model entities to the forecasts list.

Parameters

- **world** (*object*) – mosaik world object to orchestrate the simulation process
- **dict_entities** (*dict*) – dict of all used model entity objects
- **dict_simulators** (*dict*) – dict of all used simulators with their ModelFactory-objects
- **forecast** (*object*) – forecast model entity
- **forecast_sim** (*object*) – simulator for the forecast model
- **connect_models_names** (*list*) – model names to directly connect to forecast entity

connect_entities_of_two_model_types(*world: object, entity_list_strong: list, entity_list_weak: list, model_connect_config_from_strong: list, model_connect_config_from_weak: list = [], sim_entities_weak: object = None*)

Connect the elements of two lists in both directions (if needed) via mosaik. Also add elements to list of controlled entities if the “weak” entity is an ems.

Parameters

- **world** (*object*) – mosaik World object
- **entity_list_strong** (*list*) – entities that have “strong” outgoing connections
- **entity_list_weak** (*list*) – entities that have “weak” outgoing connections
- **model_connect_config_from_strong** (*list*) – list of properties (str or tuple) to connect the two models types - from strong to weak
- **model_connect_config_from_weak** (*list*) – list of properties (str or tuple) to connect the two models types - from weak to strong. Defaults to [].

- **sim_entities_weak**(*object*) – Simulator of the “weak” entities for the adding of entities to the ems controlled entities. Defaults to None.

Raises

- **TypeError** – if given mosaik world is not correct (does not have connect method)
- **ValueError** – if no strong connection properties are given but there are weak connections

get_default_dirs(*dir_base*, *scenario*: str = 'building', *grid*: str = 'example_grid_kerber.json', *format_db*: str = 'hdf5') → dict

Gathers all needed directories resp. its paths based on eELib’s default structure.

Parameters

- **dir_base** (str) – string with path to root director
- **scenario** (str) – Type of used scenario (like building, grid etc.). Defaults to “building”.
- **grid** (str) – name of the grid file to use. Defaults to “example_grid_kerber.json”.
- **format_db** (str) – format of the database. Defaults to None.

Raises

FileNotFoundException – If model data for current simulation scenario not found

Returns

all relevant paths for a simulation

Return type

dict

eelib.utils.validation

Provide a dictionary of type and value validation rules and validate given parameters or print a readable string of the given set of rules.

Author: elenia@TUBS

Copyright 2024 elenia

This file is part of eELib, which is free software under the terms of the GNU GPL Version 3.

Module Contents

Functions

validate_init_parameters (<i>model_class</i> , <i>input_param_dict</i>)	in-	Validate the type and value of a list of parameters according to a provided dictionary.
format_valid_parameters_dictionary (<i>valid_params</i>)		Take the valid parameters dictionary of a model and transform it into a readable string

validate_init_parameters(*model_class*, *input_param_dict*: dict)

Validate the type and value of a list of parameters according to a provided dictionary.

Parameters

- **model_class** (*class*) – a class representing a component. This should contain a method `get_valid_parameters()` that returns a dictionary.
- **input_param_dict** (*dict*) – a dictionary of parameter name value pairs to be assessed and validated.

Raises

- **TypeError** – Invalid parameter input types
- **ValueError** – Invalid parameter input values

format_valid_parameters_dictionary(*valid_parameters*: *dict*)

Take the valid parameters dictionary of a model and transform it into a readable string
format for the purpose of displaying it.

Parameters

valid_parameters (*dict*) – a dictionary representing valid parameter types and values

Returns

Message string with the collected errors from input validation

Return type

str

2.1.4 Disclaimer / Authors

Author: elenia@TUBS

Copyright 2024 elenia

The eELib is free software under the terms of the GNU GPL Version 3.

If you intend to cite the eELib, please use this:

(TBD) Carsten Wegkamp, Henrik Wagner, Eike Niehs, Julien Essers, Marcel Luedcke, Bernd Engel: “eELib: Open-Source Model Library for Prosumer Power Systems and Energy Management Strategies”, Open Source Modelling and Simulation of Energy Systems (OSMSES) 2024, Vienna, Austria, 2024

CHAPTER
THREE

INDICES AND TABLES

- genindex
- modindex

PYTHON MODULE INDEX

C

eelib.core, 44
eelib.core.control, 44
eelib.core.control.EMS, 44
eelib.core.control.EMS.EMS_bss_helper, 44
eelib.core.control.EMS.EMS_car_helper, 46
eelib.core.control.EMS.EMS_cs_helper, 48
eelib.core.control.EMS.EMS_hp_helper, 50
eelib.core.control.EMS.EMS_model, 52
eelib.core.control.EMS.EMS_simulator, 56
eelib.core.control.EMS.schedule_helper, 58
eelib.core.control.grid, 61
eelib.core.control.grid.grid_ems_model, 61
eelib.core.control.grid.grid_ems_simulator,
 62
eelib.core.devices, 64
eelib.core.devices.car, 64
eelib.core.devices.car.car_model, 64
eelib.core.devices.car.car_simulator, 66
eelib.core.devices.charging_station, 68
eelib.core.devices.charging_station.charging
 68
eelib.core.devices.charging_station.charging
 69
eelib.core.devices.heatpump, 71
eelib.core.devices.heatpump.heatpump_model,
 71
eelib.core.devices.heatpump.heatpump_simulator,
 72
eelib.core.devices.pv, 75
eelib.core.devices.pv.pv_lib_model, 75
eelib.core.devices.pv.pv_lib_simulator, 77
eelib.core.devices.storage, 79
eelib.core.devices.storage.storage_model, 79
eelib.core.devices.storage.storage_simulator,
 80
eelib.core.forecast, 83
eelib.core.forecast.forecast_model, 83
eelib.core.forecast.forecast_simulator, 84
eelib.core.grid, 86
eelib.core.grid.pandapower, 86
eelib.core.grid.pandapower.pandapower_model,

 86
eelib.core.grid.pandapower.pandapower_simulator,
 90
eelib.core.market, 92
eelib.core.market.retail_electricity_provider,
 92
eelib.core.market.retail_electricity_provider.rep_model,
 92
eelib.core.market.retail_electricity_provider.rep_simulator,
 93

d

eelib.data, 96
eelib.data.collector, 121
eelib.data.csv_reader, 96
eelib.data.csv_reader.csv_reader_model, 96
eelib.data.csv_reader.csv_reader_simulator,
 101
eelib.data.database, 103
eelib.data.database.hdf5, 103
eelib.data.dataclass, 106
eelib.data.dataclass._base, 106
eelib.data.dataclass.control, 107
eelib.data.dataclass.devices, 107
eelib.data.dataclass.options, 111
eelib.data.dataclass.tariff, 112
eelib.data.influx_reader, 114
eelib.data.influx_reader.influx_reader_model,
 114
eelib.data.influx_reader.influx_reader_simulator,
 118
eelib.data.input, 120
eelib.data.input.extract, 120
eelib.data.input.load, 120

e

eelib, 43

m

eelib.model_connections, 123
eelib.model_connections.connections, 123

U

`eelib.utils`, [124](#)
`eelib.utils.ancillary_services`, [124](#)
`eelib.utils.ancillary_services.voltage_control_concepts`,
 [124](#)
`eelib.utils.colormap`, [129](#)
`eelib.utils.eval`, [125](#)
`eelib.utils.eval.evaluation_utils`, [125](#)
`eelib.utils.logging_helpers`, [130](#)
`eelib.utils.read_pickle`, [132](#)
`eelib.utils.resample`, [132](#)
`eelib.utils.simulation_helper`, [133](#)
`eelib.utils.validation`, [139](#)

INDEX

Symbols

_VALID_PARAMETERS (*BSS attribute*), 79
_VALID_PARAMETERS (*CSVReader attribute*), 97
_VALID_PARAMETERS (*ChargingStation attribute*), 68
_VALID_PARAMETERS (*EV attribute*), 65
_VALID_PARAMETERS (*Forecast attribute*), 83
_VALID_PARAMETERS (*GenericInflux attribute*), 115
_VALID_PARAMETERS (*GridEMS attribute*), 61
_VALID_PARAMETERS (*HEMS attribute*), 52
_VALID_PARAMETERS (*Heatpump attribute*), 72
_VALID_PARAMETERS (*PVLibBase attribute*), 75
_VALID_PARAMETERS (*Pandapower attribute*), 87
_VALID_PARAMETERS (*RetailElectricityProvider attribute*), 92
__calc_appearance_duration() (*EV method*), 65
__calc_bev_consumption_period() (*EV method*), 66
__calc_charge_efficiency() (*BSS method*), 80
__calc_charging_efficiency() (*BSS method*), 80
__calc_discharge_efficiency() (*BSS method*), 80
__calc_next_arrival() (*EV method*), 65
__calc_power() (*EV method*), 65
__calc_power_limits() (*BSS method*), 80
__calc_power_limits() (*EV method*), 65
__calc_thermal_limits() (*Heatpump method*), 72
__calculate_aging_status() (*BSS method*), 80
__check_appearance() (*EV method*), 65
__del__() (*GenericInflux method*), 115
__del__() (*InfluxDbStorage method*), 121
__request_forecast() (*RetailElectricityProvider method*), 93
__set_emobpy_data() (*EV method*), 65
__set_energy_within_limit() (*BSS method*), 80
__set_energy_within_limit() (*EV method*), 65
__set_power_within_limit() (*BSS method*), 79
__set_state() (*Heatpump method*), 72
apply_p_rated() (*RatedCSV method*), 98
apply_p_rated() (*RatedInflux method*), 116
_calc_current_efficiency() (*ChargingStation method*), 69
_calc_financial_output() (*HEMS method*), 53
_calc_power_energy() (*HEMS method*), 53
_calc_power_limits() (*ChargingStation method*), 68
_calc_ptdf() (*Pandapower method*), 89
_calc_tariff_output() (*RetailElectricityProvider method*), 93
_calc_vpif() (*Pandapower method*), 89
_check_data() (*CSVReader method*), 97
_create_dataset() (*Hdf5Database method*), 104
_create_grid_tariff_signal() (*GridEMS method*), 61
_distribute_charging_power() (*ChargingStation method*), 69
_get_buses() (*Pandapower method*), 87
_get_component_by_type() (*HEMS method*), 52
_get_entity_path() (*Hdf5Database method*), 105
_get_grid_status() (*Pandapower method*), 89
_get_group() (*Hdf5Database method*), 105
_get_lines() (*Pandapower method*), 88
_get_loads() (*Pandapower method*), 87
_get_powerflow_result_component() (*Pandapower method*), 88
_get_slack() (*Pandapower method*), 87
_get_status_bus() (*Pandapower method*), 89
_get_status_line() (*Pandapower method*), 89
_get_supergroup() (*Hdf5Database method*), 105
_get_trafos() (*Pandapower method*), 88
_handle_incoming_signals() (*HEMS method*), 53
_load_case() (*Pandapower method*), 87
_logger (*in module eelib.core.control.EMS.schedule_helper*), 58
_logger (*in module eelib.core.forecast.forecast_model*), 83
_logger (*in module eelib.data.influx_reader.influx_reader_model*), 115
_logger (*in module eelib.utils.resample*), 133
_logger (*in module eelib.utils.simulation_helper*), 134
_open_csv() (*CSVReader method*), 97
_powerflow() (*Pandapower method*), 88
_read_config() (*in module eelib.utils.eval.evaluation_utils*), 128
_read_db() (*GenericInflux method*), 116
_request_forecast() (*HEMS_forecast_base method*), 54
_resample_data() (*CSVReader method*), 97

`_reset_financial_values()` (*HEMS method*), 53
`_retrieve_weather_step()` (*PVLibBase method*), 75
`_set_bss_p()` (*HEMS method*), 53
`_set_cs_p()` (*HEMS method*), 53
`_set_hp_p_th()` (*HEMS method*), 53
`_set_power()` (*PVLibBase method*), 76
`_set_power_in_limits()` (*HEMS_forecast_base method*), 54
`_set_pv_max()` (*HEMS method*), 53
`_set_reactive_power()` (*PowerCSV method*), 98
`_set_reactive_power()` (*PowerInflux method*), 117
`_set_schedule_values()` (*HEMS_forecast_base method*), 54
`_set_schedule_values_bss()` (*HEMS_forecast_base method*), 55
`_set_schedule_values_cs()` (*HEMS_forecast_base method*), 55
`_set_schedule_values_hp()` (*HEMS_forecast_base method*), 55
`_set_schedule_values_pv()` (*HEMS_forecast_base method*), 55
`_store_dict()` (*Hdf5Database method*), 105
`_store_json()` (*Hdf5Database method*), 105
`_store_power_flow_results()` (*Pandapower method*), 88
`_store_relations()` (*Hdf5Database method*), 104

A

`ac2bat_efficiency` (*BSSData attribute*), 109
`ADAPTION_TOLERANCE` (in module *eelib.core.control.EMS.EMS_simulator*), 56
`ADAPTION_TOLERANCE` (in module *eelib.core.control.grid.grid_ems_simulator*), 62
`ADAPTION_TOLERANCE` (in module *eelib.core.devices.car.car_simulator*), 66
`ADAPTION_TOLERANCE` (in module *eelib.core.devices.charging_station.charging_station_simuldblr*), 70
`ADAPTION_TOLERANCE` (in module *eelib.core.devices.heatpump.heatpump_simulator*), 73
`ADAPTION_TOLERANCE` (in module *eelib.core.devices.pv.pv_lib_simulator*), 77
`ADAPTION_TOLERANCE` (in module *eelib.core.devices.storage.storage_simulator*), 81
`ADAPTION_TOLERANCE` (in module *eelib.core.forecast.forecast_simulator*), 84
`ADAPTION_TOLERANCE` (in module *eelib.core.grid.pandapower.pandapower_simulator*), 90

`ADAPTION_TOLERANCE` (in module *eelib.core.market.retail_electricity_provider.rep_simulator*), 94
`add_controlled_entity()` (*HEMS method*), 52
`add_controlled_entity()` (*Sim method*), 58, 64
`add_forecasted_entity()` (*Forecast method*), 83
`add_forecasted_entity()` (*Sim method*), 86
`add_market_entity()` (*RetailElectricityProvider method*), 93
`add_market_entity()` (*Sim method*), 95
`appearance` (*EVData attribute*), 109

B

`BaseData` (*class in eelib.data.dataclass._base*), 106
`BaseDeviceData` (*class in eelib.data.dataclass.devices*), 108
`bat2ac_efficiency` (*BSSData attribute*), 109
`bat_cycles` (*BSSData attribute*), 109
`bat_cycles_max` (*BSSData attribute*), 108
`bold_red` (*CustomFormatter attribute*), 131
`bool_is_list` (*GridTariffSignal attribute*), 113
`bool_is_list` (*TariffSignal attribute*), 113
`BSS` (*class in eelib.core.devices.storage.storage_model*), 79
`bss_calc_balance()` (in module *eelib.core.control.EMS.EMS_bss_helper*), 44
`bss_calc_e_bat()` (in module *eelib.core.control.EMS.EMS_bss_helper*), 45
`bss_calc_p_limits()` (in module *eelib.core.control.EMS.EMS_bss_helper*), 46
`bss_calc_schedule()` (in module *eelib.core.control.EMS.schedule_helper*), 59
`bss_direct_cha` (*OptimOptions attribute*), 111
`bss_end_energy_incentive` (*OptimOptions attribute*),
`bss_set_energy_within_limit()` (in module *eelib.core.control.EMS.EMS_bss_helper*), 45

`bss_strategy_reduce_curtailment()` (in module *eelib.core.control.EMS.EMS_bss_helper*), 45

`BSSData` (*class in eelib.data.dataclass.devices*), 108

C

`calc_forecast_residual()` (in module *eelib.core.control.EMS.schedule_helper*), 58
`calc_forecast_thermal_residual()` (in module *eelib.core.control.EMS.schedule_helper*), 59
`calc_hp_power_limits()` (in module *eelib.core.control.EMS.EMS_hp_helper*), 51

calc_schedule_opt() (in module `eelib.core.control.EMS.schedule_helper`), 60
 capacity_fee_dem (`GridTariff` attribute), 113
 capacity_fee_dem (`GridTariffSignal` attribute), 114
 capacity_fee_dem (`Tariff` attribute), 112
 capacity_fee_dem (`TariffSignal` attribute), 113
 capacity_fee_gen (`GridTariff` attribute), 113
 capacity_fee_gen (`GridTariffSignal` attribute), 114
 capacity_fee_gen (`Tariff` attribute), 112
 capacity_fee_gen (`TariffSignal` attribute), 113
 capacity_fee_horizon_sec (`GridTariff` attribute), 113
 capacity_fee_horizon_sec (`GridTariffSignal` attribute), 114
 capacity_fee_horizon_sec (`Tariff` attribute), 112
 capacity_fee_horizon_sec (`TariffSignal` attribute), 113
 car_calc_e_bat() (in module `eelib.core.control.EMS.EMS_car_helper`), 46
 car_calc_power() (in module `eelib.core.control.EMS.EMS_car_helper`), 47
 car_calc_power_limits() (in module `eelib.core.control.EMS.EMS_car_helper`), 47
 car_set_energy_within_limit() (in module `eelib.core.control.EMS.EMS_car_helper`), 47
 charge_efficiency (`BSSData` attribute), 109
 charge_efficiency (`CSDData` attribute), 109
 charge_efficiency (`EVData` attribute), 109
 ChargingStation (class in `eelib.core.devices.charging_station.charging_station`), 68
 ChargingStationCSV (class in `eelib.data.csv_reader.csv_reader_model`), 99
 check_adaption_tolerance() (`BaseData` method), 106
 check_model_connect_config() (in module `eelib.utils.simulation_helper`), 136
 clear_logger() (in module `eelib.utils.logging_helpers`), 131
 Collector (class in `eelib.data.collector`), 122
 conf (in module `eelib.model_connections.connections`), 123
 connect_entities() (in module `eelib.utils.simulation_helper`), 136
 connect_entities_in_grid() (in module `eelib.utils.simulation_helper`), 137
 connect_entities_of_two_model_types() (in module `eelib.utils.simulation_helper`), 138
 connect_entities_to_db() (in module `eelib.utils.simulation_helper`), 137
 connect_grid_to_db() (in module `eelib.utils.simulation_helper`), 138
 connect_to_forecast() (in module `eelib.utils.simulation_helper`), 138
 consider_thermal (`OptimOptions` attribute), 111
 ControlSignalEMS (class in `eelib.data.dataclass.control`), 107
 convert_hdf5_to_csv() (in module `eelib.utils.eval.evaluation_utils`), 127
 cop (`HPData` attribute), 110
 cos_phi_fix() (in module `eelib.utils.ancillary_services.voltage_control_concepts`), 124
 create() (*Collector* method), 122
 create() (*Hdf5Database* method), 103
 create() (*Sim* method), 57, 63, 67, 70, 73, 78, 81, 85, 91, 94, 101, 119
 create_entities() (in module `eelib.utils.simulation_helper`), 135
 create_entities_of_model() (in module `eelib.utils.simulation_helper`), 136
 create_plots() (in module `eelib.utils.simulation_helper`), 135
 cs_calc_current_efficiency() (in module `eelib.core.control.EMS.EMS_cs_helper`), 49
 cs_calc_power_limits() (in module `eelib.core.control.EMS.EMS_cs_helper`), 49
 cs_calc_schedule_uncontrolled() (in module `eelib.core.control.EMS.schedule_helper`), 60
 in cs_distribute_charging_power() (in module `eelib.core.control.EMS.EMS_cs_helper`), 48
 cs_strategy_balanced_charging() (in module `eelib.core.control.EMS.EMS_cs_helper`), 48
 cs_strategy_night_charging() (in module `eelib.core.control.EMS.EMS_cs_helper`), 48
 cs_strategy_solar_charging() (in module `eelib.core.control.EMS.EMS_cs_helper`), 48
 CSDData (class in `eelib.data.dataclass.devices`), 109
 CSVReader (class in `eelib.data.csv_reader.csv_reader_model`), 96
 CustomFormatter (class in `eelib.utils.logging_helpers`), 131

D

data_path (in module `eelib.data.input.load`), 121
 dcharge_efficiency (`EVData` attribute), 109
 dir_cha_desc_factor (`OptimOptions` attribute), 111
 DISC_CMAP (in module `eelib.utils.colormap`), 130
 discharge_efficiency (`BSSData` attribute), 109

discharge_efficiency (*CSData attribute*), 109
dod_max (*BSSData attribute*), 108

E

e_bat (*BSSData attribute*), 109
e_bat (*EVData attribute*), 109
e_bat_rated (*BSSData attribute*), 108
e_bat_usable (*BSSData attribute*), 109
e_max (*EVData attribute*), 109
eelib
 module, 43
eelib.core
 module, 44
eelib.core.control
 module, 44
eelib.core.control.EMS
 module, 44
eelib.core.control.EMS.EMS_bss_helper
 module, 44
eelib.core.control.EMS.EMS_car_helper
 module, 46
eelib.core.control.EMS.EMS_cs_helper
 module, 48
eelib.core.control.EMS.EMS_hp_helper
 module, 50
eelib.core.control.EMS.EMS_model
 module, 52
eelib.core.control.EMS.EMS_simulator
 module, 56
eelib.core.control.EMS.schedule_helper
 module, 58
eelib.core.control.grid
 module, 61
eelib.core.control.grid.grid_ems_model
 module, 61
eelib.core.control.grid.grid_ems_simulator
 module, 62
eelib.core.devices
 module, 64
eelib.core.devices.car
 module, 64
eelib.core.devices.car.car_model
 module, 64
eelib.core.devices.car.car_simulator
 module, 66
eelib.core.devices.charging_station
 module, 68
eelib.core.devices.charging_station.charging_station
 module, 68
eelib.core.devices.charging_station.charging_station_simulator
 module, 69
eelib.core.devices.heatpump
 module, 71
eelib.core.devices.heatpump.heatpump_model

 module, 71
eelib.core.devices.heatpump.heatpump_simulator
 module, 72
eelib.core.devices.pv
 module, 75
eelib.core.devices.pv.pv_lib_model
 module, 75
eelib.core.devices.pv.pv_lib_simulator
 module, 77
eelib.core.devices.storage
 module, 79
eelib.core.devices.storage.storage_model
 module, 79
eelib.core.devices.storage.storage_simulator
 module, 80
eelib.core.forecast
 module, 83
eelib.core.forecast.forecast_model
 module, 83
eelib.core.forecast.forecast_simulator
 module, 84
eelib.core.grid
 module, 86
eelib.core.grid.pandapower
 module, 86
eelib.core.grid.pandapower.pandapower_model
 module, 86
eelib.core.grid.pandapower.pandapower_simulator
 module, 90
eelib.core.market
 module, 92
eelib.core.market.retail_electricity_provider
 module, 92
eelib.core.market.retail_electricity_provider.rep_model
 module, 92
eelib.core.market.retail_electricity_provider.rep_simulator
 module, 93
eelib.data
 module, 96
eelib.data.collector
 module, 121
eelib.data.csv_reader
 module, 96
eelib.data.csv_reader.csv_reader_model
 module, 96
eelib.data.csv_reader.csv_reader_simulator
 module, 101
eelib.data.database
 module, 103
eelib.data.database.hdf5
 module, 103
eelib.data.dataclass
 module, 106
eelib.data.dataclass._base

module, 106
`eelib.data.dataclass.control`
 module, 107
`eelib.data.dataclass.devices`
 module, 107
`eelib.data.dataclass.options`
 module, 111
`eelib.data.dataclass.tariff`
 module, 112
`eelib.data.influx_reader`
 module, 114
`eelib.data.influx_reader.influx_reader_model`
 module, 114
`eelib.data.influx_reader.influx_reader_simulator`
 module, 118
`eelib.data.input`
 module, 120
`eelib.data.input.extract`
 module, 120
`eelib.data.input.load`
 module, 120
`eelib.model_connections`
 module, 123
`eelib.model_connections.connections`
 module, 123
`eelib.utils`
 module, 124
`eelib.utils.ancillary_services`
 module, 124
`eelib.utils.ancillary_services.voltage_control_concepts`
 module, 124
`eelib.utils.colormap`
 module, 129
`eelib.utils.eval`
 module, 125
`eelib.utils.eval.evaluation_utils`
 module, 125
`eelib.utils.logging_helpers`
 module, 130
`eelib.utils.read_pickle`
 module, 132
`eelib.utils.resample`
 module, 132
`eelib.utils.simulation_helper`
 module, 133
`eelib.utils.validation`
 module, 139
`elec_price` (*Tariff attribute*), 112
`elec_price` (*TariffSignal attribute*), 113
`ELENIA_CMAP` (*in module eelib.utils.colormap*), 129
`END`, 41
`energy_price` (*GridTariff attribute*), 113
`energy_price` (*GridTariffSignal attribute*), 114
`Entity`, 40

EV (*class in eelib.core.devices.car.car_model*), 65
`ev_data` (*CSData attribute*), 109
`ev_direct_cha` (*OptimOptions attribute*), 111
`ev_end_energy_penalty` (*OptimOptions attribute*), 111
`EVData` (*class in eelib.data.dataclass.devices*), 109
event-based/hybrid, 40
`extract_htw()` (*in module eelib.data.input.extract*), 120

F

`feedin_tariff` (*Tariff attribute*), 112
`feedin_tariff` (*TariffSignal attribute*), 113
`find_corresponding_component()` (*in module eelib.utils.eval.evaluation_utils*), 126
`find_corresponding_component_dict()` (*in module eelib.utils.eval.evaluation_utils*), 126
Forecast, 40
Forecast (*class in eelib.core.forecast.forecast_model*), 83
`forecast_types` (*HEMS_forecast_base attribute*), 54
`format()` (*CustomFormatter method*), 131
`format_str` (*CustomFormatter attribute*), 131
`format_valid_parameters_dictionary()` (*in module eelib.utils.validation*), 140
FORMATS (*CustomFormatter attribute*), 131

G

`GCP_Aggregator_HEMS` (*class in eelib.core.control.EMS.EMS_model*), 54
`generate_influx_query()` (*GenericInflux method*), 115
`generate_tag_filter()` (*GenericInflux static method*), 115
`GenericCSV` (*class in eelib.data.csv_reader.csv_reader_model*), 97
GenericInflux (*class in eelib.data.influx_reader.influx_reader_model*), 115
`get_config()` (*in module eelib.utils.eval.evaluation_utils*), 127
`get_connection_directions_config()` (*in module eelib.model_connections.connections*), 123
`get_data()` (*Sim method*), 57, 63, 67, 71, 74, 78, 82, 85, 91, 95, 102, 119
`get_default_connections()` (*in module eelib.model_connections.connections*), 123
`get_default_dirs()` (*in module eelib.utils.simulation_helper*), 139
`get_entity_by_id()` (*in module eelib.utils.simulation_helper*), 134
`get_entity_by_id()` (*Sim method*), 57, 63, 67, 70, 74, 78, 82, 85, 91, 94, 102
`get_entity_by_id_from_dict_list()` (*in module eelib.utils.simulation_helper*), 135

get_grid_components() (in module `eelib.utils.simulation_helper`), 136
 get_resolution_pandas_timeseries() (in module `eelib.utils.resample`), 133
 get_timeseries() (in module `eelib.utils.eval.evaluation_utils`), 127
 get_valid_parameters() (*BSS* class method), 79
 get_valid_parameters() (*ChargingStation* class method), 68
 get_valid_parameters() (*ChargingStationCSV* class method), 99
 get_valid_parameters() (*CSVReader* class method), 97
 get_valid_parameters() (*EV* class method), 65
 get_valid_parameters() (*Forecast* class method), 83
 get_valid_parameters() (*GCP_Aggregator_HEMS* class method), 54
 get_valid_parameters() (*GenericCSV* class method), 97
 get_valid_parameters() (*GenericInflux* class method), 115
 get_valid_parameters() (*GridEMS* class method), 61
 get_valid_parameters() (*Heatpump* class method), 72
 get_valid_parameters() (*HeatpumpCSV* class method), 99
 get_valid_parameters() (*HEMS* class method), 52
 get_valid_parameters() (*HEMS_default* class method), 53
 get_valid_parameters() (*HEMS_forecast_base* class method), 54
 get_valid_parameters() (*HEMS_forecast_default* class method), 55
 get_valid_parameters() (*HEMS_forecast_opt* class method), 55
 get_valid_parameters() (*HouseholdCSV* class method), 98
 get_valid_parameters() (*HouseholdInflux* class method), 117
 get_valid_parameters() (*HouseholdThermalCSV* class method), 100
 get_valid_parameters() (*MarketIntradayContinuousCSV* class method), 100
 get_valid_parameters() (*Pandapower* class method), 87
 get_valid_parameters() (*PowerCSV* class method), 98
 get_valid_parameters() (*PowerInflux* class method), 117
 get_valid_parameters() (*PvCSV* class method), 99
 get_valid_parameters() (*PvInflux* class method), 117
 get_valid_parameters() (*PVLib* class method), 76
 get_valid_parameters() (*PVLibBase* class method), 75
 get_valid_parameters() (*PVLibExact* class method), 76
 get_valid_parameters() (*RatedCSV* class method), 98
 get_valid_parameters() (*RatedInflux* class method), 116
 get_valid_parameters() (*RetailElectricityProvider* class method), 92
 grey (*CustomFormatter* attribute), 131
 grid_tariff_model (*GridTariff* attribute), 113
 GridEMS (class in `eelib.core.control.grid.grid_ems_model`), 61
 GridTariff (class in `eelib.data.dataclass.tariff`), 113
 GridTariffSignal (class in `eelib.data.dataclass.tariff`), 113

H

hdf5_file_as_pandas() (in module `eelib.utils.eval.evaluation_utils`), 126
 Hdf5Database (class in `eelib.data.database.hdf5`), 103
 Heatpump (class in `eelib.core.devices.heatpump.heatpump_model`), 72
 HeatpumpCSV (class in `eelib.data.csv_reader.csv_reader_model`), 99
 HEMS (class in `eelib.core.control.EMS.EMS_model`), 52
 HEMS_default (class in `eelib.core.control.EMS.EMS_model`), 53
 HEMS_forecast_base (class in `eelib.core.control.EMS.EMS_model`), 54
 HEMS_forecast_default (class in `eelib.core.control.EMS.EMS_model`), 55
 HEMS_forecast_opt (class in `eelib.core.control.EMS.EMS_model`), 55
 HouseholdCSV (class in `eelib.data.csv_reader.csv_reader_model`), 98
 HouseholdInflux (class in `eelib.data.influx_reader.influx_reader_model`), 117
 HouseholdThermalCSV (class in `eelib.data.csv_reader.csv_reader_model`), 100
 hp_calc_schedule() (in module `eelib.core.control.EMS.schedule_helper`), 59
 hp_set_power_with_limits() (in module `eelib.core.control.EMS.EMS_hp_helper`), 50
 HPData (class in `eelib.data.dataclass.devices`), 110

I

InfluxDbStorage (class in `eelib.data.input.load`), 121
 init() (Collector method), 122

`init()` (*Hdf5Database method*), 103
`init()` (*Sim method*), 56, 62, 66, 70, 73, 77, 81, 84, 90, 94, 101, 118

L

`LIM` (*Pandapower attribute*), 87
`LOGGING_FORMAT` (in module `eelib.utils.logging_helpers`), 131
`loss_rate` (*BSSData attribute*), 108

M

`make_compact()` (in module `eelib.utils.eval.evaluation_utils`), 126
`market_info_attrs` (*RetailElectricityProvider attribute*), 92
`MarketData` (class in `eelib.data.dataclass.tariff`), 112
`MarketIntradayContinuousCSV` (class in `eelib.data.csv_reader.csv_reader_model`), 100
`META` (in module `eelib.core.control.EMS.EMS_simulator`), 56
`META` (in module `eelib.core.control.grid.grid_ems_simulator`), 62
`META` (in module `eelib.core.devices.car.car_simulator`), 66
`META` (in module `eelib.core.devices.charging_station.charging_station_simulator`), 70
`META` (in module `eelib.core.devices.heatpump.heatpump_simulator`), 73
`META` (in module `eelib.core.devices.pv.pv_lib_simulator`), 77
`META` (in module `eelib.core.devices.storage.storage_simulator`), 81
`META` (in module `eelib.core.forecast.forecast_simulator`), 84
`META` (in module `eelib.core.grid.pandapower.pandapower_simulator`), 90
`META` (in module `eelib.core.market.retail_electricity_provider.rep_simulator`), 94
`META` (in module `eelib.data.collector`), 122
`META` (in module `eelib.data.csv_reader.csv_reader_simulator`), 101
`meta` (in module `eelib.data.database.hdf5`), 103
`META` (in module `eelib.data.influx_reader.influx_reader_simulator`), 118
`Model`, 40
`module`
 `eelib`, 43
 `eelib.core`, 44
 `eelib.core.control`, 44
 `eelib.core.control.EMS`, 44
 `eelib.core.control.EMS.EMS_bss_helper`, 44
 `eelib.core.control.EMS.EMS_car_helper`, 46
 `eelib.core.control.EMS.EMS_cs_helper`, 48

`eelib.core.control.EMS.EMS_hp_helper`, 50
`eelib.core.control.EMS.EMS_model`, 52
`eelib.core.control.EMS.EMS_simulator`, 56
`eelib.core.control.EMS.schedule_helper`, 58
`eelib.core.control.grid`, 61
`eelib.core.control.grid.grid_ems_model`, 61
`eelib.core.control.grid.grid_ems_simulator`, 62
`eelib.core.devices`, 64
`eelib.core.devices.car`, 64
`eelib.core.devices.car.car_model`, 64
`eelib.core.devices.car.car_simulator`, 66
`eelib.core.devices.charging_station`, 68
`eelib.core.devices.charging_station.charging_station_m`, 68
`eelib.core.devices.charging_station.charging_station_s`, 69
`eelib.core.devices.heatpump`, 71
`eelib.core.devices.heatpump.heatpump_model`, 71
`eelib.core.devices.heatpump.heatpump_simulator`, 72
`eelib.core.devices.pv`, 75
~~`eelib.core.devices.pv.pv_lib_model`~~, 75
`eelib.core.devices.pv.pv_lib_simulator`, 77
`eelib.core.devices.storage`, 79
`eelib.core.devices.storage.storage_model`, 79
`eelib.core.devices.storage.storage_simulator`, 80
`eelib.core.forecast`, 83
`eelib.core.forecast.forecast_model`, 83
`eelib.core.forecast.forecast_simulator`, 84
~~`eelib.core.grid`~~, 86
~~`eilib.core.grid.pandapower`~~, 86
`eelib.core.grid.pandapower.pandapower_model`, 86
`eelib.core.grid.pandapower.pandapower_simulator`, 90
`eelib.core.market`, 92
`eelib.core.market.retail_electricity_provider`, 92
`eelib.core.market.retail_electricity_provider.rep_mode`, 92
`eelib.core.market.retail_electricity_provider.rep_simu`, 93
`eelib.data`, 96
`eelib.data.collector`, 121
`eelib.data.csv_reader`, 96
`eelib.data.csv_reader.csv_reader_model`,

96
eelib.data.csv_reader.csv_reader_simulator
 p_nom_charge_max (*EVData attribute*), 109
 p_nom_discharge_max (*EVData attribute*), 109
 p_rated (*CSDData attribute*), 109
 p_rated (*PVData attribute*), 110
 p_rated_charge_max (*BSSData attribute*), 108
 p_rated_discharge_max (*BSSData attribute*), 108
 p_rated_th (*HPData attribute*), 110
 p_th (*HPData attribute*), 110
 p_th_max (*HPData attribute*), 110
 p_th_min (*HPData attribute*), 110
 p_th_min_on (*HPData attribute*), 110
eelib.data.influx_reader.influx_reader_model
Pandapower (*class in eelib.core.grid.pandapower.pandapower_model*), 87
penalty_cost (*ControlSignalEMS attribute*), 107
PowerCSV (*class in eelib.data.csv_reader.csv_reader_model*), 98
PowerInflux (*class in eelib.data.influx_reader.influx_reader_model*), 116
 price_high (*MarketData attribute*), 112
 price_last (*MarketData attribute*), 112
 price_low (*MarketData attribute*), 112
price_weighted_avg (*MarketData attribute*), 112
PRIM_DISC_CMAP (*in module eelib.utils.colormap*), 129
PRIM_ELENIA_CMAP (*in module eelib.utils.colormap*), 129
PRIM_INT_CMAP (*in module eelib.utils.colormap*), 130
PSC, 40
pv_calc_schedule() (*in module eelib.core.control.EMS.schedule_helper*), 59
PvCSV (*class in eelib.data.csv_reader.csv_reader_model*), 99
PVData (*class in eelib.data.dataclass.devices*), 110
PvInflux (*class in eelib.data.influx_reader.influx_reader_model*), 117
PVLib (*class in eelib.core.devices.pv.pv_lib_model*), 76
PVLibBase (*class in eelib.core.devices.pv.pv_lib_model*), 75
PVLibExact (*class in eelib.core.devices.pv.pv_lib_model*), 76
Q
 q (*CSDData attribute*), 110
 q (*HPData attribute*), 110
 q (*PVData attribute*), 110
R
RatedCSV (*class in eelib.data.csv_reader.csv_reader_model*), 97
RatedInflux (*class in eelib.data.influx_reader.influx_reader_model*), 116

`read_pickle()` (*in module eelib.utils.read_pickle*), 132
`red` (*CustomFormatter attribute*), 131
`RED_GREEN_INT_CMAP` (*in module eelib.utils.colormap*), 130
`RED_GREEN_RED_INT_CMAP` (*in module eelib.utils.colormap*), 130
`register_and_use_elenia_colormap()` (*in module eelib.utils.colormap*), 130
`RENAMING_ATTRS` (*in module eelib.core.grid.pandapower.pandapower_model*), 87
`resample_pandas_timeseries_agg()` (*in module eelib.utils.resample*), 133
`reset` (*CustomFormatter attribute*), 131
`RetailElectricityProvider` (*class in module eelib.core.market.retail_electricity_provider.rep_provider*), 92
`round_int` (*OptimOptions attribute*), 111

S

`save_figure()` (*in module eelib.utils.eval.evaluation_utils*), 128
`Schedule`, 40
`SEC_DISC_CMAP` (*in module eelib.utils.colormap*), 130
`SEC_ELENIA_CMAP` (*in module eelib.utils.colormap*), 129
`SEC_INT_CMAP` (*in module eelib.utils.colormap*), 130
`self_discharge_step` (*BSSData attribute*), 108
`set_connection_direction()` (*in module eelib.utils.simulation_helper*), 137
`set_console_logger()` (*in module eelib.utils.logging_helpers*), 131
`set_file_logger()` (*in module eelib.utils.logging_helpers*), 131
`set_hp_state()` (*in module eelib.core.control.EMS.EMS_hp_helper*), 51
`set_hp_time()` (*in module eelib.core.control.EMS.EMS_hp_helper*), 50
`set_inputs()` (*Pandapower method*), 88
`set_meta_attrs()` (*in module eelib.data.influx_reader.influx_reader_simulator*), 118
`setup_done()` (*Hdf5Database method*), 104
`setup_done()` (*Sim method*), 91
`Sim` (*class in eelib.core.control.EMS.EMS_simulator*), 56
`Sim` (*class in eelib.core.control.grid.grid_ems_simulator*), 62
`Sim` (*class in eelib.core.devices.car.car_simulator*), 66
`Sim` (*class in eelib.core.devices.charging_station.charging_station_simulator*), 70
`Sim` (*class in eelib.core.devices.heatpump.heatpump_simulator*), 73
`Sim` (*class in eelib.core.devices.pv.pv_lib_simulator*), 77
`Sim` (*class in eelib.core.devices.storage.storage_simulator*), 81
`Sim` (*class in eelib.core.forecast.forecast_simulator*), 84
`Sim` (*class in eelib.core.grid.pandapower.pandapower_simulator*), 90
`Sim` (*class in eelib.core.market.retail_electricity_provider.rep_simulator*), 94
`Sim` (*class in eelib.data.csv_reader.csv_reader_simulator*), 101
`Sim` (*class in eelib.data.influx_reader.influx_reader_simulator*), 118
`Simulator`, 40
`soc_min` (*BSSData attribute*), 109
`soc_min` (*EVData attribute*), 109
`soh` (*BSSData attribute*), 109
`soh_cycles_max` (*BSSData attribute*), 108
`START`, 41
`start_simulators()` (*in module eelib.utils.simulation_helper*), 135
`state` (*HPData attribute*), 110
`status_aging` (*BSSData attribute*), 108
`step()` (*BSS method*), 80
`step()` (*ChargingStation method*), 69
`step()` (*Collector method*), 122
`step()` (*CSVReader method*), 97
`step()` (*EV method*), 65
`step()` (*Forecast method*), 83
`step()` (*GCP_Aggregator_HEMS method*), 54
`step()` (*GenericCSV method*), 97
`step()` (*GenericInflux method*), 116
`step()` (*GridEMS method*), 61
`step()` (*Hdf5Database method*), 104
`step()` (*Heatpump method*), 72
`step()` (*HeatpumpCSV method*), 99
`step()` (*HEMS method*), 53
`step()` (*HEMS_default method*), 53
`step()` (*HEMS_forecast_base method*), 55
`step()` (*HEMS_forecast_default method*), 55
`step()` (*HEMS_forecast_opt method*), 55
`step()` (*HouseholdThermalCSV method*), 100
`step()` (*MarketIntradayContinuousCSV method*), 100
`step()` (*Pandapower method*), 88
`step()` (*PowerCSV method*), 98
`step()` (*PowerInflux method*), 117
`step()` (*PvCSV method*), 99
`step()` (*PVLib method*), 76
`step()` (*PVLibBase method*), 76
`step()` (*PVLibExact method*), 76
`step()` (*RetailElectricityProvider method*), 93
`step()` (*Sim method*), 57, 63, 67, 71, 74, 78, 82, 85, 91, 95, 102, 119
`STEP_SIZE_IN_SECONDS`, 41
`steps` (*ControlSignalEMS attribute*), 107
`steps` (*GridTariffSignal attribute*), 114

steps (*TariffSignal attribute*), 113

T

Tariff (*class in eelib.data.dataclass.tariff*), 112
TariffSignal (*class in eelib.data.dataclass.tariff*), 113
th_e_penalty (*OptimOptions attribute*), 111
thermal_energy_restriction (*OptimOptions attribute*), 111
thermal_energy_start (*OptimOptions attribute*), 111
time_min (*HPData attribute*), 110
time_off (*HPData attribute*), 110
time_on (*HPData attribute*), 110
time-based, 40
timestep_to_datetime() (in module
 `eeelib.utils.eval.evaluation_utils`), 128
TOLERANCE_OVERCHARGED (in module
 `eeelib.core.devices.car.car_model`), 65

U

USE_FORECAST, 41

V

validate_init_parameters() (in module
 `eeelib.utils.validation`), 139

W

write_pandas_dataframe() (InfluxDbStorage
 method), 121

Y

yellow (*CustomFormatter attribute*), 131